



ACCESS CODE FOR TRANSMISSION

Attachment A: Transmission Model

Table of contents

Table of contents	2
1 Definitions	73
1.1 Naming conventions.....	83
1.2 List of definitions	94
2 Application area.....	2749
3 Services	2749
3.1 Entry and Exit Services	2749
3.1.1 Overview and characteristics of subscribed MTSR of Entry and Exit Services	2749
3.1.2 Energy MTSR (EMTSR) and Volume MTSR (VMTSR).....	3224
3.1.3 Capacity Exceedings.....	3324
3.2 Short haul Services	3627
3.2.1 Wheelings and OCUC (Operational Capacity Usage Commitments).....	3627
3.2.2 Zee Platform Service.....	3728
3.3 Cross Border Delivery Service	3829
3.4 Quality Conversion Services	3930
3.4.1 Quality Conversion Services H→L.....	3930
3.4.2 Quality Conversion Services L→H.....	4031
3.5 ZTP Trading Services.....	4031
3.5.1 Overview on the ZTP Trading Services.....	4031
3.5.2 Imbalance Pooling Service.....	4131
3.5.3 Imbalance Transfer Service.....	4132
3.6 Substitution Services	4233
3.6.1 Capacity Conversion Service	4333
3.6.2 L/H Capacity Switch Service	4434
3.6.3 Diversion Service.....	4635
3.7 Ancillary Services	4736
3.7.1 Real-time data measurement	4736
4 Nominations, Metering and Allocations.....	4736
4.1 Overview	4736
4.2 Nominations	4736
4.3 Metering	4836
4.4 Allocations.....	4836
5 Balancing and Allocation settlement	4837
5.1 Hourly exchange of information between the TSO and the Balancing Operator	4837
5.2 Allocation Settlements.....	4937
5.2.1 Allocation Settlement Network User Sale	4938
5.2.2 Allocation Settlement Network User Purchase	4938
6 Invoicing.....	5038
6.1 General	5038
6.2 Monthly Invoice	5139
6.2.1 Monthly Capacity Fees	5139
6.2.2 Monthly Variable Flex Fee	5746
6.2.3 Monthly Zee Platform Fee	5846
6.2.4 Monthly Quality Conversion H->L Capacity Fee	5947
6.2.5 Monthly Capacity Fee for Quality Conversion L->H	5947
6.2.6 Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service	6048
6.2.7 Monthly Energy In Cash Fee	6048
6.2.8 Monthly Allocation Settlement Fees.....	6149
6.2.9 Monthly Transmission Imbalance Fees.....	6149
6.2.10 Monthly Odourisation Fees.....	6149
6.2.11 Monthly Fix ZTP Trading Services Fee.....	6250
6.2.12 Capacity Exceedings	6250
6.2.13 Monthly Administrative Fees.....	6250
6.3 Monthly Self-billing Invoice	6351

Table of contents	2
1— Definitions	3
1.1— Naming conventions	3
1.2— List of definitions	4
2— Application area	19
3— Services	20
3.1— Services on Interconnection Points and Installation Points	20
3.1.1— Entry and Exit Services	20
3.2— Short haul Services	28
3.2.1— Wheelings and OCUC (Operational Capacity Usage Commitments)	28
3.2.2— Zee Platform Service	29
3.3— Cross Border Delivery Service	30
3.4— Quality Conversion Services	31
3.4.1— Quality Conversion Services H → L	31
3.4.2— Quality Conversion Services L → H	32
3.5— ZTP Trading Services	32
3.5.1— Overview on the ZTP Trading Services	32
3.5.2— Imbalance Pooling Service	32
3.5.3— Imbalance Transfer Service	33
3.6— Substitution Services	34
3.6.1— Capacity Conversion Service	34
3.6.2— L/H Capacity Switch Service	34
3.6.3— Diversion Service	36
3.7— Ancillary Services	37
3.7.1— Real time data measurement	37
4— Nominations, Metering and Allocations	37
4.1— Overview	37
4.2— Nominations	37
4.3— Metering	37
4.4— Allocations	37
5— Balancing and Allocation settlement	38
5.1— Hourly exchange of information between the TSO and the Balancing Operator	38
5.2— Allocation Settlements	38
5.2.1— Allocation Settlement Network User Sale	39
5.2.2— Allocation Settlement Network User Purchase	39
6— Invoicing	39
6.1— General	39
6.2— Monthly Invoice	40
6.2.1— Monthly Capacity Fees	40
6.2.2— Monthly Variable Flex Fee	47
6.2.3— Monthly Zee Platform Fee	48
6.2.4— Monthly Quality Conversion H > L Capacity Fee	48
6.2.5— Monthly Capacity Fee for Quality Conversion L > H	48
6.2.6— Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service	49
6.2.7— Monthly Energy In Cash Fee	49
6.2.8— Monthly Allocation Settlement Fees	50
6.2.9— Monthly Transmission Imbalance Fees	50
6.2.10— Monthly Odorisation Fees	50
6.2.11— Monthly Fix ZTP Trading Services Fee	51
6.2.12— Capacity Exceedings	51
6.2.13— Monthly Administrative Fees	51
6.3— Monthly Self billing Invoice	52
Table of contents	2
1— Definitions	3
1.1— Naming conventions	3

1.2	List of definitions	4
2	Application area	19
3	Services	20
3.1	Services on Interconnection Points and Installation Points	20
3.1.1	Entry and Exit Services	20
3.2	Short haul Services	29
3.2.1	Wheelings and OCUC (Operational Capacity Usage Commitments)	29
3.2.2	Zee Platform Service	30
3.3	Cross Border Delivery Service	30
3.4	Quality Conversion Services	31
3.4.1	Quality Conversion Services H → L	31
3.4.2	Quality Conversion Services L → H	32
3.5	ZTP Trading Services	32
3.5.1	Overview on the ZTP Trading Services	32
3.5.2	Imbalance Pooling Service	33
3.5.3	Imbalance Transfer Service	33
3.6	Substitution Services	34
3.6.1	Capacity Conversion Service	35
3.6.2	L/H Capacity Switch Service	35
3.6.3	Diversion Service	36
3.7	Ancillary Services	37
3.7.1	Real-time data measurement	37
4	Nominations, Metering and Allocations	37
4.1	Overview	37
4.2	Nominations	38
4.3	Metering	38
4.4	Allocations	38
5	Balancing and Allocation settlement	38
5.1	Hourly exchange of information between the TSO and the Balancing Operator	38
5.2	Allocation Settlements	39
5.2.1	Allocation Settlement Network User Sale	39
5.2.2	Allocation Settlement Network User Purchase	39
6	Invoicing	40
6.1	General	40
6.2	Monthly Invoice	41
6.2.1	Monthly Capacity Fees	41
6.2.2	Monthly Variable Flex Fee	47
6.2.3	Monthly Zee Platform Fee	47
6.2.4	Monthly Quality Conversion H → L Capacity Fee	48
6.2.5	Monthly Capacity Fee for Quality Conversion L → H	48
6.2.6	Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service	49
6.2.7	Monthly Energy In Cash Fee	49
6.2.8	Monthly Allocation Settlement Fees	50
6.2.9	Monthly Transmission Imbalance Fees	50
6.2.10	Monthly Odourisation Fees	50
6.2.11	Monthly Fix ZTP Trading Services Fee	51
6.2.12	Capacity Exceedings	51
6.2.13	Monthly Administrative Fees	51
6.3	Monthly Self-billing Invoice	52
	Table of contents	2
1	Definitions	3
1.1	Naming conventions	3
1.2	List of definitions	4
2	Application area	20
3	Services	20

3.1	Services on Interconnection Points and Installation Points	20
3.1.1	Entry and Exit Services	20
3.2	Short haul Services	28
3.2.1	Wheelings and OCUC (Operational Capacity Usage Commitments)	28
3.2.2	Zee Platform Service	29
3.3	Cross Border Delivery Service	30
3.4	Quality Conversion Services	31
3.4.1	Quality Conversion Services H→L	31
3.4.2	Quality Conversion Services L→H	32
3.5	ZTP Trading Services	32
3.5.1	Overview on the ZTP Trading Services	32
3.5.2	Imbalance Pooling Service	32
3.5.3	Imbalance Transfer Service	33
3.6	Substitution Services	34
3.6.1	Capacity Conversion Service	34
3.6.2	Reshuffling Service	34
3.6.3	L/H Capacity Switch Service	35
3.6.4	Diversion Service	37
3.7	Ancillary Services	38
3.7.1	Real-time data measurement	38
4	Nominations, Metering and Allocations	38
4.1	Overview	38
4.2	Nominations	38
4.3	Metering	38
4.4	Allocations	39
5	Balancing and Allocation settlement	39
5.1	Hourly exchange of information between the TSO and the Balancing Operator	39
5.2	Allocation Settlements	39
5.2.1	Allocation Settlement Grid User Sale	40
5.2.2	Allocation Settlement Grid User Purchase	40
6	Invoicing	40
6.1	General	40
6.2	Monthly Invoice	41
6.2.1	Monthly Capacity Fees	41
6.2.2	Monthly Variable Flex Fee	46
6.2.3	Monthly Zee Platform Fee	47
6.2.4	Monthly Quality Conversion H > L Capacity Fee	47
6.2.5	Monthly Capacity Fee for Quality Conversion L > H	48
6.2.6	Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service	48
6.2.7	Monthly Energy In Cash Fee	49
6.2.8	Monthly Allocation Settlement Fees	49
6.2.9	Monthly Transmission Imbalance Fees	50
6.2.10	Monthly Odourisation Fees	50
6.2.11	Monthly Fix ZTP Trading Services Fee	50
6.2.12	Capacity Exceedings	51
6.2.13	Monthly Administrative Fees	51
6.3	Monthly Self-billing Invoice	52
	Table of contents	2
1	Definitions	3
1.1	Naming conventions	3
1.2	List of definitions	4
2	Application area	20
3	Services	20
3.1	Services on Interconnection Points and Installation Points	20
3.1.1	Entry and Exit Services	20

3.2	Short haul Services	28
3.2.1	Wheelings and OCUC (Operational Capacity Usage Commitments)	28
3.2.2	Zee Platform Service	29
3.3	Cross Border Delivery Service	30
3.4	Quality Conversion Services	31
3.4.1	Quality Conversion Services H → L	31
3.4.2	Quality Conversion Services L → H	32
3.5	ZTP Trading Services	32
3.5.1	Overview on the ZTP Trading Services	32
3.5.2	Imbalance Pooling Service	32
3.5.3	Imbalance Transfer Service	33
3.6	Substitution Services	34
3.6.1	Capacity Conversion Service	34
3.6.2	Reshuffling Service	34
3.6.3	L/H Capacity Switch Service	35
3.8.4	Diversion Service	37
3.7	Ancillary Services	38
3.7.1	Real time data measurement	38
4	Nominations, Metering and Allocations	38
4.1	Overview	38
4.2	Nominations	38
4.3	Metering	38
4.4	Allocations	39
5	Balancing and Allocation settlement	39
5.1	Hourly exchange of information between the TSO and the Balancing Operator	39
5.2	Allocation Settlements	39
5.2.1	Allocation Settlement Grid User Sale	40
5.2.2	Allocation Settlement Grid User Purchase	40
6	Invoicing	40
6.1	General	40
6.2	Monthly Invoice	41
6.2.1	Monthly Capacity Fees	41
6.2.2	Monthly Variable Flex Fee	46
6.2.3	Monthly Zee Platform Fee	47
6.2.4	Monthly Quality Conversion H → L Capacity Fee	47
6.2.5	Monthly Capacity Fee for Quality Conversion L → H	48
6.2.6	Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service	48
6.2.7	Monthly Energy In Cash Fee	49
6.2.8	Monthly Allocation Settlement Fees	49
6.2.9	Monthly Transmission Imbalance Fees	50
6.2.10	Monthly Odorisation Fees	50
6.2.11	Monthly Fix ZTP Trading Services Fee	50
6.2.12	Capacity Exceedings	51
6.2.13	Monthly Administrative Fees	51
6.3	Monthly Self-billing Invoice	52
	Table of contents	2
1	Definitions	3
1.1	Naming conventions	3
1.2	List of definitions	4
2	Application area	19
3	Services	20
3.1	Entry and Exit Services	20
3.1.1	Overview and characteristics of subscribed MTSR of Entry and Exit Services	20
3.1.2	Energy MTSR (EMTSR) and Volume MTSR (VMTSR)	23
3.1.3	Capacity Exceedings	24

3.2	Wheelings and OCUC (Operational Capacity Usage Commitments)	27
3.3	Cross Border Delivery Service	28
3.4	Zee Platform Service	28
3.5	Quality Conversion Services H→L	29
3.6	Quality Conversion Services L→H	30
3.7	ZTP Trading Services	31
3.7.1	Overview on the ZTP Trading Services	31
3.7.2	Imbalance Pooling Service	31
3.7.3	Imbalance Transfer Service	32
3.8	Substitution Services	32
3.8.1	Capacity Conversion Service	32
3.8.2	Reshuffling Service	33
3.8.3	L/H Capacity Switch Service	34
3.8.4	Diversion Service	35
4	Nominations, Metering and Allocations	36
4.1	Overview	36
4.2	Nominations	37
4.3	Metering	37
4.4	Allocations	37
5	Balancing and Allocation settlement	37
5.1	Hourly exchange of information between the TSO and the Balancing Operator	37
5.2	Allocation Settlements	38
5.2.1	Allocation Settlement Grid User Sale	38
5.2.2	Allocation Settlement Grid User Purchase	38
6	Invoicing	39
6.1	General	39
6.2	Monthly Invoice	40
6.2.1	Monthly Capacity Fees	40
6.2.2	Monthly Variable Flex Fee	45
6.2.3	Monthly Zee Platform Fee	46
6.2.4	Monthly Quality Conversion H > L Capacity Fee	46
6.2.5	Monthly Capacity Fee for Quality Conversion L > H	46
6.2.6	Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service	47
6.2.7	Monthly Energy In Cash Fee	47
6.2.8	Monthly Allocation Settlement Fees	48
6.2.9	Monthly Transmission Imbalance Fees	48
6.2.10	Monthly Odorisation Fees	48
6.2.11	Monthly Fix ZTP Trading Services Fee	49
6.2.12	Capacity Exceedings	49
6.2.13	Monthly Administrative Fees	49
6.3	Monthly Self-billing Invoice	50

1 Definitions

Unless the context requires otherwise, the definitions set out in the Attachment 3 of the STA apply to this Attachment A. Capitalized words and expressions used in this Attachment A which are not defined in the Attachment 3 of the STA shall have the following meaning:

1.1 Naming conventions

The variables and parameters used in this Attachment are named according to the following naming conventions, unless indicated otherwise:

- indices to *sum* function (e.g. $\sum_{indice} variable_i$), *max* and *min* functions :
 - d = sum of values per hour of Gas Day d
 - m = sum of values per Gas Day d of Gas Month m
 - $zone$ = sum of values of all ~~Interconnection~~ Connection Points ~~or Domestic Exit Points~~ of the Zone, as specified
 - (all) ~~Grid User~~ Network Users = sum of values for all ~~Grid User~~ Network Users
- indices : h = hourly; d = daily; m = monthly; y = yearly
- indices : f = forecast; r = real (actual)
- index: a = auction
- prefix (tariffs) : T = Regulated Tariff
- prefix : E = Entry; X = Exit
- prefix (nominations, allocations) : E = Energy; V = Volume
- suffix : M = Metering; N = Nomination; A = Allocation
- suffix prime (') = final (allocation) or last (nomination); no quote means provisional (allocation) or initial (nomination)
- suffix m = matched
- suffix $*$ = before settlement; no suffix means after settlement
- indices (exceedings) : p = peak; np = non-peak
- prefix (incentives) : E = Excess or Exceeding; S = Shortfall; I = Incentives
- indices (capacity services): e = Entry; x = Exit, dl = Direct Line
- indices (capacity type): f = Firm; b = Backhaul; i = Interruptible; io = Operational Interruptible
- indices (rate type): y = Yearly; s = Seasonal; st = Short Term; ff = Fix/Flex
- indices (Point): IP = Interconnection Point or Installation Point; XP = ~~Domestic Exit Point~~ Domestic Point, z = Zone
- indices ts = Transmission Service; ct = Capacity Type; rt = Rate Type; ~~rs = Reshuffling Service~~

- indices (market): 1m = Primary Market; 2m = Secondary Market,
- indices (~~Grid-UserNetwork User~~): g = ~~Grid-UserNetwork User~~ (formerly known as grid user),
- indices qcs = Quality Conversion Service; bl = base load; pl = peak load; sl = seasonal load,
- indices (implicit allocation): ia = implicit allocation; h-n = a previous hour in the same Gas Day; shortfall = shortfall transfer service charge; excess = excess transfer service charge

1.2 List of definitions

The following term is defined as:

The variables and parameters used in this Agreement are listed hereunder:

<i>AS_{d,z,g}</i>	Allocation Settlement – daily value per Grid-UserNetwork User per Zone, compensating the difference between allocations based on provisional data and allocations based on final data, expressed in kWh, as provided for in section 5.25.25.2 .
<i>ASGP_{d,z,g}</i>	Allocation Settlement Grid-UserNetwork User Purchase – daily value per Grid-UserNetwork User per Zone, purchase compensating a negative Allocation Settlement (<i>AS_{d,z,g}</i>), expressed in €, as provided for in section 5.25.25.2 .
<i>ASGS_{d,z,g}</i>	Allocation Settlement Grid-UserNetwork User Sale – daily value per Grid-UserNetwork User per Zone, sale compensating a positive Allocation Settlement (<i>AS_{d,z,g}</i>), expressed in €, as provided for in section 5.25.25.2 .
<i>CE_{d,g}</i>	Confirmed Energy – daily value in MWh per Grid-UserNetwork User which is the nominated energy for ZTP Trading Services as provided for in section 6.2.11.2.
<i>CGCV_z</i>	Conversion Gross Calorific Value – fix conversion factor per Zone <i>z</i> , expressed in kWh/m ³ (n) for conversion of a MTSR subscribed in m ³ (h)/h towards kWh/h, which is equal to 11.3 for H calorific gas and to 9.8 for L calorific gas.
<i>D_{dl}</i>	Distance of Direct Line – expressed in km; as provided for in section 6.2.1.36.2.1.36.2.1.36.2.1.3 .
<i>DPRS_{XP}</i>	Dedicated Pressure Reduction Station – value per Domestic-Exit PointDomestic Point ; physical characteristic of a Domestic-Exit PointDomestic Point ; equals 1 if the Domestic-Exit PointDomestic Point is equipped with a DPRS, and 0 otherwise, may be any value between 0 and 1 for Distribution Domestic-Exit

	Point Domestic Points ; as provided for in section 6.2.1.26.2.1.26.2.1.2.
EA'_h	Energy (final) Allocation – hourly value per Grid User <u>Network User</u> and per Connection Point; expressed in kWh; as provided for in section 3.1.33.1.33.1.3.
EEA'_h	Entry Energy (final) Allocation – hourly value per Grid User <u>Network User</u> and per Connection Point; positive value expressed in kWh; as provided for in section 4.44.44.4.
EEA_h	Entry Energy (provisional) Allocation – hourly value per Grid User <u>Network User</u> and per Connection Point; positive value expressed in kWh; as provided for in section 4.44.44.4.
EEE_d	Exceeding of Entry Energy – daily value per Grid User <u>Network User</u> and per Connection Point; expressed in kWh/h; daily maximum of exceeding of entry energy, as provided for in section 3.1.3.13.1.3.1.3.1.
$EEE_{m,np}$	Non-Peak Exceeding of Entry Energy – monthly value per Grid User <u>Network User</u> and per Connection Point; expressed in kWh/h; sum of EEE_d over Month m , less $EEE_{m,p}$, as provided for in section 3.1.3.13.1.3.1.3.1.
$EEE_{m,p}$	Peak Exceeding of Entry Energy – monthly value per Grid User <u>Network User</u> and per Connection Point; expressed in kWh/h; maximum of EEE_d over Month m , as provided for in section 3.1.3.13.1.3.1.3.1.
EEN_h	Entry Energy (initial) Nomination – hourly value per Grid User and per Connection Point; positive value expressed in kWh; nomination received by the TSO before 14:00 hours of Gas Day $d-1$ and accepted by the TSO, as provided for in section 4.2.
EEN'_h	Entry Energy (last) Nomination – hourly value per Grid User <u>Network User</u> and per Connection Point; positive value expressed in kWh; last nomination confirmed <u>accepted</u> by the TSO, as provided for in Attachment B.
EEN'^m_h	Entry Energy (last) Nomination – matched - hourly value per Grid User <u>Network User</u> and per Connection Point; positive value expressed in kWh; last nomination confirmed by the TSO, as provided for in section 3.5.34.2.

<i>EIMTSR_h</i>	Energy Interrupted Maximum Transmission Services Right – hourly value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in kWh; the part of <i>MTSR_i</i> and/or <i>MTSR_{io}</i> and/or <i>MTSR_b</i> that is interrupted at hour <i>h</i> , as provided for in section 3.1.13.1.13.1.1 .
<i>EM'_h</i>	Energy (final) Measurement – hourly value per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in kWh; as provided for in section 4.
<i>EM_h</i>	Energy (provisional) Measurement – hourly value per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in kWh; as provided for in section 4.
<i>EMTSR_d</i>	Energy MTSR – daily value per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in kWh/h; as provided for in section 3.1.23.1.23.1.2 .
<i>EVA'_h</i>	Entry Volume (final) Allocation – hourly value per Grid User <u>Network User</u> and per Interconnection Point <u>or Installation Point</u> ; positive value expressed in m ³ (n); as provided for in section 4.
<i>EVA_h</i>	Entry Volume (provisional) Allocation – hourly value per Grid User <u>Network User</u> and per Interconnection Point <u>or Installation Point</u> ; positive value expressed in m ³ (n); as provided for in section 4.
<i>EVM'_h</i>	Entry Volume (final) Measurement – hourly value per Interconnection Point <u>or Installation Point</u> ; expressed in m ³ (n); as provided for in section 4.
<i>EVM_h</i>	Entry Volume (provisional) Measurement – hourly value per Interconnection Point <u>or Installation Point</u> ; expressed in m ³ (n); as provided for in section 4.
<i>EXE_d</i>	Exceeding of Exit Energy – daily value per Grid User <u>Network User</u> and per Domestic Exit Point <u>or Interconnection Connection Point</u> ; expressed in kWh/h, daily maximum of exceeding of hourly exit energy, as provided for in section 3.1.33.1.33.1.3 .
<i>EXE_{m, np}</i>	Non-Peak Exceeding of Exit Energy – monthly value per Grid User <u>Network User</u> and per Domestic Exit Point <u>or Interconnection Connection Point</u> ; expressed in kWh/h; sum of <i>EXE_d</i> over Month <i>m</i> , less <i>EXE_{m, p}</i> , as provided for in section 3.1.33.1.33.1.3 .

$EXE_{m,p}$	Peak Exceeding of Exit Energy – monthly value per Grid User <u>Network User</u> and per Domestic Exit Point or Interconnection Connection Point; expressed in kWh/h; maximum of EXE_d over Month m , as provided for in section 3.1.33.1.33.1.3 .
GCV'_h	Gross Calorific Value (final) – hourly value per Interconnection Connection Point or Domestic Exit Point ; expressed in kWh/m ³ (n); as provided for in section 3.1.23.1.23.1.2 .
GCV_h	Gross Calorific Value (provisional) – hourly value per Interconnection Connection Point or Domestic Exit Point ; expressed in kWh/m ³ (n); as provided for in section 3.1.23.1.23.1.2 .
GP_d	Gas Price – reference price for Gas Day d – daily value; expressed in €/kWh. Fluxys Belgium will publish on its website – transmission tariff web-page – the currently applicable price reference together with the list of previous used references with their associated validity period. Such applicable price reference can change over time, subject to a notification by Fluxys Belgium to the market with pre-notice period of at least 1 month.
h	Hour – Period of 60 minutes, beginning at a full hour and ending at the next succeeding full hour, and identified by the beginning as herein defined.
$I_{h,z,g}$	Imbalance – hourly value in kWh per Zone and per Grid User <u>Network User</u> ; based on provisional values; as provided for in section 5.1.
$IEEE_{m,np}$	Incentives for Exceeding Entry Energy (non-peak) – monthly value per Grid User <u>Network User</u> and per Interconnection Point <u>or Installation Point</u> ; expressed in €; as provided for in section 3.1.33.1.33.1.3 .
$IEEE_{m,p}$	Incentives for Exceeding Entry Energy (peak) – monthly value per Grid User <u>Network User</u> and per Interconnection Point <u>or Installation Point</u> ; expressed in €; as provided for in section 3.1.33.1.33.1.3 .
$IEXE_{m,np}$	Incentives for Excess of Exit Energy (non-peak) – monthly value per Grid User <u>Network User</u> and per Interconnection Connection

	Point or Domestic Exit Point ; expressed in €; as provided for in section 3.1.33.1.33.1.3 .
$IEXE_{m,p}$	Incentives for Excess of Exit Energy (peak) – monthly value per Grid User <u>Network User</u> and per Interconnection Connection Point or Domestic Exit Point ; expressed in €; as provided for in section 3.1.33.1.33.1.3 .
$IPT_{h,z,g}$	Imbalance Pooling Transfer – hourly value in kWh per Zone and per Grid User <u>Network User</u> ; based on provisional values; as provided for in section 3.5.23.5.23.5.23.7.2 .

Monthly Administrative Fee

Amounts, invoiced to and payable by ~~Grid User~~Network User on a monthly basis based on the performed assignment transactions on the secondary market, cancellations and the subscribed real time data delivery service on the Electronic Data Platform, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Allocation Settlement Fee

Amounts payable by or to ~~Grid User~~Network User on a monthly basis based on the difference between the provisional and final allocations, invoiced with the Monthly Invoice or with the Monthly Self-billing Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Allocation Settlement Purchase Fee

Amounts, invoiced to and payable by ~~Grid User~~Network User on a monthly basis based on the subscribed Transmission Services, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Allocation Settlement Sale Fee

Amounts, invoiced to and payable to ~~Grid User~~Network User on a monthly basis based on the subscribed Transmission Services, invoiced with the Monthly Self-billing Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Capacity Fee for implicitly allocated Transmission Services for Zeebrugge

Amounts, invoiced to and payable by ~~Grid-User~~Network User on a monthly basis based on the implicit allocation of Transmission Services invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Capacity Fee for Quality Conversion H->L

Amounts, invoiced to and payable by ~~Grid-User~~Network User on a monthly basis based on the subscribed Quality Conversion H->L Services, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Capacity Fee for Quality Conversion L->H

Amounts, invoiced to and payable by ~~Grid-User~~Network User on a monthly basis based on the subscribed Quality Conversion H->L Services, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Energy in Cash Fee

Amounts, payable by ~~Grid-User~~Network User on a monthly basis, based on the transmitted quantities, invoiced with the Monthly ~~COM~~ Invoice, in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly DPRS Fee

Component of the Monthly Capacity Fee, invoiced to and payable by ~~Grid-User~~Network User on a monthly basis, based on the Subscribed Transmission Services, invoiced with the Monthly Invoice, in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Fixed Fees for ZTP Trading Services

Amounts, invoiced to and payable by ~~Grid-User~~Network User on a monthly basis based on the subscribed ZTP Trading Services, invoiced with the Monthly Invoice in accordance with the

Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Incentive Fee

Amounts, invoiced to and payable by ~~Grid User~~Network User on a monthly basis, for the Capacity Exceedings and Balancing Incentives, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Odourisation Fee

Amounts, invoiced to and payable by ~~Grid User~~Network User on a monthly basis, for the odourisation of the Natural Gas, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Transmission Imbalance Settlement Fee

Amounts, payable by ~~Grid User~~Network User on a monthly basis based on Transmission Imbalance, invoiced with the Monthly Invoice, in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Variable Fee for Quality Conversion H->L

Amounts, payable by ~~Grid User~~Network User on a monthly basis, based on the converted quantities by the Quality Conversion H->L Service, invoiced with the Monthly ~~COM~~ Invoice, in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

Monthly Variable Fees for ZTP Trading Services

Amounts, invoiced to and payable by ~~Grid User~~Network User on a monthly basis, based on traded/transferred quantities of Gas through ZTP Trading Services, invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs

Monthly Zee Platform Fee

Amounts, invoiced to and payable by ~~Grid User~~Network User on a monthly basis based on the subscribed Zee Platform Services,

invoiced with the Monthly Invoice in accordance with the Standard Transmission Agreement (STA – Attachment 2 – Article 6), section 6 of this Attachment and the Regulated Tariffs.

<i>MP_{XP}</i>	Medium Pressure – value per Domestic Exit Point <u>Domestic Point</u> ; physical characteristic of a Domestic Exit Point <u>Domestic Point</u> ; equals 1 if the Domestic Exit Point <u>Domestic Point</u> is on a MP-grid, and 0 if the Domestic Exit Point <u>Domestic Point</u> is on a HP-grid; may be any value between 0 and 1 for Domestic Exit Point <u>Domestic Point</u> s of type ARS, as provided for in section 6.2.1.26-2.1.26-2.1.2 .
<i>MTSR</i>	Maximum Transmission Services Right – value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in kWh/h; as provided for in section 3.
<i>MTSR_{BB}</i>	Maximum Transmission Services Right Buy-Back – value per Grid User <u>Network User</u> and per Interconnection Point that is bought back through the buy-back procedures from Grid User <u>Network User</u> by TSO; expressed in kWh/h; as provided for in section 3.
<i>MTSR_{1m}</i>	Maximum Transmission Services Right – Primary Market – value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> ; subscribed on the Primary market; expressed in kWh/h.
<i>MTSR_{2m}</i>	Maximum Transmission Services Right – Secondary Market – value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> , traded on the Secondary market, positive value if bought and a negative value if sold; expressed in kWh/h.
<i>MTSR_b</i>	Maximum Transmission Services Right – Backhaul – value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in kWh/h; as provided for in section 3.
<i>MTSR_{cbds}</i>	Maximum Transmission Services Right – Cross Border Delivery Service – value per Grid User <u>Network User</u> and per Interconnection Point <u>or Installation Point</u> ; expressed in kWh/h; as provided in section 3.2.23-2.23.3 .
<i>MTSR_d</i>	Maximum Transmission Services Right – value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> for considered Gas Day <i>d</i> ; expressed in kWh/h; as provided for in section 3.

$MTSR_{d,ct,y,XP,g}$	Maximum Transmission Services Right for Gas Day d for Capacity Type ct , of the Yearly Rate Type y , at Domestic Exit Point Domestic Point XP for Grid User Network User g ; expressed in kWh/h; as provided for in section 3.
$MTSR_{d,ct,s,XP,g}$	Maximum Transmission Services Right for Gas Day d for Capacity Type ct , of the Seasonal Rate Type s , at Domestic Exit Point Domestic Point XP for Grid User Network User g ; expressed in kWh/h; as provided for in section 3.
$MTSR_{d,ct,st,XP,g}$	Maximum Transmission Services Right for Gas Day d for Capacity Type ct , of the Short Term Rate Type st , at Domestic Exit Point Domestic Point XP for Grid User Network User g ; expressed in kWh/h; as provided for in section 3.
$MTSR_{d,ct,ff,XP,g}$	Maximum Transmission Services Right for Gas Day d for Capacity Type ct , of the Fix/Flex Rate Type, at Domestic Exit Point Domestic Point XP for Grid User Network User g ; expressed in kWh/h; as provided for in section 6.
$MTSR_{d,dl,y,XP,g}$	Maximum Transmission Services Right for Gas Day d for Direct Line dl , of the Yearly Rate Type, at Domestic Exit Point Domestic Point XP for Grid User Network User g ; expressed in kWh/h; as provided for in section 6.
$MTSR_{d,dl,s,XP,g}$	Maximum Transmission Services Right for Gas Day d for Direct Line dl , of the Seasonal Rate Type, at Domestic Exit Point Domestic Point XP for Grid User Network User g ; expressed in kWh/h; as provided for in section 6.
$MTSR_{d,ip1,ip2,ocuc,g}$	Maximum Transmission Services Right – OCUC – value per Grid User Network User and for Entry at Interconnection Point 1 and Exit at Interconnection Point 2 for considered Gas Day d ; expressed in kWh/h; as provided for in section 6.2.1.56.2.1.56.2.1.5 .
$MTSR_{d,ip1,ip2,w,g}$	Maximum Transmission Services Right – Wheeling – value per Grid User Network User and for Entry at Interconnection Point 1 and Exit at Interconnection Point 2 for considered Gas Day d ; expressed in kWh/h; as provided for in section 6.2.1.46.2.1.46.2.1.4 .
$MTSR_{d,QCH->L,bl,g}$	Maximum Transmission Services Right – Quality Conversion H->L, for the Quality Conversion Service Base Load bl , value per Grid User Network User for Installation Point “QC” for Gas Day d ; expressed in kWh/h; as provided for in section 6.2.46.2.46.2.4 .

$MTSR_{d,QCH \rightarrow L,pl,ct,g}$	Maximum Transmission Services Right – Quality Conversion H->L, for the Quality Conversion Service Peak Load pl , for Capacity Type ct , value per Grid-User <u>Network User</u> for Installation Point “QC” for Gas Day d ; expressed in kWh/h; as provided for in section 6.2.46.2.46.2.4 .
$MTSR_{d,QCH \rightarrow L,sl,g}$	Maximum Transmission Services Right – Quality Conversion H->L, for the Quality Conversion Service Seasonal Load sl , value per Grid-User <u>Network User</u> for Installation Point “QC” for Gas Day d ; expressed in kWh/h; as provided for in section 6.2.46.2.46.2.4 .
$MTSR_{d,QCL \rightarrow H,g}$	Maximum Transmission Services Right – Quality Conversion L->H – value per Grid-User <u>Network User</u> for Gas Day d ; as provided for in section 6.2.56.2.56.2.5 .
$MTSR_{d,ts,ct,s,IP,g}$	Maximum Transmission Services Right for Gas Day d for Transmission Service ts , of Capacity Type ct , of the Seasonal Rate Type, at Interconnection Point <u>or Installation Point</u> IP for Grid-User <u>Network User</u> g ; expressed in kWh/h; as provided for in section 6.
$MTSR_{d,ts,ct,y,IP,g}$	Maximum Transmission Services Right for Gas Day d for Transmission Service ts , of Capacity Type ct , of the Yearly Rate Type, at Interconnection Point <u>or Installation Point</u> IP for Grid-User <u>Network User</u> g ; expressed in kWh/h; as provided for in section 6.
$MTSR_{DS,f}$	Maximum Transmission Services Right eligible for Diversion Service as provided for in section 3.
$MTSR_e$	Maximum Transmission Services Right – Entry – value per Grid-User <u>Network User</u> and per Interconnection Point <u>or Installation Point</u> ; expressed in kWh/h; as provided for in section 3.1.23.1.23.1.2 .
$MTSR_f$	Maximum Transmission Services Right – Firm – value per Grid-User <u>Network User</u> and per Interconnection-Connection Point <u>or Domestic-Exit Point</u> ; expressed in kWh/h; as provided for in section 3.
$MTSR_{ff}$	Maximum Transmission Services Right – Fix/Flex – value per Grid-User <u>Network User</u> and per Domestic-Exit Point <u>Domestic Point</u> , expressed in kWh/h; as provided for in section 3.13.13.1 .
$MTSR_{h,ts,ct,s,IP,g}$	Maximum Transmission Services Right for Gas Hour h for Transmission Service ts, of Capacity Type ct, of the Seasonal Rate Type, at Interconnection Point or Installation Point IP for

	Grid-User Network User g ; expressed in kWh/h; as provided for in section 6.
$MTSR_{h,ts,ct,y,IP,g}$	Maximum Transmission Services Right for Gas Hour h for Transmission Service ts, of Capacity Type ct, of the Yearly Rate Type, at Interconnection Point or Installation Point IP for Grid-User Network User g ; expressed in kWh/h; as provided for in section 6.
$MTSR_i$	Maximum Transmission Services Right – Interruptible – value per Grid-User Network User and per Interconnection-Connection Point-or-Domestic-Exit-Point ; expressed in kWh/h; as provided for in section 3.
$MTSR_{io}$	Maximum Transmission Services Right – Interruptible Operational – value per Grid-User Network User and per Installation Point; expressed in kWh/h; as provided for in section 3.
$MTSR_{ITS}$	Maximum Transmission Services Right – Imbalance Transfer Service – value per Grid-User Network User; expressed in kWh/h; as provided for in section 3.5.23.5.23.7.2 .
$MTSR_{ITSia}$	Maximum Transmission Services Right – Imbalance Transfer Service Implicit Allocation – value per Grid-User Network User; expressed in kWh/h; as provided for in section 3.5.23.5.23.7.2 .
$MTSR_{LHCS,Y}$	Maximum Transmission Services Right eligible for L/H Capacity switch Service for Gas Year Y as provided for in section 3.6.23.6.23.8.3 .
$MTSR_{ONia}$	Maximum Transmission Services Right – Implicit Allocation through overnomination – value per Network User; expressed in kWh/h; as provided for in Attachment B.
$MTSR_{QCH->L}$	Maximum Transmission Services Right – Quality Conversion H→L – value per Grid-User Network User on Installation Point “QC”, in kWh/h; as provided for in section 3.43.43.5 .
$MTSR_{QCL->H}$	Maximum Transmission Services Right – Quality Conversion L→H – value per Grid-User Network User; expressed in kWh/h; as provided for in section 3.4.23.4.23.6 .
$MTSR_{RS4}$	Maximum Transmission Services Right eligible for Reshuffling Service – 4 years option; as provided for in section 3.8.3.
$MTSR_{RS5}$	Maximum Transmission Services Right eligible for Reshuffling Service – 5 years option; as provided for in section 3.8.3.

$MTSR_s$	Maximum Transmission Services Right – Seasonal – value per Grid User <u>Network User</u> and per Interconnection Connection Point or Domestic Exit Point , expressed in kWh/h; as provided for in section 3.
$MTSR_{st}$	Maximum Transmission Services Right – Short Term – value per Grid User <u>Network User</u> and per Domestic Exit Point <u>Domestic Point</u> , expressed in kWh/h; as provided for in section 3.
$MTSR_x$	Maximum Transmission Services Right – Exit – value per Grid User <u>Network User</u> and per Interconnection Connection Point or Domestic Exit Point ; expressed in kWh/h; as provided for in section 3.
$MTSR_y$	Maximum Transmission Services Right – Yearly – value per Grid User <u>Network User</u> and per Interconnection Connection Point or per Domestic Exit Point ; expressed in kWh/h; as provided for in section 3.
$MTSR_{zpf}$	Maximum Transmission Services Right – Yearly – unlimited MTSR per Grid User <u>Network User</u> to transmit natural gas between Zee Platform Interconnection Points <u>and Installation Point</u> ; on the conditions as set out in section <u>1.13.2.23.2-23.4</u> .
$MVFF_{g,XP,y,m}$	Monthly Variable Flex Fee – monthly value per Grid User <u>Network User</u> g per Domestic Exit Point <u>Domestic Point</u> XP , for the calendar year y and for the month m ; expressed in €; as provided for in section <u>6.2.26.2-26.2.2</u> .
$NCTT_{h,g,z}$	Net Confirmed Title Transfers – provisional – hourly value per Zone per Grid User <u>Network User</u> , expressed in kWh, positive values indicate net purchases, negative values indicate net sales, as described in ACT – Attachment C1.
$NCTT'_{h,g,z}$	Net Confirmed Title Transfers – final – hourly value per Zone and per Grid User <u>Network User</u> , expressed in kWh, positive values indicate net purchases, negative values indicate net sales, as described in ACT – Attachment C1.
$NCTTP_{h,g,z}$	Net Confirmed Title Transfers for ZTP Physical Trading Services being the net values transferred to or from the Grid User <u>Network User</u> Balancing Position via Zeebrugge in order to have balanced ZTP Physical Trading Services – provisional – hourly value per Zone per Grid User <u>Network User</u> , expressed in kWh, positive values indicate net purchases, negative values indicate net sales, as described in ACT – Attachment C1.
$NCTTP'_{h,g,z}$	Net Confirmed Title Transfers for ZTP Physical Trading Services being the net values transferred to or from the Grid User <u>Network</u>

	<p><u>User</u> Balancing Position via Zeebrugge in order to have balanced ZTP Physical Trading Services – final – hourly value per Zone and per Grid-UserNetwork <u>User</u>, expressed in kWh, positive values indicate net purchases, negative values indicate net sales, as described in ACT – Attachment C1.</p>
$NCTTN_{h,g,z}$	<p>Net Confirmed Title Transfers for ZTP Notional Trading Services being the net values transferred to or from the Grid-UserNetwork <u>User</u> Balancing Position via ZTP or ZTPL in order to have balanced ZTP Notional Trading Services – provisional – hourly value per Zone per Grid-UserNetwork <u>User</u>, expressed in kWh, positive values indicate net purchases, negative values indicate net sales, as described in ACT – Attachment C1.</p>
$NCTTN'_{h,g,z}$	<p>Net Confirmed Title Transfers for ZTP Notional Trading Services being the net values transferred to or from the Grid-UserNetwork <u>User</u> Balancing Position via ZTP or ZTPL in order to have balanced ZTP Notional Trading Services – final – hourly value per Zone and per Grid-UserNetwork <u>User</u>, expressed in kWh, positive values indicate net purchases, negative values indicate net sales, as described in ACT – Attachment C1.</p>
$N_{h,y}$	<p>Number of Hours within the considered calendar year, as provided in section 6.</p>
$NEA'_{h,IP,g}$	<p>Netted off Energy Allocation – final – hourly value per a Grid User g per Interconnection Point IP which is the result of: $EAA'_{h,IP,g} + XEA'_{h,IP,g}$ as provided for in section 1.1.</p>
$NEN^m_{h,IP,g}$	<p>Netted off Energy Nomination – matched – hourly value per Grid User g per Interconnection Point IP which is the result of: $EEN^m_{h,IP,g} + XEN^m_{h,IP,g}$ as provided for in section 1.1.</p>
N_m	<p>Number of Days within the considered calendar month, as provided in section 6.</p>
N_y	<p>Number of Days within the considered calendar year, as provided in section 6.</p>
NYM	<p>Non-Yearly Multiplier – factor applied for non-yearly capacity, as defined in the Regulated Tariffs, and as provided for in section 6.</p>
ODO_{XP}	<p>Odorisation – value per Domestic-Exit-Point <u>Domestic Point</u>; physical characteristic of a Domestic-Exit-Point <u>Domestic Point</u>; equals 1 if the Domestic-Exit-Point <u>Domestic Point</u> is odorised, and 0 otherwise, may be any value between 0 and 1 for</p>

	Distribution Domestic Exit Point <u>Domestic Points</u> , as provided for in section 6.2.106.2.106.2.10 .
$OF_{m,IPorXP,g}$	Occurrence Factor – monthly value per Grid User <u>Network User</u> and per Interconnection Connection Point or Domestic Exit Point ; one increased by the number of Months of the preceding 12 Months during which capacity exceedings have taken place for Grid User <u>Network User</u> for the concerned Interconnection Connected Point or Domestic Exit Point , as provided for in section 3.1.33.1.33.1.3 .
$P_{BB,g}$	Price for buy back paid by the TSO – daily; expressed in €/kWh/h/d as provided for in section 6.2.16.2.16.2.1 .
$P_{LH,Y}$	Percentage of L-gas Entry Service that can be transferred for Gas Year Y under the L/H Capacity Switch Service as set out in section 3.6.23.6.23.8.3 . This percentage is defined based on the physical conversion planning as published by Synergrid once a year.
RPS_{XP}	Reduced Pressure Service – value per Domestic Point; physical characteristic of a Domestic Point; equals 1 if the Domestic Point is equipped with a RPS, and 0 otherwise, may be any value between 0 and 1 for Distribution Domestic Points; as provided for in section 6.2.1.2¹.
$RH_{g,XP,y,n}$	Running hours – monthly value based on final allocations, corresponding to the equivalent number of hours that the MTSR of Grid User <u>Network User</u> g on Domestic Exit Point <u>Domestic Point</u> XP was used under full load in year y up to and including month n – expressed in hours, as provided for in section 6.2.26.2.26.2.2 .
$RH-TRH$	Running hours threshold – value provided in the Regulated Tariffs, expressed in number of hours and which represent the threshold of $RH_{g,XP,y,n}$ at which the applicable tariff changes from $T_{flex,ff,XP,1}$ to $T_{flex,ff,XP,2}$
RPS_{XP}	Reduced Pressure Service - value per Domestic Point; physical characteristic of a Domestic Point; equals 1 if the Domestic Point is equipped with a RPS, and 0 otherwise, may be any value

between 0 and 1 for Distribution Domestic Points; as provided for in section 6.2.1.26.2.1.26.2.1.2².

SC_m	Seasonal Coefficient – monthly value; factor defining the seasonal capacity tariff versus the yearly capacity tariff, as defined in the Regulated Tariffs, as provided for in section <u>6.16.16.1</u> .
STM	Short Term Multiplier – factor defining the Short Term capacity tariff versus the Seasonal capacity tariff, as defined in the Regulated Tariffs; as provided for in section 6.
$T_{ct,HP,XP}$	Tariff for HP Supply of Capacity Type ct at Domestic Exit Point <u>Domestic Point</u> XP – Regulated Tariff; expressed in € / kWh/h / year, as provided for in section 6.
$T_{ct,MP,XP}$	Tariff for MP Supply of Capacity Type ct at Domestic Exit Point <u>Domestic Point</u> XP – Regulated Tariff; expressed in € / kWh/h / year, as provided for in section 6.
<u>$T_{ct,RPS,XP}$</u>	<u>Tariff for RPS Supply of Capacity Type ct at Domestic Point XP – Regulated Tariff; expressed in € / kWh/h / year, as provided for in section 6³.</u>
$T_{dt,ct}$	Tariff for Direct Line of Capacity Type ct – Regulated Tariff; expressed in € / kWh/h / year, as provided for in section 6.
$T_{dt,d}$	Tariff for Direct Line based on Distance D_{dl} – Regulated Tariff; expressed in € / kWh/h / km / year, as provided for in section 6.
T_{DPRS}	Tariff for DPRS – Yearly – Regulated Tariff; expressed in € / kWh/h/year; as provided for in section <u>6.2.1.26.2.1.26.2.1.2</u> .
T_{EIC}	Tariff for Energy In Cash – Regulated Tariff; factor of applicable on the total allocated energy of a Grid User <u>Network User</u> on an

² From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the Reduced Pressure Service. This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits. Hence from that date MP_{XP} and $DPRS_{XP}$ coefficients will be replaced by RPS_{XP} and accordingly the $T_{ct,RPS,XP}$ will be applied.

³ From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the Reduced Pressure Service. This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits. Hence from that date MP_{XP} and $DPRS_{XP}$ coefficients will be replaced by RPS_{XP} and accordingly the $T_{ct,RPS,XP}$ will be applied.

	Interconnection-Connection Point or a Domestic Exit Point , used in the invoicing of the energy in cash, as provided for in section 6.
T_{FixZTP}	Fixed tariff for ZTP Trading Services - Regulated Tariff; expressed in €/Month, as provided for in section 6.
$T_{fix,ff,XP}$	Fix tariff – Fix/Flex – fixed tariff applicable on Transmission-Exit Services towards End Users <u>Domestic Points</u> of the Fix/Flex Rate Type <u>ff.</u> —Regulated Tariff; as provided for in 6.2.1.26.2.1.26.2.1.2.
$T_{flex,ff,XP,1}$	Flex tariff – Fix/Flex – variable tariff-term applicable on Transmission-Exit Services towards End User Domestic-Exit Point <u>Domestic Points XP with-of the Rate Type</u> Fix/Flex <u>ff.</u> <u>Rate Type ff.</u> applicable until $RH_{g,XP,y,n} \leq RH-TRH$ – Regulated Tariff; expressed in € / MWh, as provided for in 6.2.26.2.26.2.2.
$T_{flex,ff,XP,2}$	Flex tariff – Fix/Flex – variable tariff-term applicable on Transmission-Exit Services towards End User Domestic-Exit Point <u>Domestic Points XP with-of the Rate Type</u> Fix/Flex <u>Rate Type ff.</u> applicable as from $RH_{g,XP,y,n} > RH-TRH$ – Regulated Tariff; expressed in € / MWh, as provided for in 6.2.26.2.26.2.2.
$T_{IP1,IP2,OCUC}$	Tariff for OCUC from Interconnection Point $IP1$ to Interconnection Point $IP2$ – Yearly – Regulated Tariff; expressed in €/(kWh/h)/year; as provided for in section 6.
$T_{IP1,IP2,w}$	Tariff for Wheeling from Interconnection Point $IP1$ to Interconnection Point $IP2$ – Yearly – Regulated Tariff; expressed in €/(kWh/h)/year; as provided for in section 6.
T_{ITS}	Tariff for the implicit allocation of Transmission Services at the Zeebrugge Interconnection Point for the Imbalance Transfer Service – Regulated Tariff; expressed in €/(kWh/h)/year, as defined in the Regulated Tariffs, as provided for in section 6.2.6.
	T_{mse}—Tariff for multi-shipper codes—Regulated Tariff; expressed in € / Additional Nomination Code / year; as provided for in section 6.
T_{ODO}	Tariff for Odorisation – variable term – Regulated Tariff; expressed in €/MWh; as provided for in section 6.2.106.2.106.2.10.
$T_{QCH->L,bl}$	Tariff for Quality Conversion H->L, for Quality Conversion Service Base Load bl – Regulated Tariff; expressed in €/kWh/h/year, as provided for in section 6.

$T_{QCH->L,pl}$	Tariff for Quality Conversion H->L, for Quality Conversion Service Peak Load pl – Regulated Tariff; expressed in €/kWh/h/year, as provided for in section 6.
$T_{QCH->L,sl}$	Tariff for Quality Conversion H->L, for Quality Conversion Service Seasonal Load sl – Regulated Tariff; expressed in €/kWh/h/year, as provided for in section 6.
$T_{QCL->H}$	Tariff for Quality Conversion L->H – Regulated Tariff; expressed in € / kWh/h / year, as provided for in section 6.
$T_{ts,ct,IP}$	Tariff for Transmission Service ts of Capacity Type ct at Interconnection Point <u>or Installation Point</u> IP – Regulated Tariff; expressed in € / kWh/h / year, as provided for in section 6.
T_{VarZTP}	Variable tariff for ZTP Trading Services - Regulated Tariff; expressed in €/MWh, as provided for in section 6.
$T_{var,qcH->L,pl}$	Variable tariff for Quality Conversion H->L, applicable on the Quality Conversion Service Peak Load pl – Regulated Tariff; expressed in € / MWh, as provided for in section 6.
$TI'_{h,g}$	Transmission Imbalance – validated – hourly value per Grid User <u>Network User</u> based on final allocations for Wheeling Services, Zee Platform Services, Services submitted to an Operational Capacity Usage Commitment or Direct Line Services; expressed in kWh; as provided for in section 6.2.96.2.96.2.9 .
$TVFF_{g,XP,y,n}$	Total Variable Flex Fee – Total Variable Flex Fee in year y up to and including month n , total monthly value per Grid User <u>Network User</u> and per Domestic Exit Point <u>Domestic Point</u> XP ; expressed in €; as provided for in section 6.2.26.2.26.2.2 .
$TXEA_{h,z,g}$	Total Exit Energy Allocations – hourly value per Zone, per Grid User <u>Network User</u> , expressed in kWh, as provided for in Attachment C section 5.1.4.
VM'_h	Volume (final) Measurement – hourly value per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in m ³ (n); as provided for in section 4.
VM_h	Volume (provisional) Measurement – hourly value per Interconnection Connection Point <u>or Domestic Exit Point</u> ; expressed in m ³ (n); as provided for in section 4.

$VMTSR_d$	Volume MTSR – daily value per Interconnection-Connection Point-or Domestic-Exit Point ; expressed in $m^3(n)/h$; as provided for in section 3.1.2.
$VIMTSR_h$	Volume Interrupted Maximum Transmission Services Right – hourly value per Grid User/Network User and per Interconnection-Connection Point-or Domestic-Exit Point ; expressed in $m^3(n)/h$; the part of $MTSR_i$ and/or $MTSR_{i1}$ and/or $MTSR_{iN}$ and/or $MTSR_{io}$ and/or $MTSR_b$ that is interrupted at hour h , as provided for in section 3.1.2.
XEA'_h	Exit Energy (final) Allocation – hourly value per Grid User/Network User and per Interconnection-Connection Point-or Domestic-Exit Point ; negative value expressed in kWh; as provided for in section 4.
XEA_h	Exit Energy (provisional) Allocation – hourly value per Grid User/Network User and per Interconnection-Connection Point-or Domestic-Exit Point ; negative value expressed in kWh; as provided for in section 4.
XEN_h	Exit Energy (initial) Nomination – hourly value per Grid User and per Interconnection Point or Domestic Exit Point/Domestic Point; negative value expressed in kWh; nomination received by the TSO before 14:00 hours of Day $d-1$ and accepted by the TSO, as provided for in section 4.
XEN'_h	Exit Energy (last) Nomination – hourly value per Grid User/Network User and per Interconnection-Connection Point-or Domestic-Exit Point ; negative value expressed in kWh; last nomination confirmed-accepted by the TSO, as provided for in Attachment B section 4.
XEN^m_h	Exit Energy (initial) Nomination – matched – hourly value per Grid User and per Interconnection Point or Domestic Exit Point/Domestic Point; negative value expressed in kWh; nomination received by the TSO before 14:00 hours of Day $d-1$ and accepted by the TSO, as provided for in section 4.
XEN^m_h	Exit Energy (last) Nomination – matched - hourly value per Grid User/Network User and per Interconnection-Connection Point-or Domestic-Exit Point ; negative value expressed in kWh; last nomination confirmed by the TSO, as provided for in section 3.5.34 .
XVA'_h	Exit Volume (final) Allocation – hourly value per Grid User/Network User and per Interconnection-Connection Point-or

	Domestic Exit Point ;	negative value expressed in m ³ (n); as provided for in section 4.
	XVA_h	Exit Volume (provisional) Allocation – hourly value per Grid User <u>Network User</u> and per Interconnection Connection Point <u>or Domestic Exit Point</u> ; negative value expressed in m ³ (n); as provided for in section 4.
	$ZPF_{d,g}$	Number of Zee Platform Interconnection Points <u>or Installation Point</u> (minimum 2 points) for which Grid User <u>Network User</u> has Zee Platform Services for Gas Day d , as provided for in section 1.13.2.23-2.23.4 .

2 Application area

Fluxys Belgium and the TSO from Luxembourg, Creos Luxembourg, completed the integration of their respective H market zones on 1 October 2015. The resulting BeLux area consists of an entry/exit system with a Virtual Trading Point “Zeebrugge Trading Point” or “ZTP”. ~~Grid user~~Network Users don’t have to subscribe to capacity services to transport gas between Belgium and Luxembourg (and vice versa). This Access Code for Transmission is applicable for services offered by Fluxys Belgium on the Belgian territory.

3 Services

[3.1.13.1](#) Entry and Exit Services

[3.1.13.1.1](#) *Overview and characteristics of subscribed MTSR of Entry and Exit Services*

The Transmission Grid consists of two Zones (one for H-calorific Natural Gas and one for L-calorific Natural Gas), of Interconnection Points, Installation Points and Domestic Exit Points for each Zone. Each Interconnection Point, Installation Point and Domestic Exit Point is located in one Zone⁴.

Each Transmission Service is characterized by respectively a location (Interconnection Point, Installation Point or Domestic PointExit), by a Capacity Type, a Rate Type and a Service Duration (with a start date and an end date).

The following Entry and Exit Services exist:

⁴ Except for the ~~Interconnection-Installation~~ Point “Quality Conversion” which is located both in the H Zone and the L Zone.

- An Entry Transmission Service ($MTSR_e$) enables a ~~Grid-User~~Network User to inject a quantity of Natural Gas at an Interconnection Point, Installation Point or a Domestic Point⁵ into a Zone.
- An Exit Transmission Service ($MTSR_x$) enables a ~~Grid-User~~Network User to withdraw a quantity of Natural Gas from a Zone, at an Interconnection Point, Installation Point or a ~~Domestic Exit Point~~Domestic Point.

The following Capacity Types exist for Transmission Services:

- Firm Transmission Services ($MTSR_f$) are, subject to the terms and conditions of the Standard Transmission Agreement, always available and usable under normal operating conditions.
- Interruptible capacity ($MTSR_i$, $MTSR_{io}$) can be interrupted by the TSO, following the rules described in ACT – Attachment C1.
- Backhaul capacity ($MTSR_b$) ~~is~~can be offered at ~~an~~uni-directional ~~Interconnection-Connection~~ Points, in the opposite direction of the physical gas flow direction and is available as long as the resulting physical flow remains in the physical direction of the ~~Interconnection-Connection~~ Point.

In the following tables, an overview is set out with the Capacity Types on offer for the different Point:

⁵ For the Domestic Entry Service the TSO reserves the right to change the start-date of the service (or to put indefinitely this start-date on-hold) and/or to subject the access to the service to financial, technical and/or quality requirements to ensure coverage of the costs linked to the service, safeguard the system integrity of the Transmission system and compliance with applicable laws and regulations. The indicative start-date is 1 January 2020.

Interconnection Points <u>and Installation Points</u>	Zone	Entry Transmission Services			Exit Transmission Services		
		Firm	Backhaul	Interruptible	Firm	Backhaul	Interruptible
Blaregnies L	L		X		X		O
Eynatten 1	H	X		O	X		O
Eynatten 2	H	X		O	X		O
IZT	H	X		O	X		O
Hilvarenbeek L	L	X		O		X	
's Gravenvoeren	H	X		O		X	
Virtualys_(1)	H	X		O	X		O
Zandvliet H	H	X		O		X	
Zeebrugge	H	X		O	X		O
Zelzate 1	H	X		O	X		O
Zelzate 2	H		X		X		O
ZPT	H	X		O		X	
Loenhout	H	X		X*	X		X*
Zeebrugge LNG Terminal	H	X		X*		X	
Dunkirk LNG Terminal	H	X					

- X = Service is offered and can be contracted within indicative availabilities as published on the Fluxys Belgium website
- X* = Operational Interruptible capacity that corresponds to capacities that Fluxys Belgium has secured for the operation of the Transmission Grid and that are made available to ~~Grid~~ User/Network Users on an Interruptible basis.
- O = Service is optionally offered, depending on Firm availability
- (1) = According to the regulations set out in NC CAM Art 19.9, the name of the Interconnection Points Alveringem, Blaregnies Segeo and Blaregnies Troll are aligned with the name of the “virtual” Interconnection Point Virtualys. Any reference in a Service Confirmation to Alveringem, Blaregnies Segeo and Blaregnies Troll will then is considered as a reference to the new Interconnection Point Virtualys.

Former IP (name)	New IP (name) “virtual”
- Blaregnies Segeo	- Virtualys
- Blaregnies Troll	- Virtualys
- Alveringem	- Virtualys

The Quality Conversion Service H→L consists of the possibility to have Natural Gas transmitted from the H Zone to the L zone, at the Installation Point “QC”. The Capacity Type can be Firm or Interruptible. The Quality Conversion Service L→H consists of the possibility to inject Natural Gas into the H Zone. The Capacity Type is Interruptible.

<u>Domestic Points</u>	Zone	<u>Entry Transmission Services</u>			<u>Exit Transmission Services</u>		
		<u>Firm</u>	<u>Back haul</u>	<u>Interruptible</u>	<u>Firm</u>	<u>Back haul</u>	<u>Interruptible</u>
End User Domestic Exit Point <u>Domestic Point</u>	H of L	X	-	-	X	-	O
Distribution Domestic Exit Point <u>Domestic Point</u>	H of L	-	X	-	X	-	-

The following Rate Types exists for Transmission Services:

- Yearly Transmission Services ($MTSR_y$);
- Seasonal Transmission Services ($MTSR_s$);
- Short Term Transmission Services ($MTSR_{st}$);
- Fix/Flex Transmission Services ($MTSR_{ff}$).

These Rate Types are attributed based on the characteristics of the Transmission Service (Entry or Exit, location and Service Period), as set out in the Access Code (ACT - Attachment B). For the sake of completeness of this Attachment, these are summarized in the following table:

Capacity Transmission Services	Service Period	Rate Type	MTSR
Entry Transmission Services <u>on Interconnection Points and Installation Points</u>	= 1 year or multiple of 12 calendar months ^(*)	Yearly	$MTSR_{d,e,ct,y,IP}$
	1 month ^(*) >= x < 1 year	Seasonal	$MTSR_{d,e,ct,s,IP}$
	< 1 month ^(*)		
Exit Transmission Services <u>on Interconnection Points and Installation Points</u>	All Service Periods ^(*)	Yearly	$MTSR_{d,x,ct,y,IP}$
Exit Transmission Services <u>on End User Domestic Exit Point Domestic Points</u>	= 1 year or multiple of 12 calendar months	Yearly	$MTSR_{d,x,ct,y,XP}$
		Fix/Flex ^(**)	$MTSR_{d,x,ct,ff,XP}$
	1 month ^(***) >= x < 1 year	Seasonal	$MTSR_{d,x,ct,s,XP}$
	< 1 month	Short Term	$MTSR_{d,x,ct,st,XP}$

Exit Transmission Services on Distribution Domestic Exit Point Domestic Points	All Service Periods	Yearly	$MTSR_{d,x,ct,y,XP}$
Entry Transmission Services on End User Domestic Points	<u>year</u>	Yearly	$MTSR_{d,e,ct,y,XP}$
Entry Transmission Services on Distribution Domestic Points	<u>year</u>	Yearly	$MTSR_{d,e,ct,y,XP}$

- ~~(*) The Service Periods for Transmission Services on Interconnection Points and Installation Points subscribed through PRISMA or EBS are defined by default as annual, quarterly, monthly, daily and within day (as are described in ACT Attachment B).~~
- ~~(**) As described in ACT Attachment B, the Fix/Flex Rate Type can only be attributed for capacity subscriptions of 12 consecutive months from 1 January until and including 31 December of the same year.~~
- ~~(***) The Service Period of Transmission Services with start date 14/mm/yy and 13/mm+1/yy as end date are considered as 1 calendar month.~~
- ~~Note that for capacities allocated by the TSO (through implicit allocation) for Loenhout or for Distribution Domestic Exit Point Domestic Points, the Rate Type is always Yearly and for Zeebrugge, the Rate Type is always Seasonal.~~

~~Exit Transmission Services on Distribution Domestic Exit Point Domestic Points At Domestic Exit Point Domestic Points, the Transmission Services~~ always include the high pressure (HP) Exit Service and may include the services of medium pressure (MP), Dedicated Pressure Reduction Station (DPRS) and odourisation (ODO).

- Via the medium pressure service, Fluxys Belgium transports the gas to a ~~Domestic Exit Point Domestic Point~~ via a medium pressure network³.
- Via the Dedicated Pressure Reduction Station service, Fluxys Belgium reduces the pressure at a ~~Domestic Exit Point Domestic Point~~ within the contractual minimum and maximum pressure limits⁶.
- Odourisation consists in Fluxys Belgium injecting an odourant in gas at ~~Domestic Exit Point Domestic Points~~ where an odourisation facility is operated by Fluxys Belgium.

⁶ From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the Reduced Pressure Service (RPS). This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits. Hence from that date MP_{XP} and $DPRS_{XP}$ coefficients will be replaced by RPS_{XP} and accordingly the $T_{ct,RPS,XP}$ will be applied.

The subscription of Exit Capacity at ~~Domestic-Exit-Point~~Domestic Points ($MTSR_{d,x,ct,y,XP}$) implies the delivery (and the payment, according to section 6) of these services in function of the respective coefficients MP_{XP} , $DPRS_{XP}$, and ODO_{XP} . These coefficients are set per End User ~~Domestic-Exit-Point~~Domestic Point or per Aggregated Receiving Station (ARS) for Distribution ~~Domestic-Exit-Point~~Domestic Points, have a value between 0 and 1 and are published on Fluxys Belgium's website⁷.

For two specific cases of End Users located in Belgium near a border and directly connected to the Transmission Grid of an Adjacent TSO or to the grid of a foreign Distribution Network Operator (currently: from Veldwezelt to Steenfabriek Wienerberger and from Momignies to Gerresheimer Momignies), Direct Line MTSR ($MTSR_{dl}$) is offered instead of Entry and Exit MTSR.

3.1.1.23.1.2 **Energy MTSR (EMTSR) and Volume MTSR (VMTSR)**

MTSR is always expressed in energy (kWh/h). For existing capacities that were subscribed in volume [$m^3(n)/h$], Grid-User~~Network User~~ has the possibility to either convert these capacities to energy [kWh/h], either keep this capacity in volume.

MTSR that was subscribed in volume and is not converted to energy by Grid-User~~Network User~~ is referred to as Volume MTSR ($VMTSR$).

MTSR that is subscribed in volume but converted to energy or, that is either subscribed or implicitly allocated in energy is referred to as Energy MTSR ($EMTSR$).

At a considered ~~Intereconnection-Connection~~ Point ~~or Domestic-Exit-Point~~, the MTSR of a Grid-User~~Network User~~ is calculated by multiplying the Volume MTSR ($VMTSR_d$) by the conversion GCV of the Zone z at which the ~~Intereconnection-Connection~~ Point ~~or Domestic-Exit-Point~~ is located ($CGCV_z$), by adding the Energy MTSR ($EMTSR_d$) and for Interconnection Points by subtracting the MTSR bought back through the buy-back procedure ($MTSRBB_d$).

$$MTSR_d = EMTSR_d + (VMTSR_d \times CGCV_z) - MTSRBB_d$$

The $MTSR_f$ bought back through the buy-back procedure ($MTSRBB_{d,IP,g}$) for Day d , for Interconnection Point IP , for a Grid-User~~Network User~~ g is calculated as the maximum of $MTSR_{h,f}$ bought back during the specific gasdayGas Day.

$$MTSRBB_{d,IP,g} = \max_d (MTSRBB_{h,IP,g})$$

⁷ <http://www.fluxys.com/belgium/en/Services/Transmission/TransmissionTariffs/TransmissionTariffs>

3.1.1.3.1.3 Capacity Exceedings

3.1.1.3.1.3.1 Entry Capacity Exceedings at an Interconnection Point and Installation Points

For ~~Grid User~~Network Users having subscribed Entry Transmission Services in Volume ($VMTSR_d$) at an Interconnection Point or Installation Point, Capacity Exceedings can apply, based on the measured GCV and the Energy Allocations.

The daily Entry Energy Exceeding ($EEE_{d,IP,g}$) for such ~~Grid User~~Network User g expressed in kWh/h for Gas Day d , is the highest excess, for that Gas Day d , of the final Entry Energy Allocation (EEA'_h) with respect to Transmission Services in Volume which are not switched to energy ($VMTSR_d$) and also considering the Transmission Services of ~~Grid User~~Network User that are in energy ($EMTSR_d$)⁸, the Volume Interrupted MTSR ($VIMTSR_h$), the Energy Interrupted MTSR ($EIMTSR_h$) and the MTSR bought back through the buy-back procedure ($MTSRBB_h$) on the considered Interconnection Point or Installation Point IP ⁹.

$$EEE_{d,IP,g} = \max_d \left[\max \left(0; EEA'_{h,IP,g} - EMTSR_{d,e,IP,g} + EIMTSR_{h,e,IP,g} - (VMTSR_{d,e,IP,g} - VIMTSR_{h,e,IP,g}) \times GCV'_{h,IP,g} + MTSRBB_{h,e,IP,g} \right) \right]$$

The Peak Exceeding of Entry Energy for ~~Grid User~~Network User g ($EEE_{m,p,IP,g}$) for Month m is equal to the highest daily Entry Energy Exceeding over Month m on the considered Interconnection Point or Installation Point IP :

$$EEE_{m,p,IP,g} = \max_m EEE_{d,IP,g}$$

The Non-Peak Exceeding of Entry Energy for ~~Grid User~~Network User g ($EEE_{m,np,IP,g}$) for Month m is equal to the sum of all daily Entry Energy Exceedings of ~~Grid User~~Network User g for the considered Transmission Service less the Peak Exceeding of Entry Energy of ~~Grid User~~Network User g on the considered Interconnection Point or Installation Point IP :

$$EEE_{m,np,IP,g} = \sum_m EEE_{d,IP,g} - EEE_{m,p,IP,g}$$

The Peak Incentive for Exceeding Entry Energy for a ~~Grid User~~Network User g , for Month m , for Interconnection Point or Installation Point IP is calculated as follows:

⁸ In case of Within-day auctions, the EMTSR can vary on an hourly basis.

⁹ In case Grid User has Wheeling Services from the considered Interconnection Point to another Interconnection Point and/or Entry Services at the considered Interconnection Point on which an OCUC applies, $EEA'_{h,IP,g}$ will also include allocations for Grid User for wheeling and OCUC and $EMTSR_{d,e,IP,g}$ and $VMTSR_{d,e,IP,g}$ will include Wheeling Services and Entry Services on which an OCUC applies. In case of interruption of Wheeling or OCUC, $IMTSR_{h,e,IP,g}$ will include this interruption.

$$IEEE_{m,p,IP,g} = EEE_{m,p,IP,g} \times T_{e,f,y,IP} \times \min \left[\frac{1.5 \times OF_{m,IP,g}}{12}; 1 \right]$$

The Non-Peak Incentive for Exceeding Entry Energy for a ~~Grid User~~ Network User g , for Month m , for Interconnection Point or Installation Point IP is calculated as follows:

$$IEEE_{m,np,IP,g} = \min \left[\frac{EEE_{m,np,IP,g} \times T_{e,f,y,IP}}{6} \times \min \left[\frac{1.5 \times OF_{m,IP,g}}{12}; 1 \right]; IEE_{m,p,IP,g} \right]$$

3.1.1.3.23.1.3.2 Exit Capacity Exceedings at an Interconnection Point and Installation Point

For ~~Grid User~~ Network Users having subscribed Exit Transmission Services in Volume ($VMTSR_d$) at an Interconnection Point or Installation Point, Capacity Exceedings can apply, based on the measured GCV and the Energy Allocations.

The daily Exit Energy Exceeding ($EXE_{d,IP,g}$) for such ~~Grid User~~ Network User g expressed in kWh/h for Gas Day d , is the highest excess, for that Gas Day d , of the final Exit Energy Allocation (XEA'_h) with respect to Transmission Services in Volume which are not switched to energy ($VMTSR_d$) and also considering the Transmission Services of ~~Grid User~~ Network User that were switched to energy ($EMTSR_d$)¹⁰, the Volume Interrupted MTSR ($VIMTSR_h$), the Energy Interrupted MTSR ($EIMTSR_h$) and the MTSR bought back through the buy-back procedure ($MTSRBB_h$) on the considered Interconnection Point or Installation Point IP ¹¹.

$$EXE_{d,IP,g} = \max \left[0; -XEA'_{h,IP,g} - EMTSR_{d,x,IP,g} + EIMTSR_{h,x,IP,g} - (VMTSR_{d,x,IP,g} - VIMTSR_{h,x,IP,g}) \times GCV_{h,IP,g} + MTSRBB_{h,e,IP,g} \right]$$

The Peak Exceeding of Exit Energy for ~~Grid User~~ Network User g ($EXE_{m,p,IP,g}$) for Month m is equal to the highest daily Exit Energy Exceeding over Month m on the considered Interconnection Point or Installation Point IP :

$$EXE_{m,p,IP,g} = \max_m EXE_{d,IP,g}$$

The Non-Peak Exceeding of Exit Energy for ~~Grid User~~ Network User g ($EXE_{m,np,IP,g}$) for Month m is equal to the sum of all daily Exit Energy Exceedings of ~~Grid User~~ Network User g for the considered Transmission Service less the Peak Exceeding

¹⁰ In case of Within-day auctions, the EMTSR can vary on an hourly basis.

¹¹ In case Grid User has Wheeling Services from another Interconnection Point to the considered Interconnection Point and/or Exit Services at the considered Interconnection Point on which an OCUC applies, $XEA'_{h,IP,g}$ will also include allocations for Grid User for wheeling and OCUC and $EMTSR_{d,x,IP,g}$ and $VMTSR_{d,x,IP,g}$ will include Wheeling Services and Exit Services on which an OCUC applies. In case of interruption of Wheeling or OCUC, $IMTSR_{h,x,IP,g}$ will include this interruption.

of Exit Energy of ~~Grid User~~Network User g on the considered Interconnection Point or Installation Point IP :

$$EXE_{m,np,IP,g} = \sum_m EXE_{d,IP,g} - EXE_{m,p,IP,g}$$

The Peak Incentive for Exceeding Exit Energy for a ~~Grid User~~Network User g , for Month m , for Interconnection Point or Installation Point IP is calculated as follows:

$$IEXE_{m,p,IP,g} = EXE_{m,p,IP,g} \times T_{x,f,y,IP} \times \min \left[\frac{1.5 \times OF_{m,IP,g}}{12}; 1 \right]$$

The Non-Peak Incentive for Exceeding Exit Energy for a ~~Grid User~~Network User g , for Month m , for Interconnection Point or Installation Point IP is calculated as follows:

$$IEXE_{m,np,IP,g} = \min \left[\frac{EXE_{m,np,IP,g} \times T_{x,f,y,IP}}{6} \times \min \left[\frac{1.5 \times OF_{m,IP,g}}{12}; 1 \right]; IEXE_{m,p,IP,g} \right]$$

3.1.3.3 Entry Capacity Exceedings at an End User Domestic Point

Capacity Exceedings for Entry are not applicable to End User Domestic Points.

~~3.1.1.3.3~~ 3.1.3.4 Exit Capacity Exceedings at an End User Domestic Point

Capacity Exceedings are applicable to End User ~~Domestic Exit Point~~Domestic Points, and not to Distribution ~~Domestic Exit Point~~Domestic Points.

The Energy Exit Exceeding ($EXE_{d,XP,g}$), expressed in kWh/h for Gas Day d , for ~~Grid User~~Network User g , for ~~Domestic Exit Point~~Domestic Point XP is the highest excess, for that Gas Day d , of the final Exit Energy Allocation (XEA'_h) with respect to Transmission Services of ~~Grid User~~Network User that were switched to energy ($EMTSR_d$), the Volume Interrupted MTSR ($VIMTSR_h$), and the Energy Interrupted MTSR ($EIMTSR_h$) on the considered End User ~~Domestic Exit Point~~Domestic Point :

$$EXE_{d,XP,g} = \max_d \left[\max \left(0; -XEA'_{h,IP,g} - EMTSR_{d,XP,g} + EIMTSR_{h,XP,g} - (VMTSR_{d,XP,g} - VIMTSR_{h,XP,g}) \times GCV_{h,XP,g} \right) \right]$$

The Peak Exceeding of Exit Energy for ~~Grid User~~Network User g ($EXE_{m,p,XP,g}$) for Month m is equal to the highest daily Exit Energy Exceeding over Month m on the considered ~~Domestic Exit Point~~Domestic Point XP :

$$EXE_{m,p,XP,g} = \max_m EXE_{d,XP,g}$$

The Non-Peak Exceeding of Exit Energy for ~~Grid User~~Network User g ($EXE_{m,np,XP,g}$) for Month m is equal to the sum of all daily Exit Energy Exceedings of ~~Grid User~~Network User g for the considered Transmission Service less the Peak Exceeding of Exit Energy of ~~Grid User~~Network User g on the considered ~~Domestic Exit Point~~Domestic Point XP :

$$EXE_{m,np,XP,g} = \sum_m EXE_{d,XP,g} - EXE_{m,p,XP,g}$$

The Peak Exit Exceeding Incentive for Month m for ~~Grid User~~Network User g for ~~Domestic Exit Point~~Domestic Point XP is calculated as follows:

$$IEXE_{m,p,XP,g} = EXE_{m,p,XP,g} \times (T_{f,HP} + MP_{XP} \times T_{f,MP} + DPRS_{XP} \times T_{DPRS}) \times \min \left[\frac{1.5 \times OF_{m,XP,g}}{12}; 1 \right]$$

The Non-Peak Exit Exceeding Incentive for Month m for ~~Grid User~~Network User g for ~~Domestic Exit Point~~Domestic Point XP is calculated as follows:

$$IEXE_{m,np,XP,g} = \min \left[EXE_{m,np,XP,g} \times \frac{(T_{f,HP} + MP_{XP} \times T_{f,MP} + DPRS_{XP} \times T_{DPRS})}{6} \times \min \left[\frac{1.5 \times OF_{m,XP,g}}{12}; 1 \right]; IEXE_{m,p,XP,g} \right]$$

3.2 Short haul Services

3.1.23.2.1 Wheelings and OCUC (Operational Capacity Usage Commitments)

Wheelings and OCUC (*Operational Capacity Usage Commitments*) are operational agreements between the ~~Grid User~~Network User and the TSO, in the framework of proactive congestion management, as set out in the Code of Conduct and in Congestion Management (ACT - Attachment E).

A Wheeling or an OCUC consists of a commitment on the combined use of a given Entry Service at an Interconnection Point with a given Exit Service at another Interconnection Point, to avoid a potential congestion in the Transmission Grid, and without access to the Market Based Balancing model or to ZTP Notional Trading Services.

The Entry and Exit Services that are eligible for Wheelings or OCUC, in the framework of its proactive congestion management policy are the following ones:

Wheelings are offered between the following Interconnection Points:

- Eynatten 1 and Eynatten 2, and between Eynatten 2 and Eynatten 1
- Zelzate 1 and Zelzate 2, and between Zelzate 2 and Zelzate 1

Operational Capacity Usage Commitments are offered between the following Interconnection Points:

- Entry Eynatten 1 or Eynatten 2, with Exit 's Gravenvoeren
- Entry 's Gravenvoeren, with Exit Eynatten 1 or Eynatten 2
- Entry Zelzate 1 or Zelzate 2, with Exit IZT or Zeebrugge
- Entry IZT or Zeebrugge, with Exit Zelzate 1 or Zelzate 2
- Entry Dunkirk LNG Terminal or Virtualys, with Exit IZT or Zeebrugge.

Entry and Exit Services subject to a Wheeling or an Operational Capacity Usage Commitment are subject to a specific Regulated Tariff on the MTSR that falls under the Wheeling or the OCUC, as described in the Regulated Tariffs.

3.2.2 Zee Platform Service

The Zee Platform Service gives unlimited Firm or Backhaul MTSR ($MTSR_{f,zpf}$, $MTSR_{b,zpf}$) between the ~~Interconnection Points~~ and/or Installation Connection Points of the Zee Platform for which ~~Grid User~~ Network User has registered.

The table below shows the Capacity Type of the Zee Platform Service per Zee Platform ~~Interconnection~~ Connection Point ~~and/or Installation Point~~:

	<u>IZT</u>	<u>LNG</u>	<u>ZPT</u>	<u>Zeebrugge</u>
<u>Entry</u>	$MTSR_{f,zpf}$	$MTSR_{f,zpf}$	$MTSR_{f,zpf}$	$MTSR_{f,zpf}$
<u>Exit</u>	$MTSR_{f,zpf}$	$MTSR_{b,zpf}$	$MTSR_{b,zpf}$	$MTSR_{f,zpf}$

Any $MTSR_{f,zpf}$ and/or $MTSR_{b,zpf}$ shall be considered as Transmission Services of unlimited capacity between the Zee Platform ~~Interconnection~~ Connection Points ~~and/or Installation Point~~, to the extent that the technical import and export capacities of the Adjacent Transmission Systems at ZPT, LNG or IZT remain at the level as set forth in the table below.

	<u>Technical Import Capacity</u> <u>kWh/h</u>	<u>Technical Export Capacity</u> <u>m³(n)/h</u>
<u>Zeebrugge ZPT</u>	19,775,000	0
<u>Zeebrugge IZT</u>	25,990,000	32,770,000
<u>Zeebrugge LNG</u>	19,210,000	0

$MTSR_{f,zpf}$ and $MTSR_{b,zpf}$ do not give access to ZTP Notional Trading Services nor to the Zone, and have no access to the Market Based Balancing model (for Zee Platform, Entry and Exit Nominations have to be balanced on an hourly basis).

The utilization of Zee Platform Services is separated from Entry and Exit Services in the Zeebrugge area through a separate nomination code.

In the event that the technical import and/or export capacities of the Adjacent Transmission Systems at ZPT, LNG and IZT change compared to the levels as set forth in the table above, the Transmission System Operator shall as soon as reasonably possible communicate to Grid User ~~Network User~~ the resulting capacity limitations (if any) following from this new situation, which shall automatically and immediately apply to the $MTSR_{f,zpf}$ and/or $MTSR_{b,zpf}$.

3.23.3 Cross Border Delivery Service

A Cross Border Delivery Service ($MTSR_{cbds}$) enables a ~~Grid User~~ Network User to inject a quantity of Natural Gas in the Transmission System at a Connection Point which is not located in Belgium nor directly physically connected to the Transmission System of Fluxys Belgium.

The Cross Border Delivery Service shall always be associated and implicitly allocated together (meaning matched in quantity, time and Capacity Type) with the subscription of its associated Entry, Exit and/or OCUC Services, as described in ACT – Attachment B. The Cross Border Delivery Service shall be offered on Interconnection Points and/or Installation Points linked to Cross Border Capacity. The Operator of the Transmission System or Installation connected to the Fluxys Belgium grid by means of the Cross Border Capacity shall be considered as an Adjacent TSO to the Fluxys Belgium’s grid.

Overview of existing Cross Border Delivery Services:

Capacity Transmission Services (*)	Service Period	Rate Type	MTSR code
Cross Border Delivery Service on Installation Point Dunkirk LNG Terminal	>= 1 year	Yearly	$MTSR_{d,cbd,f,y,IP}$
	< 1 year	Seasonal	$MTSR_{d,cbd,f,s,IP}$

(*) Note that the Cross Border Delivery Service is only offered on Entry and that the Capacity Type can only be Firm.

~~3.31.1 Zee Platform Service~~

~~The Zee Platform Service gives unlimited Firm or Backhaul MTSR ($MTSR_{f,zpf}$ $MTSR_{b,zpf}$) between the Interconnection Points of the Zee Platform for which Grid User Network User has registered.~~

~~The table below shows the Capacity Type of the Zee Platform Service per Zee Platform Interconnection Point:~~

	<u>IZT</u>	<u>LNG</u>	<u>ZPT</u>	<u>Zeebrugge</u>
<u>Entry</u>	$MTSR_{f,zpf}$	$MTSR_{f,zpf}$	$MTSR_{f,zpf}$	$MTSR_{f,zpf}$
<u>Exit</u>	$MTSR_{f,zpf}$	$MTSR_{b,zpf}$	$MTSR_{b,zpf}$	$MTSR_{f,zpf}$

~~Any $MTSR_{f,zpf}$ and/or $MTSR_{b,zpf}$ shall be considered as Transmission Services of unlimited capacity between the Zee Platform Interconnection Points, to the extent that~~

~~the technical import and export capacities of the Adjacent Transmission Systems at ZPT, LNG or IZT remain at the level as set forth in the table below.~~

	Technical Import Capacity kWh/h	Technical Export Capacity m³(n)/h
Zeebrugge ZPT	19,775,000	0
Zeebrugge IZT	25,990,000	32,770,000
Zeebrugge LNG	19,210,000	0

~~MTSR_{f,zpf} and MTSR_{b,zpf} do not give access to ZTP Notional Trading Services nor to the Zone, and have no access to the Market Based Balancing model (for Zee Platform; Entry and Exit Nominations have to be balanced on an hourly basis).~~

~~The utilization of Zee Platform Services is separated from Entry and Exit Services in the Zeebrugge area through a separate nomination code.~~

~~In the event that the technical import and/or export capacities of the Adjacent Transmission Systems at ZPT, LNG and IZT change compared to the levels as set forth in the table above, the Transmission System Operator shall as soon as reasonably possible communicate to Grid User Network User the resulting capacity limitations (if any) following from this new situation, which shall automatically and immediately apply to the MTSR_{f,zpf} and/or MTSR_{b,zpf}.~~

3.4 Quality Conversion Services

3.3.13.4.1 Quality Conversion Services H→L

The following Quality Conversion Services H→L are offered, namely “peak load”, “base load” and “seasonal load”, each with a different tariff and different specifications regarding the availability of capacities, as described in Attachment C3.

The Quality Conversion Service H→L ($MTSR_{QCH \rightarrow L}$) consists of the possibility to have Natural Gas transmitted from the H Zone to the L zone, at the Installation Point “QC”. The peak load Quality Conversion Service H→L ($MTSR_{QCH \rightarrow L, pl}$) can be used from 1/11/Y until 31/03/Y+1 and the availability depends on the temperature, such that more capacity is available at cold temperatures. The seasonal load Quality Conversion Service H→L ($MTSR_{QCH \rightarrow L, sl}$) can be used during the whole Contract year, but its usage is limited from 1/04/Y+1 until 31/10/Y+1. The base load Quality Conversion Service H→L ($MTSR_{QCH \rightarrow L, bl}$) can be used during the whole Contract year.

Peak Load Quality Conversion Services H→L are offered in standard bundled units. One standard bundled unit consists of the following Quality Conversion Services:

Firm peak load H->L capacity	Interruptible peak load H->L capacity
1 kWh/h	0,13 kWh/h

Base and Seasonal Load Quality Conversion Service H→L are offered in energy [kWh/h], as set out in Subscription & Allocation of Services (ACT – Attachment B). No additional Transmission Services from and towards the Installation Point “QC” are required. The following capacities are offered for the different Quality Conversion Services H→L¹²:

Peak load	Firm	177.000 m ³ (n)/h = 1.734.600 kWh/h	1.734.600 bundles
	Interruptible	23.010 m ³ (n)/h = 225.498 kWh/h	
Base load	Firm	100.000 m ³ /h = 980.000 kWh/h	-
Seasonal load	Firm		

Nominations for Quality Conversion H→L shall be made in accordance with the Operating Procedures (ACT – Attachment C.3).

The TSO calculates the Real Conversion Capacity in function of the equivalent temperature and period of year as set out in the Operating Procedures (ACT - Attachment C.3). The Nominations shall not exceed the Real Conversion Capacity of ~~Grid User~~Network User.

3.3.23.4.2 **Quality Conversion Services L→H**

The Quality Conversion Service L→H consists of the possibility to inject L Natural Gas into the H Zone ($MTSR_{QCL \rightarrow H,i}$).

Quality Conversion Services L→H can be subscribed as set out in Subscription & Allocation of Services (ACT - Attachment B). No additional Transmission Services are required.

3.43.5 **ZTP Trading Services**

3.4.13.5.1 **Overview on the ZTP Trading Services**

The TSO offers ZTP Trading Services, enabling ~~Grid User~~Network Users to execute transaction (exchange title of gas), through following services:

¹² Depending on operational needs, changes to the installations or the availability of the logistics contracts (e.g. with nitrogen suppliers), the TSO possibly has to adapt the Quality Conversion Service offering.

- ZTP Physical Trading Services, and associated Imbalance Pooling Service and Imbalance Transfer Service
- ZTP Notional Trading Services (on ZTP for the H Zone, on ZTPL for the L Zone)

The operational aspects of the ZTP Trading Services are described in ACT-Attachment C1 (matching, allocations, reporting).

3.4.23.5.2 **Imbalance Pooling Service**

The Imbalance Pooling Service enables ~~Grid User~~Network Users to transfer the Net Confirmed Title Transfer for ZTP Physical Trading Services, from one ~~Grid User~~Network User ('Imbalance Transferor') to another ~~Grid User~~Network User ('Imbalance Transferee') as an Imbalance Pooling Transfer ($IPT_{h,z,g}$) as follows:

- the Imbalance Transferor shall authorise that the (whole) hourly Net Confirmed Title Transfer for ZTP Physical Trading Services ($NCTTP_{h,g,z}$) being positive as well as negative shall be transferred to the Imbalance Transferee;
- the Imbalance Transferee shall authorise that the (whole) hourly Net Confirmed Title Transfer for ZTP Physical Trading Services ($NCTTP_{h,g,z}$) of the Imbalance Transferor, if any, being positive as well as negative shall be transferred from the Imbalance Transferor to the Imbalance Transferee ;
- the transfer of the hourly Net Confirmed Title Transfer for ZTP Physical Trading Services shall be performed by the TSO before the Imbalance Transfer Service, as provided for in section 3.5.33.7.3;
- the transfer of the Net Confirmed Title Transfer for ZTP Physical Trading Services will be performed by the TSO as implicit Nominations on the ZTP Physical Trading Services and will be accounted for as transactions for both Parties in accordance with Section 6.2.11.2;
- a ~~Grid User~~Network User can only perform the role of either Imbalance Transferor or Imbalance Transferee;

The Imbalance Pooling Service can be subscribed according to the rules defined in ACT – Attachment B and via the Imbalance Pooling Service form as published on the Fluxys Belgium website.

3.4.33.5.3 **Imbalance Transfer Service**

The Imbalance Transfer Service is a Service performed by the TSO for the ~~Grid User~~Network User(s) whereby the Net Confirmed Title Transfer for ZTP Physical Trading Services ($NCTTP_{h,g,z}$) are automatically transferred to/from the ~~Grid User~~Network User Balancing Position in the BeLux H-Zone. The Transmission Services (Entry or Exit) at the Interconnection Point Zeebrugge required to perform such transfer are implicitly allocated.

Transmission Services at Zeebrugge ($MTSR_{ITSia}$) are implicitly allocated to the ~~Grid User~~Network User till the end of the same Gas Day in case and up to the amount the hourly quantities transferred under this Imbalance Transfer Service plus the hourly matched Nominations ($EEN^{m}_{h,g}$, $XEN^{m}_{h,g}$) on Transmission Services for Interconnection Points IZT, ~~Zeebrugge LNG Terminal and ZPT~~ and Installation Point Zeebrugge LNG Terminal are the sum of:

- the hourly subscribed Transmission Services at the Interconnection Points Zeebrugge, IZT, ~~Zeebrugge LNG Terminal and ZPT~~ and at Installation Point Zeebrugge LNG Terminal of the ~~Grid User~~Network User in the same direction
($MTSR_{Zeebrugge,h,g} + MTSR_{IZT,h,g} + MTSR_{ZeebruggeLNGTerminal,h,g} + MTSR_{ZPT,h,g}$); and
- the implicitly allocated Transmission Services at Zeebrugge till the end of the same Gas Day under the Imbalance Transfer Service for (a) previous hour(s) of the same Gas Day ($MTSR_{ITSia,h-n,g}$).

This Service is an associated Service, which doesn't have to be subscribed by ~~Grid User~~Network Users and which is performed by the TSO for each ~~Grid User~~Network User using the ZTP Physical Trading Service as long as Firm Transmission Services are available at the Interconnection Points Zeebrugge, IZT, ~~Zeebrugge LNG Terminal and ZPT~~ and at installation Point Zeebrugge LNG Terminal in the same direction. The detailed calculation of the implicit allocation of Transmission Services at the Interconnection Point Zeebrugge for the Imbalance Transfer Service is set out in ACT- Attachment B.

3-53.6 Substitution Services

The Substitution Services enable a ~~Grid User~~Network User holding unbundled Transmission Service at an Interconnection Point or at an Installation Point to either convert ~~the (part of) that~~ Transmission Service into a bundled Transmission Service on the same Interconnection Point, or to transfer (part of) that Transmission Service to another Interconnection Point or Installation Point. It is to be understood that Substitution Services are not modifying the existing Transmission Services except for, as the case may be, the Connection Point, the quantity, the tariff and/or the capacity type. As a consequence, Entry or Exit Transmission Services resulting from the conversion of a Transmission Service from unbundled to bundled, and/or resulting from the transfer of a Transmission Service from an Interconnection Point or an Installation Point to another Interconnection Point or Installation Point, cannot be considered as eligible for OCUC or Wheeling.

Transmission Services bought on PRISMA in the framework of Substitution Services are substituted by existing Transmission Services with its related contract reference. This reference is unknown by PRISMA and as a consequence, Entry or Exit Transmission Services resulting from the conversion of a Transmission Service from unbundled to bundled, and/or resulting from the transfer of a Transmission Service

from an Interconnection Point or an Installation Point to another Interconnection Point or Installation Point cannot be assigned to another Network User on PRISMA.

3.5.13.6.1 Capacity Conversion Service

The Capacity Conversion Service enables ~~Grid User~~Network Users holding unbundled capacity at one side of an Interconnection Point to convert this capacity into bundled capacity according to the conditions set forth in ACT – Attachment B and free of extra charge.

Firm and Backhaul Entry and Exit Transmission Services as well as OCUC and Wheeling Transmission Services are eligible for Capacity Conversion Service.

To apply, the ~~Grid User~~Network User will use the Service Request Form for Capacity Conversion Service as published on the Fluxus Belgium website.

~~3.5.2 Reshuffling Service~~

~~Only unbundled Firm or Backhaul Entry and Exit Transmission Services are eligible for Reshuffling Service. Entry and Exit Transmission Services that are associated with Cross Border Delivery Service, OCUC and Wheeling Transmission Services are not eligible for Reshuffling Service.~~

~~The service is offered to Grid User having a $MTSR_{d,f,y,IP}$ on each day of the period starting on 1 October 2018 and ending on 30 September 2023. The eligible MTSR for Reshuffling Service – 5 years option – ($MTSR_{RS5}$) on an Interconnection Point, in one direction, corresponds to the smallest $MTSR_d$ on that Interconnection Point and in that direction on the considered period. Moreover, Transmission Services that are assigned with retained payment obligation cannot be transferred under the Reshuffling Service by the assignor nor the assignee.~~

~~The service is also offered to Grid User having a $MTSR_{d,f,y,IP}$ on each day of the period starting on 1 October 2019 and ending on 30 September 2023. The eligible MTSR for Reshuffling – 4 years option – ($MTSR_{RS4}$) on an Interconnection Point, in one direction, corresponds to the smallest $MTSR_d$ on that Interconnection Point and in that direction on the considered period.~~

~~For the avoidance of doubts, the $MTSR_{RS4}$ and $MTSR_{RS5}$ are constant over the whole considered period.~~

~~In the framework of the Reshuffling Service, TSO shall offer to the Grid User holding $MTSR_{RS4}$ or $MTSR_{RS5}$ on an Interconnection Point and in one direction the possibility transfer its underlying existing Transmission Services during the considered period under the strict conditions that:~~

- ~~• Grid User subscribes new Transmission Services on any other Interconnection Point¹³ flat over each Gas Year of the considered period. Such new Transmission Services shall have the same direction than the existing Transmission Services to be reshuffled and generate equivalent monthly capacity fees for TSO¹⁴ (based on tariffs applicable at the time of the allocation and without taking into account any premium due by Grid User for a given auction); and~~
- ~~• Grid User surrenders the existing Transmission Services to be reshuffled on each Gas Year of the considered period according to ACT Attachment E.~~

~~For the avoidance of doubts, if the Grid User did not manage to acquire the requested new Transmission Services but the TSO was able to reallocate (part of) the existing Transmission Services under the conditions of the Surrender process, the Grid User shall be released from the rights and obligations of (such part of) its existing Transmission Services under the Surrender process, including applicable tariff due (ACT Attachment E).~~

~~The applicable tariff for Reshuffling Service, as set out in Article 6.2.13 of the current Attachment, shall be applied only on the new Transmission Services that have effectively been acquired.~~

~~The Reshuffling Service can only be requested during a subscription window as set out in Subscription & Allocation of Services (ACT Attachment B).~~

3.5.33.6.2 *L/H Capacity Switch Service*

In the framework of the physical L-gas to H-gas conversion project, TSO shall proceed with the commercial conversion of the concerned L-gas Domestic Exits each year on the 1st of June.

The L/H Capacity switch Service is offered each Gas Year, free of charge, to ~~Grid User~~Network Users having a $M_{TSR_{d,f,y,IP}}$ Entry on a L-gas Interconnection Point after the 1st of June of that Gas Year. Only unbundled Firm Entry Transmission Services are eligible for the L/H Capacity switch Service. Moreover, Transmission Services that are assigned with retained payment obligation cannot be transferred under the L/H Capacity Switch Service by the assignor nor the assignee.

Each Gas Year Y, following the confirmation of the conversion planning made by Synergrid, TSO shall publish the percentages $P_{LH,Y+1}$ and $P_{LH,Y+2}$ that depends on the level of L-gas Domestic Exit capacities that will have been that are scheduled to be

¹³ On H-Zone or L-Zone

¹⁴ ~~Meaning that the quantity of the requested Transmission Service shall be equal to the quantity of the to be reshuffled Transmission Service multiplied by the tariff ratio of the considered Interconnection Points.~~

converted to H-gas between the 1st of June 2018 and the start of Gas Years Y+1 and Y+2, respectively.

The quantity that will be eligible for the L/H Capacity switch Service on a L-gas Interconnection Point for the Gas Year Y+1 ($MTSR_{LHCS, Y+1}$), shall be equal to the $MTSR_{d,e}$ such Grid User holds on that Interconnection Point on the 1st of June of Gas Year Y multiplied by the applicable percentage $P_{LH, Y+1}$.

$$MTSR_{LHCS, Y+1} = MTSR_{1/06/Y, x} P_{LH, Y+1}$$

The quantity that will be eligible for the L/H Capacity switch Service on a L-gas Interconnection Point for the Gas Years Y+x ($MTSR_{LHCS, Y+x}$), shall be equal to the $MTSR_{d,e}$ such ~~Grid User~~ Network User holds on that Interconnection Point on the 1st of June of Gas Year Y multiplied by the applicable percentage $P_{LH, Y+x}$.

$$MTSR_{LHCS, Y+x} = MTSR_{1/06/Y, x} P_{LH, Y+x}$$

In the framework of the L/H Capacity switch Service, TSO shall offer to the ~~Grid User~~ Network User holding $MTSR_{LHCS}$ on a L-gas IP the possibility to transfer (part of the) of the underlying existing Transmission Services during the considered Gas Years at the strict conditions that:

- ~~Grid User~~ Network User subscribes new Firm Entry Transmission Services on any H-gas Interconnection Point for the considered Gas Years. Such new Transmission Services shall have the same quantity in kWh/h than the existing Transmission Services to be switched; and
- ~~Grid User~~ Network User surrenders the existing L-gas Entry Transmission Services to be switched on the considered Gas Years according to ACT – Attachment E.

For the avoidance of doubts, if the ~~Grid User~~ Network User did not manage to acquire the requested new Transmission Services but the TSO was able to reallocate (part of) the existing Transmission Services under the conditions of the Surrender process, the ~~Grid User~~ Network User shall be released from the rights and obligations of (such part of) its existing Transmission Services under the Surrender process, including applicable tariff due (ACT- Attachment E).

The L/H Capacity switch Service can only be requested during a subscription window as set out in Subscription & Allocation of Services (ACT – Attachment B).

~~On an exceptional basis, in order to facilitate the application of the L/H Capacity switch Service, TSO shall in 2018 offer to Grid User Network Users having a contracted Entry $MTSR$ at a L gas Interconnection Point in the coming Gas Years, an unique opportunity to align its L gas Entry portfolio on Gas Year by transferring the quantity above its minimum Entry $MTSR_d$ over a Gas Year to any Interconnection~~

~~Point on the H Zone, provided that that quantity is available on the Primary market. This transfer can only be requested during a subscription window as set out in Subscription & Allocation of Services (ACT Attachment B).~~

3.5.43.6.3 **Diversion Service**

~~Only unbundled Firm and Backhaul Entry and Exit Transmission Services as well as OCUC Transmission Services are eligible for Diversion Service. OCUC and Wheeling Transmission Services are not eligible for Diversion Service.~~

The Diversion Service is offered, free of charge, to Network Users willing to transfer Transmission Services for a standard period of a Month, a Quarter or a Gas Year¹⁵ prior to each monthly, quarterly and yearly auction, free of charge, to Grid Users willing to transfer Transmission Services during the considered period between the following Interconnection Points or Installation Point that are at the same grid location :

- Zelzate 1 and Zelzate 2
- Eynatten 1 and Eynatten 2
- Zeebrugge, Zeebrugge LNG Terminal, ZPT and IZT

~~The eligible MTSR for Diversion Service $MTSR_{DS,f}$ on an Interconnection Point, in one direction, corresponds to the smallest $MTSR_{d,f}$ on that Interconnection Point and in that direction on the considered period.~~

~~In the framework of the Diversion Service, TSO shall offer Diversion Service to the Grid User/Network User on such Interconnection Points or Installation Point holding $MTSR_{DS,f}$ on an Interconnection Point the possibility to transfer (part of) its existing Firm or Backhaul Transmission Services during the considered period under the strict conditions that:~~

~~Grid User/Network User subscribes new Transmission Services on another applicable Interconnection Point or Installation Point for the considered period. Such new Transmission Services shall have the same direction than the existing Transmission Services to be diverted and generate equivalent monthly capacity fees for TSO (based on tariffs applicable at the time of the allocation and without taking into account any premium due by Grid User/Network User for a given auction); and~~

~~Grid User surrenders the existing Transmission Services to be diverted for the considered period according to ACT Attachment E.~~

~~For the avoidance of doubt, if the Grid User did not manage to acquire the requested new Transmission Services but the TSO was able to reallocate (part of) the existing~~

¹⁵ Except for Transmission Services that are sold on FCFS basis for which a minimum of 30 days shall be considered.

~~Transmission Services under the conditions of the Surrender process, the Grid User shall be released from the rights and obligations of (such part of) its existing Transmission Services under the Surrender process, including applicable tariff due (ACT Attachment E).~~

To apply, the ~~Grid User~~Network User will use the Service Request Form for Diversion Service as published on the Fluxys Belgium website¹⁶.

3.7 Ancillary Services

3.7.1 Real-time data measurement

The TSO offers a real-time data service which can additionally be subscribed by Network Users and which provides them with on-line gas flow data (updated every 6 minutes) for selected Interconnection Points, privately available on the Electronic Data Platform.

4 Nominations, Metering and Allocations

4.1 Overview

The following table illustrates the different parameters for Nominations and Allocations at Interconnection Points, Installation Points and applicable Domestic Exit Point~~Domestic Points~~, defined and used in this section.

		Interconnection <u>Connection Point</u>	
		Entry	Exit
<u>Nominations</u>	Last <u>received</u>	EEN'_h	XEN'_h
	Last <u>cConfirmed</u>	EEN^m_h	XEN^m_h
Allocations	Provisional	$EEA_h & EVA_h$	$XEA_h & XVA_h$
	Final	$EEA'_h & EVA'_h$	$XEA'_h & XVA'_h$
Metering	Provisional	$EM_h & VM_h & GCV_h$	$EM_h & VM_h & GCV_h$
	Validated	$EM'_h & VM'_h & GCV'_h$	$EM'_h & VM'_h & GCV'_h$

4.2 Nominations

In order to notify the TSO of the quantity of Natural Gas that will flow at each Interconnection Point, Installation Point or End User ~~Domestic Exit Point~~Domestic Point, the ~~Grid User~~Network User shall send Nominations and, if applicable, renominations to the TSO, according to the Operating Procedures (ACT – Attachment C.1).

¹⁶ The possibility to use PRISMA to request the Diversion of existing services is being developed. The start date will be confirmed by the TSO at least 4 weeks in advance. Until then, the procedure remains manual

The Nominations and Allocation for Entry and Exit Services subject to a Wheeling or an OCUC are independent from other Entry and Exit Services through the use of separate nomination codes, as described in the Operating Procedures (ACT – Attachment C.1).

4.3 Metering

Each ~~Intereconnection-Connection Point~~ or ~~Domestic-Exit Point~~ may contain one or more Nodes providing hourly measurement data, as set out in the Metering Procedures (ACT - Attachment D).

4.4 Allocations

At each ~~Intereconnection-Connection Point~~, or ~~Domestic-Exit Point~~, the TSO shall allocate a quantity of the Natural Gas measured to each ~~Grid-User~~Network User for which Natural Gas is transported at that Connection Point, according to the relevant Allocation Agreement or Operating Balancing Agreement, as set out in the Operating Procedures (ACT - Attachment C.1).

The determination of provisional allocations of Natural Gas takes place every hour. The determination of the final allocated quantities of Natural Gas takes place on M+1 for every hour.

5 Balancing and Allocation settlement

Balancing Services are operated by the Balancing Operator, based on provisional data (H+1). Allocation settlements are settlements based on the difference between the provisional and the final data and are settled after the considered Month between the ~~Grid-User~~Network User and the concerned TSO of the BeLux Area.

5.1 Hourly exchange of information between the TSO and the Balancing Operator

For the purposes of enabling Balancing Operator to provide the Balancing Services, the concerned TSOs of the BeLux Area shall send hourly imbalance information by ~~Grid-User~~Network User g, for each Zone z and for each hour h to the Balancing Operator.

The hourly Imbalance ($I_{h,z,g}$) for an hour h for a Zone z and for ~~Grid-User~~Network User g is calculated as the sum of all provisional hourly Entry Energy Allocations¹⁷ for ~~Grid-User~~Network User for the ~~Intereconnection-Connection~~ Points of the considered Zone ($EEA_{h,z,g}$) increased by the provisional hourly Exit Energy Allocations¹⁸ (negative values) for ~~Grid-User~~Network User g for the Connection

¹⁷ Entry and Exit Services submitted to an OCUC and Wheeling Services, Direct Lines and Zee Platform Services are not considered in the hourly Imbalance and for Distribution Domestic Exit, the Exit Energy Allocations are calculated as set out in the Operating Procedures (ACT - Attachment C.1).

~~Points Intereconnection Points and the Domestic Exit Points~~ of the considered Zone ($XEA_{h,z,g}$), increased by the Net Confirmed Title Transfers for ZTP Notional Trading Services¹⁸ ($NCTTN_{h,z,g}$):

$$I_{h,z,g} = \sum_{Zone} EEA_{h,z,g} + \sum_{Zone} XEA_{h,z,g} + NCTTN_{h,z,g}$$

5.2 Allocation Settlements

The difference between provisional allocations and the final allocations is settled via the Allocation Settlements.

The quantity to be settled for Gas Day d for a ~~Grid User~~Network User g , in the Zone z for Allocation Settlement ($AS_{d,z,g}$) is calculated as the sum of the difference between the provisional and final Entry Allocations ($EEA'_{h,z,g}$ and $EEA_{h,z,g}$ respectively) and between the provisional and final Exit Allocations ($XEA'_{h,z,g}$ and $XEA_{h,z,g}$ respectively).

$$AS_{d,z,g} = \sum_{h \in d} \left[(EEA'_{h,z,g} - EEA_{h,z,g}) + (XEA'_{h,z,g} - XEA_{h,z,g}) \right]$$

The following cases can occur:

- Allocation Settlement ~~Grid User~~Network User Sale ($ASGS_{d,z,g}$);
- Allocation Settlement ~~Grid User~~Network User Purchase ($ASGP_{d,z,g}$).

5.2.1 Allocation Settlement ~~Grid User~~Network User Sale

In case the Allocation Settlement ($AS_{d,z,g}$) is negative, there will be an Allocation Settlement ~~Grid User~~Network User Sale ($ASGS_{d,z,g}$ – negative value):

$$ASGS_{d,z,g} = AS_{d,z,g} * GP_{d,z,g}$$

5.2.2 Allocation Settlement ~~Grid User~~Network User Purchase

In case the Allocation Settlement ($AS_{d,z,g}$) is positive, an Allocation Settlement ~~Grid User~~Network User Purchase ($ASGP_{d,z,g}$ – positive value) will take place:

$$ASGP_{d,z,g} = AS_{d,z,g} * GP_{d,z,g}$$

¹⁸ Net Confirmed Title Transfer for ZTP Physical Trading Services ($NCTTP_{h,z,g}$) are considered as net Entry or Exit Allocations at Interconnection Point Zeebrugge

6 Invoicing

6.1 General

There are 2 monthly invoices:

- Monthly Invoice;
- Monthly Self-billing Invoice.

The following Fees are invoiced with the Monthly Invoice:

- Monthly Capacity Fees;
- Monthly Variable Flex Fee;
- Monthly Capacity Pooling Service Fee;
- Monthly Zee Platform Fee;
- Monthly Capacity Fee Quality Conversion H→L;
- Monthly Variable Fee for Quality Conversion H->L;
- Monthly Capacity Fee Quality Conversion L->H;
- Monthly Fixed Fees for ZTP Trading Services;
- Monthly Fee for implicitly allocated Transmission Service at Zeebrugge Interconnection Point for Imbalance Transfer Service;
- Monthly Energy In Cash Fee;
- Monthly Allocation Settlement ~~Grid User~~Network User Purchase Fees;
- Monthly Transmission Imbalance Fee;
- Monthly Odorisation Fee;
- Monthly Variable Fees for ZTP Trading Services and transactions;
- Monthly Incentive Fees.
- Monthly Administrative Fees.

The following Fees are invoiced with the Monthly Self-billing Invoice:

- Monthly Allocation Settlement ~~Grid User~~Network User Sales Fees.

6.2 Monthly Invoice

6.2.1 Monthly Capacity Fees

The Monthly Capacity Fee (MCAF) is calculated for the MTSR subscribed by or implicitly allocated¹⁹ to Grid-User/Network User for each ~~Interconnection-Connection Point or Domestic-Exit Point~~, for each Transmission Service, for each Capacity Type and for each Rate Type.

Monthly Capacity Fees can either be:

- positive, for the MTSR subscribed by the Network User or; positive, for the MTSR subscribed by or implicitly allocated to the Grid-User/Network User or;
- negative, ~~Grid-User/Network User~~ will be credited by the TSO in case of buy-back, surrender of capacity or long-term use-it-or-lose-it, as described in section 6.2.1.1.

6.2.1.1 Monthly Capacity Fees at Interconnection Points and Installation Points

For Yearly Transmission Services at an Interconnection Point or Installation Point IP²⁰, the Monthly Capacity Fee is the sum, for each Gas Day²¹ of the considered Gas Month, of the terms that are the result of the following calculations:

- The quantity for ~~Grid-User/Network User~~ g, of Transmission Service ts, of Capacity Type ct, with Rate Type yearly (y), for Interconnection Point IP, for Gas Day d ($MTSR_{d,ts,ct,y,IP,g}$)²²;
- multiplied by the corresponding Regulated Tariff ($T_{ts,ct,IP}$)
- divided by the number of Days in the considered Year (N_y).

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,ts,ct,y,IP,g} \times \frac{T_{ts,ct,IP}}{N_y} \right]$$

¹⁹ In the framework of Loenhout implicit capacity allocation or through overnomination ($MTSR_{ONia}$), or on Distribution Domestic Points

²⁰ For Wheeling Services, IP refers to “from IP1 to IP2”

²¹ From 2020 onwards and in line with NC TAR regulation, the Monthly Capacity Fee for Yearly Transmission Services at Interconnection Points will be the result of a sum of each Gas Hour of the considered Gas Month as described in following formula.

$$= \sum_{\text{all hours } h \text{ of month } m} \left[MTSR_{h,ts,ct,y,IP,g} \times \frac{T_{ts,ct,IP}}{N_{h,y}} \right]$$

²² As specified in the Regulated Tariffs, for the Transmission Services booked during Within-Day Auctions, the highest hourly MTSR of the Gas Day is taken into account as $MTSR_d$ (valid until 31/12/2019).

For Seasonal Transmission Services, the Monthly Capacity Fee is the sum, for each Gas Day²³ of the considered Month of the terms that are the result of the following calculations:

- The quantity of ~~Grid User~~Network User g , for Transmission Service ts , of Capacity Type ct , with Rate Type seasonal (s), at Interconnection Point or Installation Point IP , for Gas Day d ($MTSR_{d,ts,ct,s,IP,g}$)²⁴;
- multiplied by the corresponding Regulated Tariff ($T_{ts,ct,IP}$);
- multiplied by the Seasonal Coefficient of the considered month m (SC_m);
- multiplied by the Non-Yearly Multiplier (NYM) where NYM=1 until 31/12/2019 and is described in the Regulated Tariff as from 01/01/2020;
- divided by the number of Days in the considered Year (N_y).

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,ts,ct,s,IP,g} \times \frac{T_{ts,ct,IP}}{N_y} \times SC_m \times NYM \right]$$

In addition to the invoicing of the Regulated Tariffs as described in the first two paragraphs of this section, for Transmission Services subscribed by ~~Grid User~~Network User via an Auction, the Monthly Capacity Fee is increased by the sum of the Auction Premiums for the delivered Transmission Services of this monthly period.

~~Grid User~~Network User will be credited for an amount corresponding with the Transmission Services bought back through the buy-back procedure(s), taking into account, for each Gas Day of the considered Month, the following elements:

- The sum of the quantities per day of Firm Transmission Services ($MTSR_{BB,d}$) bought back through the relevant buy-back procedure(s); multiplied with
- Price ($P_{BB,g}$) for the relevant buy-back procedure,

$$= \sum_{\text{all days } d \text{ of month } m} \left[\sum [MTSR_{BB,d}] \times P_{BB,g} \right]$$

²³ From 2020 onwards and in line with NC TAR regulation, the Monthly Capacity Fee for Seasonal Transmission Services at Interconnection Points will be the result of a sum of each Gas Hour of the considered Gas Month as described in following formula.

$$= \sum_{\text{all hours } h \text{ of month } m} \left[MTSR_{h,ts,ct,s,IP,g} \times \frac{T_{ts,ct,IP}}{N_{h,y}} \times SC_m \times NYM \right]$$

²⁴ As specified in the Regulated Tariffs, for Transmission Services booked during Within-Day Auctions, the highest hourly MTSR of the Gas Day is taken into account as $MTSR_d$ (valid until 31/12/2019).

In case of long term use-it-or-lose-it or surrender as described in Attachment E, ~~Grid User~~Network User will also be credited.

6.2.1.2 Monthly Capacity Fees at ~~Domestic Exit Point~~Domestic Points

For Yearly Transmission Services at a ~~Domestic Exit Point~~Domestic Point XP , the Monthly Capacity Fee is the sum, for each Gas Day of the considered Month, of the terms that are the result of the following calculations:

- The quantity of ~~Grid User~~Network User g , of Capacity Type ct , with Rate Type yearly (y), at ~~Domestic Exit Point~~Domestic Point XP , for Gas Day d ($MTSR_d$ $MTSR_{d,ct,y,XP,g}$);
- multiplied by the corresponding Regulated Tariff(s), taking into account the physical MP and DPRS characteristics²⁵ of the considered ~~Domestic Exit Point~~Domestic Point ($T_{ct,HP,XP}$, MP_{XP} , $T_{ct,MP,XP}$, $DPRS_{XP}$, T_{DPRS});
- divided by the number of Days in the considered Year (N_y).

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,ts,ct,y,XP,g} \times \frac{(T_{ts,ct,HP,XP} + MP_{XP} \times T_{ct,MP,XP} + DPRS_{XP} \times T_{DPRS})}{N_y} \right]$$

For Seasonal Transmission Services at a ~~Domestic Exit Point~~Domestic Point XP , the Monthly Capacity Fee is the sum, for each Gas Day²⁶ of the considered Month, of the terms that are the result of the following calculations:

- The quantity for ~~Grid User~~Network User g , of Capacity Type ct , with Rate Type seasonal (s), at ~~Domestic Exit Point~~Domestic Point XP , for Gas Day d ($MTSR_{d,ct,s,XP,g}$);
- multiplied by the corresponding Regulated Tariff(s), taking into account the physical MP and DPRS characteristics²⁷ of the considered ~~Domestic Exit Point~~Domestic Point ($T_{ct,HP,XP}$, MP_{XP} , $T_{ct,MP,XP}$, $DPRS_{XP}$, T_{DPRS});

²⁵ From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the Reduced Pressure Service. This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits. Hence from that date MP_{XP} and $DPRS_{XP}$ coefficients will be replaced by RPS_{XP} and accordingly the $T_{ct,RPS,XP}$ will be applied.

²⁶ From 2020 onwards and in line with NC TAR regulation, the Monthly Capacity Fee for Seasonal Transmission Services at Domestic Points will be the result of a sum of each Gas Hour of the considered Gas Month as described in following formula.

$$= \sum_{\text{all hours } h \text{ of month } m} \left[MTSR_{h,ts,ct,y,XP,g} \times \frac{(T_{ts,ct,HP,XP} + MP_{XP} \times T_{ct,MP,XP} + DPRS_{XP} \times T_{DPRS})}{N_{h,y}} \right]$$

²⁷ From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the Reduced Pressure Service. This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits. Hence from that date MP_{XP} and $DPRS_{XP}$ coefficients will be replaced by RPS_{XP} and accordingly the $T_{ct,RPS,XP}$ will be applied.

- multiplied by the Seasonal Coefficient of the considered month m (SC_m);
- multiplied by the Non-Yearly Multiplier (NYM) where $NYM=1$ until 31/12/2019 and is described in the Regulated Tariff as from 01/01/2020;
- divided by the number of Days in the considered Year (N_y).

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,ct,s,XP,g} \times \frac{(T_{Is,ct,HP,XP} + MP_{XP} \times T_{ct,MP,XP} + DPRS_{XP} \times T_{DPRS})}{N_y} \times SC_m \times NYM \right]$$

For Short Term Transmission Services at a ~~Domestic Exit Point~~Domestic Point XP , the Monthly Capacity Fee is the sum, for each Gas Day²⁸ of the considered Month, of the terms that are the result of the following calculations:

- The quantity for ~~Grid User~~Network User g , of Capacity Type ct , with Rate Type Short Term (st), at ~~Domestic Exit Point~~Domestic Point XP , for Gas Day d ($MTSR_{d,ct,st,XP,g}$);
- multiplied by the corresponding Regulated Tariff(s), taking into account the physical MP and DPRS characteristics²⁹ of the considered ~~Domestic Exit Point~~Domestic Point ($T_{ct,HP,XP}$, MP_{xp} , $T_{ct,MP,XP}$, $DPRS_{xp}$, T_{DPRS});
- multiplied by the Seasonal Coefficient of the considered month m (SC_m);
- divided by the number of Days in the considered Year (N_y);
- multiplied by the Non-Yearly Multiplier (NYM) where $NYM=1$ until 31/12/2019 and is described in the Regulated Tariff as from 01/01/2020
- ~~multiplied by the Non Yearly Multiplier (NYM) where $NYM=1$ until 31/12/2019 and included in the tariff sheet as from 01/01/2020~~
- multiplied by the Short Term Multiplier (STM).

²⁸ From 2020 onwards and in line with NC TAR regulation, the Monthly Capacity Fee for Short Term Transmission Services at Domestic Points will be the result of a sum of each Gas Hour of the considered Gas Month as described in following formula.

$$= \sum_{\text{all hours } h \text{ of month } m} \left[MTSR_{h,ct,s,XP,g} \times \frac{(T_{Is,ct,HP,XP} + MP_{XP} \times T_{ct,MP,XP} + DPRS_{XP} \times T_{DPRS})}{N_{h,y}} \times SC_m \times NYM \right]$$

²⁹ From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the Reduced Pressure Service. This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits. Hence from that date MP_{XP} and $DPRS_{XP}$ coefficients will be replaced by RPS_{XP} and accordingly the $T_{ct,RPS,XP}$ will be applied.

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,ts,ct,st,XP,g} \times \frac{(T_{ts,ct,HP,XP} + MP_{XP} \times T_{ct,MP,XP} + DPRS_{XP} \times T_{DPRS})}{N_y} \times SC_m \times NYM \times STM \right]$$

For Fix/Flex Transmission Services at a ~~Domestic Exit Point~~ Domestic Point *XP*, the Monthly Capacity Fee is the sum, for each Gas Day of the considered Month, of the terms that are the result of the following calculations:

- The quantity for ~~Grid User~~ Network User *g*, of Capacity Type *ct*, with Rate Type Fix/Flex (*ff*), at ~~Domestic Exit Point~~ Domestic Point *XP*, for Gas Day *d* ($MTSR_{d,ct,ff,XP,g}$);
- multiplied by the corresponding Regulated Tariff(s), taking into account the physical MP and DPRS characteristics¹⁸ of the considered ~~Domestic Exit Point~~ Domestic Point ($T_{ff,HP,XP}$, MP_{XP} , $T_{ct,MP,XP}$, $DPRS_{XP}$, T_{DPRS});
- divided by the number of Days in the considered Year (N_y);

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,ts,ct,ff,XP,g} \times \frac{(T_{ff,HP,XP} + MP_{XP} \times T_{ct,MP,XP} + DPRS_{XP} \times T_{DPRS})}{N_y} \right]$$

6.2.1.3 For Direct Line Services

The Yearly Monthly Capacity Fee for Direct Line Services for a Direct Line *dl* is calculated as the sum, for each Gas Day *d* of the considered Month *m*, of the terms that are the result of the following calculations:

- The direct line quantity for ~~Grid User~~ Network User *g*, of Capacity Type *ct*, with Rate Type yearly (*y*), at ~~Domestic Exit Point~~ Domestic Point *XP*, for Gas Day *d* ($MTSR_{d,dl,ct,y,XP,g}$);
- divided by the number of Days in the considered Year (N_y).
- multiplied by the sum of the following parameters:
 - the fix Direct Line Tariff ($T_{dl,ct}$),
 - the multiplication of the Distance of the Direct Line (D_{dl}) and the ~~D~~irect Line Distance Tariff ($T_{dl,d}$).

$$= \sum_{\text{all days } d \text{ of month } m} \left[\frac{MTSR_{d,dl,ct,y,XP,g} \times (T_{dl,ct} + D_{dl} \times T_{dl,d})}{N_y} \right]$$

The Seasonal Monthly Capacity Fee for Direct Line Services for a Direct Line dl is calculated as the sum, for each Gas Day³⁰ d of the considered Month m , of the terms that are the result of the following calculations:

- The direct line quantity of ~~Grid-User~~Network User g , of Capacity Type ct , with Rate Type seasonal (s), at ~~Domestic-Exit-Point~~Domestic Point XP , for Gas Day d ($MTSR_{d,dl,ct,s,XP,g}$).
- divided by the number of Days in the considered Year (N_y);
- multiplied by the Seasonal Coefficient of the considered month m (SC_m);
- multiplied by the Non-Yearly Multiplier (“NYM”) where NYM=1 until 31/12/2019 and included in the tariff sheet as from 01/01/2020
- multiplied by the sum of the following parameters:
 - the fix Direct Line Tariff ($T_{dl,ct}$),
 - the multiplication of de Distance of the Direct Line (D_{dl}) and the Direct Line Distance Tariff ($T_{dl,d}$).

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{d,dl,ct,s,XP,g} \times \frac{(T_{dl,ct} + D_{dl} \times T_{dl,d})}{N_y} \times SC_m \times NYM \right]$$

6.2.1.4 For Entry and Exit Services subject to a Wheeling

For Entry and Exit Services subject to a Wheeling, a Wheeling Tariff is charged instead of an Entry and an Exit Tariff.

The monthly Wheeling Fee is calculated as the sum, for each Gas Day d of the considered Month m , of the terms that are the result of the following calculations:

- The quantity of ~~Grid-User~~Network User g , for Entry at Interconnection Point $IP1$ and Exit at Interconnection Point $IP2$, for Gas Day d ($MTSR_{d,IP1,IP2,w,g}$);
- divided by the number of Days in the considered Year (N_y);
- multiplied by the Wheeling Tariff ($T_{IP1,IP2,w}$).

³⁰ From 2020 onwards and in line with NC TAR regulation, the Seasonal Monthly Capacity Fee for Direct Lines will be the result of a sum of each Gas Hour of the considered Gas Month as described in following formula.

$$= \sum_{\text{all hours } h \text{ of month } m} \left[MTSR_{h,dl,ct,s,XP,g} \times \frac{(T_{dl,ct} + D_{dl} \times T_{dl,d})}{N_{h,y}} \times SC_m \times NYM \right]$$

$$= \sum_{\text{all days of month } m} \left[\frac{MTSR_{d,IP1,IP2,w,g} \times T_{IP1,IP2,w}}{N_y} \right]$$

6.2.1.5 For Entry and Exit Services subject to an Operational Capacity Usage Commitment

For Entry and Exit Services subject to an Operational Capacity Usage Commitment, an OCUC Tariff is charged instead of an Entry and an Exit Tariff.

The monthly OCUC Fee is calculated as the sum, for each Gas Day d of the considered Month m , of the terms that are the result of the following calculations:

- The quantity of ~~Grid User~~Network User g , for Entry at Interconnection Point $IP1$ and Exit at Interconnection Point $IP2$, for Gas Day d ($MTSR_{d,IP1,IP2,ocuc,g}$);
- divided by the number of Days in the considered Year (N_y);
- multiplied by the OCUC Tariff ($T_{IP1,IP2,OCUC}$).

$$= \sum_{\text{all days of month } m} \left[\frac{MTSR_{d,IP1,IP2,ocuc,g} \times T_{IP1,IP2,OCUC}}{N_y} \right]$$

6.2.1.6 For Cross Border Delivery Services

As specified in the Regulated Tariffs, the applicable tariff for the implicit allocation of the Cross Border Delivery Service shall be approved by the regulator which is competent with regards to the associated Cross Border Capacity. The invoices sent to Fluxys Belgium by the Adjacent TSO which operates the Cross Border Capacity shall be invoiced “pass-through” to the ~~Grid User~~Network Users having implicitly allocated the associated Cross Border Delivery Service pro rata to their respective $MTSR_{cbds}$.

Any potential fee reduction granted to Fluxys Belgium by the Adjacent TSO which operates the Cross Border Capacity as a result of such Cross Border Capacity interruption or any other reason including Force Majeure shall be passed through pro rata to the interrupted part of $MTSR_{f,cbds}$.

6.2.2 Monthly Variable Flex Fee

The Monthly Variable Flex Fee ($MVFF_{g,XP,y,m}$) is only applicable on Transmission Services on End User ~~Domestic Exit Point~~Domestic Points XP with the Fix/Flex Rate Type. This fee is calculated by taking the difference between the Total Variable Flex Fee in year y up to and including month n ($TVFF_{g,XP,y,n}$) and the Total Variable Flex Fee in year y up to and including month $n-1$ ($TVFF_{g,XP,y,n-1}$) as follows:

$$MVFF_{g,XP,y,n} = TVFF_{g,XP,y,n} - TVFF_{g,XP,y,n-1}$$

The number of Running Hours of a ~~Domestic Exit Point~~ Domestic Point XP , of ~~Grid User~~ Network User g , in year y up to and including month n ($RH_{g,XP,y,n}$) is calculated as follows:

$$RH_{g,XP,y,n} = \frac{\sum_{\text{All months } m \in \{1, \dots, n\} \text{ in year } y} (\sum_{\text{All days } d \text{ of month } m} (\sum_{\text{All hours } h \text{ of day } d} -XEA'_{h,XP,g}))}{MTSR_{d,ff,XP,g}}$$

Based on the number of Running Hours up to and including month n ($RH_{g,XP,y,n}$), on the Regulated Tariff ($T_{flex,XP,1}$ and 2), on the subscribed capacities ($MTSR_{d,ff,XP,g}$) and on the GCV of the Zone in which the ~~Domestic Exit Point~~ Domestic Point is located ($CGCV_z$), the Total Variable Flex Fee up to and including month n ($TVFF_{g,XP,y,n}$) can be calculated as follows:

- For $RH_{g,XP,y,n} \leq RH-TRH$:

$$TVFF_{g,XP,y,n} = \frac{MTSR_{d,ff,XP,g}}{1000} * RH_{g,XP,y,n} * T_{flex,XP,1} * \frac{CGCV_{zone H}}{CGCV_z}$$

- For $RH-TRH < RH_{g,XP,y,n}$:

$$TVFF_{g,XP,y,n} = \frac{MTSR_{d,ff,y,XP,g}}{1000} * (RH-TRH * T_{flex,XP,1} + (RH_{g,XP,y,n} - RH-TRH) * T_{flex,XP,2}) * \frac{CGCV_{zone H}}{CGCV_z}$$

In case a pooling of capacity is facilitated under the Allocation Agreement in place on a ~~Domestic Exit Point~~ Domestic Point XP , the Capacity Responsible ~~Grid User~~ Network User (CRGU, as defined in the Allocation Agreement) has to pay the Monthly Variable Flex Fee for all Running Hours on this ~~Domestic Exit Point~~ Domestic Point XP . These Running Hours will be based on the sum of all Allocations and the sum of subscribed MTSR for all ~~Grid User~~ Network Users active on this ~~Domestic Exit Point~~ Domestic Point XP .

For the avoidance of doubt, in case of transfer of all rights and obligations except for the payment obligation of the Monthly Capacity Fee (assignment with retained payment obligation, as described in ACT – Attachment B), the MVFF remains due by the initial holder and will be calculated based on the sum of the Allocations of both the initial and final capacity holder.

6.2.3 Monthly Zee Platform Fee

The Monthly Zee Platform Fee for ~~Grid User~~ Network User g for Month m is a Fix Fee, in function of the number of Zee Platform Interconnection Points and/or Installation Point for which ~~Grid User~~ Network User has Zee Platform Services during the considered Month m .

6.2.4 Monthly Quality Conversion H->L Capacity Fee

6.2.4.1 Monthly Capacity Fee for Quality Conversion H->L

The Monthly Capacity Fee for the different H→L Quality Conversion Services qcs is calculated as the sum, for each Gas Day d of the considered Month m , of the terms that are the result of the following calculations:

- The quantity of the Quality Conversion H->L Service of ~~Grid-User~~Network User g , of Quality Conversion Service qcs of the Capacity Type ct , for Gas Day d ($MTRS_{d,QCH \rightarrow L,qcs,ct,g}$);
- divided by the number of Days in the considered Year (N_y).
- Multiplied by the Regulated Tariff ($T_{QCH \rightarrow L,qcs}$).

$$= \sum_{all\ qcs} \left[\sum_{all\ days\ d\ of\ mont\ m} [MTRS_{d,QCH \rightarrow L,qcs,ct,g}] * \frac{T_{QCH \rightarrow L,qcs}}{N_y} \right]$$

6.2.4.2 Monthly Variable Fee for Quality Conversion H->L

The Monthly Variable Fee for Peak Load pl Quality Conversion H->L Service is calculated as follows:

$$= \sum_{all\ days\ d\ of\ month\ m} \left(\frac{\sum_{All\ hours\ of\ day\ d} -XEA_{h,QCH \rightarrow L,pl}}{1000} \right) x T_{varQCH \rightarrow L,pl}$$

6.2.5 Monthly Capacity Fee for Quality Conversion L->H

The Monthly Capacity Fee for Quality Conversion L->H is calculated as the sum, for each Gas Day d of the considered Month m , of the terms that are the result of the following calculations:

- The quantity for Quality Conversion L->H for ~~Grid-User~~Network User g , for Gas Day d ($MTRS_{d,QCL \rightarrow H,g}$);
- divided by the number of Days in the considered Year (N_y)
- multiplied by the Regulated Tariff ($T_{QCL \rightarrow H}$).

$$= \sum_{all\ days\ d\ of\ month\ m} \left[MTRS_{d,QCL \rightarrow H,g} x \frac{T_{QCL \rightarrow H}}{N_y} \right]$$

6.2.6 Monthly Fee for implicitly allocated Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service

The Monthly Fee for implicitly allocated Transmission Service at the Zeebrugge Interconnection Point for Imbalance Transfer Service, for ~~Grid-User~~ Network User g for Month m is calculated as the sum, for each Gas Day of the considered Gas Month, of the terms that are the result of the following calculations:

- The quantity for ~~Grid-User~~ Network User g , of Transmission Service ts (entry or exit) of Capacity Type ct (firm), for Gas Day d ($MTSR_{ITSia,d,ts,ct,g}$)³¹;
- multiplied by the sum of:
 - the corresponding Regulated Tariff for IP Zeebrugge ($T_{ts,ct,IP}$), multiplied by the eventually applicable Seasonal Coefficient of the considered Month m (SC_m), multiplied by the Non-Yearly Multiplier (NYM) where NYM=1 until 31/12/2019 and is described in the Regulated Tariff as from 01/01/2020, and
 - the corresponding Regulated Tariff for implicit allocation of Transmission Services at the Zeebrugge Interconnection Point for Imbalance Transfer Service ($T_{ITS,shortfall}$ or $T_{ITS,excess}$),
 - divided by the number of Days in the considered Year (N_y)

$$= \sum_{\text{all days } d \text{ of month } m} \left[MTSR_{ITSia,d,entry,firm,g} \times \left(\frac{T_{entry,firm,Zeebrugge} \times SC_m \times NYM + T_{ITS,excess}}{N_y} \right) + MTSR_{ITSia,d,exit,firm,g} \times \left(\frac{T_{exit,firm,Zeebrugge} + T_{ITS,shortfall}}{N_y} \right) \right]$$

6.2.7 Monthly Energy In Cash Fee

The Monthly Energy In Cash Fee is applicable on all Connection Points, except for Zeebrugge and the Installation Point “QC” and is calculated as follows:

- the sum of the final Energy Allocations of the considered Gas Day ($EEA'_{d,g}$, $-XEA'_{d,g}$)³².
- multiplied by the Energy In Cash Tariff (T_{EIC}),
- multiplied by the Gas Price for Gas Day d (GP_d).

³¹ As specified in the Regulated Tariffs, for the Within Day Transmission Services, the highest hourly MTSR of the Gas Day is taken into account as $MTSR_d$.

³² Including Entry, Exit, Wheeling, Entry and Exit subject to Operational Capacity Usage Commitment, Zee Platform, and Direct Line.

$$= \sum_{\text{all days } d \text{ of month } m} \left[\left(\sum_{\text{All hours } h \text{ of day } d} EEA'_{h,g} \right) x T_{\text{EIC}} x GP_d \right] + \sum_{\text{all days } d \text{ of month } m} \left[\left(\sum_{\text{All hours } h \text{ of day } d} - XEA'_{h,g} \right) x T_{\text{EIC}} x GP_d \right]$$

6.2.8 Monthly Allocation Settlement Fees

The calculation of the Allocation Settlement Fees is described in Section 8 of this Attachment:

- Allocation Settlement ~~Grid User~~Network User Purchase ($ASGP_{d,z,g}$).

6.2.9 Monthly Transmission Imbalance Fees

The Monthly Transmission Imbalance Fees for the considered Month m consist of the settlement of the Transmission Imbalance for the following Services:

- Services submitted to an Operational Capacity Usage Commitment;
- Wheeling Services;
- Direct Line Services;
- Zee Platform Services.

These Services are normally balanced on an hourly basis, but there can be small differences, for example but not excluded to the matching process.

The Transmission Imbalance ($TI'_{h,g}$) for a ~~Grid User~~Network User g for a Hour h is the sum of all final Entry Allocations for the abovementioned Services increased by the final Exit Energy Allocations (negative values) for the abovementioned Services for the considered ~~Grid User~~Network User for the considered Hour.

The Monthly Transmission Imbalance Settlement Fee is calculated as, for each Gas Day d , the sum of the hourly Transmission Imbalances ($TI'_{h,g}$) for ~~Grid User~~Network User g multiplied by the Gas Price (GP_d) for the considered Gas Day.

$$= \sum_{\text{all days } d \text{ of month } m} \left[\sum_{\text{All hours } h \text{ of day } d} TI'_{h,g} x GP_d \right]$$

6.2.10 Monthly Odourisation Fees

The Monthly Odourisation Fee is applicable for ~~Domestic Exit Point~~Domestic Points other than Distribution ~~Domestic Exit Point~~Domestic Points, and is calculated by multiplying the odourisation coefficient of the considered ~~Domestic Exit Point~~Domestic Point (ODO_{XP}) by the sum of the final Domestic Exit Energy Allocations ($XEA'_{h,XP}$) of the considered ~~Domestic Exit Point~~Domestic Point for the considered Month and by the Regulated Tariff for Odourisation (T_{ODO}).

$$= \sum_{\text{all days } d \text{ of month } m} \left(\frac{\sum_{\text{All hours } h \text{ of day } d} - XEA'_{h,g,XP}}{1000} \right) \times ODO_{XP} \times T_{ODO}$$

6.2.11 Monthly Fix ZTP Trading Services Fee

6.2.11.1 Monthly Fixed fees for ZTP Trading Services Fee

The Monthly Fix ZTP Trading Services Fee, for ~~Grid User~~Network User *g* for Month *m*, is equal to the Regulated Tariff “ZTP Trading Services Monthly Fixed Fee”: T_{FixZTP} .

This tariff is charged only once per ~~Grid User~~Network User and per month independently of the number of ZTP Trading Services subscribed by ~~Grid User~~Network User (ZTP Physical Trading Services, ZTPL Notional Trading Services and/or ZTP Notional Trading Services).

6.2.11.2 Monthly Variable Fees for ZTP Trading Services and transactions

The Monthly Variable Fee for ZTP Trading Services is calculated as follows:

$$= \sum_{\text{all days } d \text{ of month } m} CE_{d,g} \times T_{VarZTP}$$

Where:

- $CE_{d,g}$ represents the confirmed energy (explicit or implicit – see Section [3.53.7](#)), in MWh, during day “*d*” on ZTP Services.
- T_{VarZTP} is the regulated variable tariff for ZTP Trading Services

6.2.12 Capacity Exceedings

The calculation of the following Capacity Exceedings is described in section [3.1.33.1.3](#):

- Peak Incentive for Exceeding of Entry Energy ($IEEE_{m,p,IP,g}$),
- Non-Peak Incentive for Exceeding of Entry Energy ($IEEE_{m,np,IP,g}$),
- Peak Incentive for Exceeding of Exit Energy ($IEXE_{m,p,IPorXP,g}$);
- Non-Peak Incentive for Exceeding of Exit Energy ($IEXE_{m,np,IPorXP,g}$)

6.2.13 Monthly Administrative Fees

- (i) Assignment on behalf of the ~~Grid User~~Network User:

In case the TSO assigns a Transmission Service on the Secondary Market on behalf of the ~~Grid User~~Network User, an administrative fee is due in accordance with the

Regulated Tariff “Transfer of capacity – Transaction realised by Fluxys Belgium on behalf of”.

(ii) Surrender of capacity:

In case a ~~Grid User~~Network User surrenders a Transmission Service, an administrative fee for the reallocated Transmission Services is due in accordance with the Regulated Tariff “Transfer of capacity – Transaction realised by Fluxys Belgium on behalf of”.

(iii) Cancellation of non-used capacity in case of congestion:

In case the TSO suspends a non-used capacity in case of congestion, based on a decision of the CREG as set out in Congestion Management (ACT - Attachment E), an administrative fee is charged for each cancellation for ~~Grid User~~Network User g , during Month m , as set out in the Regulated Tariffs.

(iv) Real time data delivery services on the Electronic Data Platform

In case ~~Grid User~~Network User has subscribed the real time data delivery services on the Electronic Data Platform, the fix monthly Regulated Tariff for this service is due, in accordance with the Regulated Tariffs.

~~(v) Reshuffling of capacity~~

~~In case a Grid User reshuffles a Transmission Service, an administrative fee is due for the effectively released Transmission Services in accordance with the Regulated Tariff “Transfer of capacity – Transaction transferred by Fluxys Belgium on behalf of”.~~

6.3 Monthly Self-billing Invoice

6.3.1.1 Monthly Allocation Settlement ~~Grid User~~Network User Sales Fees

The calculation of the Allocation Settlement Fees is described in section 5.2 of this Attachment:

- Allocation Settlement ~~Grid User~~Network User Sale ($ASGS_{d,z,g}$)