



TRANSMISSION PROGRAMME

Based on Article 112 of the Royal Decree of 23 December 2010 on the Code of Conduct regarding access to natural gas transmission networks

CONTENTS

CONTENTS	33
DISCLAIMER	65
1 INTRODUCTION	76
2 TRANSMISSION IN BELGIUM	87
2.1 PHYSICAL TRANSMISSION GRID IN BELGIUM	87
2.2 ORGANISATION OF THE BELGIAN GAS MARKET	98
2.3 MAIN CHARACTERISTICS OF THE COMMERCIAL MODEL	109
3 SERVICES OFFERED	1244
3.1 ENTRY AND EXIT SERVICES ON INTERCONNECTION POINTS AND INSTALLATION POINTS	1244
3.2 SERVICES AT DOMESTIC POINTS	1412
3.3 SHORT HAUL SERVICES	1715
3.4 GAS QUALITY CONVERSION SERVICE	1715
3.5 CROSS BORDER DELIVERY SERVICE.....	1916
3.6 ZTP TRADING SERVICES.....	1917
3.7 SUBSTITUTION SERVICES	2017
3.8 ANCILLARY SERVICES	2018
4 SERVICE SUBSCRIPTION AND ALLOCATION RULES	2248
4.1 PRIMARY MARKET	2248
4.2 TRADING CAPACITY ON THE SECONDARY MARKET	2823
5 OPERATING RULES	2924
5.1 NOMINATIONS.....	2924
5.2 METERING AND ALLOCATIONS.....	3025
5.3 DATA TRANSMISSION	3227
5.4 GAS QUALITY REQUIREMENTS	3227
6 BALANCING REGIME AND ALLOCATION SETTLEMENTS IN THE BELUX AREA	3328
7 INVOICING	3429
8 CONGESTION MANAGEMENT	3530
8.1 PROACTIVE CONGESTION MANAGEMENT POLICY	3530
8.2 CONGESTION MANAGEMENT PROCEDURE.....	3530
9 HOW TO CONTACT US	3732
NOTES	3833

CONTENTS	3
DISCLAIMER	5
1 INTRODUCTION	6
2 TRANSMISSION IN BELGIUM	7
2.1 PHYSICAL TRANSMISSION GRID IN BELGIUM	7
2.2 ORGANISATION OF THE BELGIAN GAS MARKET	8
2.3 MAIN CHARACTERISTICS OF THE COMMERCIAL MODEL	9
3 SERVICES OFFERED	11
3.1 ENTRY AND EXIT SERVICES ON INTERCONNECTION POINTS AND INSTALLATION POINTS	11
3.2 SERVICES AT DOMESTIC POINTS	13
3.3 SHORT HAUL SERVICES	16
3.3.1 WHEELING AND OPERATIONAL CAPACITY USAGE COMMITMENTS (OCUC)	16
3.3.2 ZEE PLATFORM SERVICE	16
3.4 GAS QUALITY CONVERSION SERVICE	16
3.4.2 GAS QUALITY CONVERSION SERVICE L → H	17
3.5 CROSS BORDER DELIVERY SERVICE	18
3.6 ZTP TRADING SERVICES	18
3.7 SUBSTITUTION SERVICES	19
3.7.1 CAPACITY CONVERSION SERVICE	19
3.7.2 L/H CAPACITY SWITCH SERVICE	19
3.7.3 DIVERSION SERVICE	19
3.8 ANCILLARY SERVICES	19
3.8.1 REAL TIME DATA MEASUREMENT SERVICE	19
4 SERVICE SUBSCRIPTION AND ALLOCATION RULES	21
4.1 PRIMARY MARKET	21
4.2 TRADING CAPACITY ON THE SECONDARY MARKET	27
5 OPERATING RULES	28
5.1 NOMINATIONS	28
5.2 METERING AND ALLOCATIONS	29
5.3 DATA TRANSMISSION	31
5.4 GAS QUALITY REQUIREMENTS	31
6 BALANCING REGIME AND ALLOCATION SETTLEMENTS IN THE BELUX AREA	32
7 INVOICING	33

8	CONGESTION MANAGEMENT	34
8.1	PROACTIVE CONGESTION MANAGEMENT POLICY	34
8.2	CONGESTION MANAGEMENT PROCEDURE	34
9	HOW TO CONTACT US	36
	NOTES	37

DISCLAIMER

This catalogue (the “transmission programme”) describes certain information regarding the transmission model and the related services offered by Fluxys Belgium. Please note that the transmission programme can be amended from time to time pursuant to the code of conduct (Royal Decree of 23.12.2010). In any case, Fluxys Belgium hereby disclaims any and all responsibility for any changes to the services described in the transmission programme which lies outside of its control. Such changes may be the result of inter alia financial and regulatory constraints defined by the relevant regulatory authority or may be imposed by the Belgian or European authorities.

In addition, the information in this transmission programme should not be construed as giving rise to any contractual relationship whatsoever between Fluxys Belgium (or any of its affiliated entities) and any interested party.



1 INTRODUCTION

Fluxys Belgium SA is the appointed independent operator of the natural gas transmission grid and storage infrastructure in Belgium (as per the Royal Decree of 23.02.2010). Fluxys LNG, its subsidiary, operates the Zeebrugge LNG terminal. The company has developed its infrastructure in Belgium into the crossroads for international gas flows in North-Western Europe.

Together with CREOS Luxembourg, the company established a cross-border market area – BeLux – and formed a joint venture Balansys to operate the balancing activities in the BeLux market area. General information on how the three companies are associated can be found in the BeLux Integrated Market Model document published on the Fluxys Belgium website.

Fluxys Belgium' gas transmission activities in Belgium, including tariff and balancing aspects, are regulated according to the Federal Act of 12 April 1965 on the transmission of gaseous and other products by pipelines (the Gas Act). This law is supplemented with guidelines on tariffs and by the Code of Conduct¹. Fluxys Belgium also abides by the 3rd European Energy Package and associated Network Codes. Her commercial model and services portfolio have been developed to take into account the obligations associated with these regulations².

This Transmission Programme describes the transmission services offered by Fluxys Belgium in accordance with the "Standard Transmission Agreement" (contractual terms and conditions), and the "Access Code" (access rules and procedures applicable in Belgium). These documents are developed by Fluxys Belgium in accordance with the code of conduct and, after consultation with the market, are approved by CREG the national regulatory authority of Belgium. These latest approved version of these documents, including the regulated tariffs in force in Belgium, can be found on the Fluxys Belgium website (<http://www.fluxys.com/belgium>).

This transmission programme is intended for information purposes and includes information that is set out in detail in the access code for transmission. Parties wishing to subscribe to the services described below may do so by signing the standard transmission agreement.

Detailed information related to the Loenhout storage facilities and Zeebrugge LNG terminal and their associated services can be found in the storage programme and LNG programme respectively, both available on the Fluxys Belgium website.


Balancing within the BeLux Area is harmonized and operated by Balansys, the Balancing Operator. Detailed information related to balancing can be found in the Balancing Programme.

¹ A code of conduct (Royal Decree of 23.12.2010) establishes the rules governing access to the transmission grid, storage facilities and LNG facilities

² Regulation (EC) No 715/2009 of the European Parliament and of the Council of 13 July 2009 on conditions for access to the natural gas transmission networks and repealing Regulation (EC) No 1775/2005

2 TRANSMISSION IN BELGIUM

2.1 Physical transmission grid in Belgium



The Fluxys Belgium transmission grid in Belgium has about 4,100 kilometres of pipelines and several physical connections, opening up the Belgian grid to natural gas flows from the United Kingdom, Norway, the Netherlands, Russia and all LNG producing countries. The Fluxys Belgium grid also serves as the crossroads for natural gas transmission flows to the Netherlands, Germany, Luxembourg, France, the United Kingdom and Southern Europe.

Pressure is required to move natural gas through a pipeline network. However, pressure gradually drops due to friction between the natural gas molecules and the pipe walls. The purpose of a compressor station is to maintain pressure in the network. Fluxys Belgium owns and operates 4 compressor stations spread over its transmission grid, located at Weelde, Winksele, Berneau, and Zelzate.


Two different types of natural gas are transported within the Fluxys Belgium grid: high-calorific natural gas (H gas or rich gas), and low-calorific natural gas (L gas or Slochteren gas). Each type of natural gas is transported via dedicated interconnection points and through specific subgrids (dedicated part of the Fluxys Belgium grid), which are operated independently. They are however connected by quality conversion facilities where gas can be transferred from one subgrid to the other, once the gas quality has been adjusted via mixing or nitrogen blending.

The Fluxys Belgium transmission grid is also connected to other facilities: the Loenhout underground storage facility operated by Fluxys Belgium, the Zeebrugge LNG terminal operated by Fluxys Belgium's subsidiary Fluxys LNG and the Dunkirk LNG Terminal, connected to the Fluxys Belgium's grid by means of cross border capacity, and operated by Dunkerque LNG.

The Loenhout underground storage facility is an aquifer storage for high calorific natural gas that combines seasonal storage for up to 700 MCM of workable volume with high flexibility of usage.

The Zeebrugge LNG terminal and the Dunkirk LNG terminal are used to load and unload ships carrying liquefied natural gas (LNG). LNG is temporarily kept in storage tanks at the facility as a buffer before regasifying the LNG and injecting it into the grid for transmission, or loading the LNG back onto LNG ships or trucks (in Zeebrugge LNG terminal only).

2.2 Organisation of the Belgian gas market



Many parties are active on the Belgian gas market. These parties fulfil one or more of the following roles.

Fluxys Belgium is the transmission system operator (TSO) that owns and operates the Belgian high-pressure natural gas transmission grid. Balansys is the balancing operator of the BeLux market area and offers balancing services to [grid user network users](#) active in the BeLux area.

A [grid user network user](#) is a company for which Fluxys Belgium transports gas within its high-pressure natural gas transmission grid, using transmission capacities contracted under terms and conditions set forth in the standard transmission agreement which is signed between the [grid user network user](#) and Fluxys Belgium.

A distribution network operator is a company that distributes natural gas at a lower pressure to final customers connected to its grid, including households and small and medium-sized enterprises. There are 17 distribution network operators in Belgium connected to the Fluxys Belgium grid through some 90 aggregated receiving stations.

A final customer is the ultimate consumer of the gas [and a producer can inject gas into the network](#). Final customers [and producers](#) can be directly connected to the Fluxys Belgium grid or connected to a distribution network. There are about 230 companies directly connected to Fluxys Belgium's natural gas transmission grid, referred to as 'end users'. They include industrial companies, cogeneration plants, power stations [and local gas producing plants \(such as biomethane or hydrogen\)](#). Terms and conditions ruling such physical connections are contractually set forth in the Connection Agreement. On the other hand households and small to medium-sized enterprises connected to a distribution network have no direct contractual relationship with Fluxys Belgium.


A trader is a party transferring title of gas within the Fluxys Belgium grid thanks to ZTP trading services (which can be either ZTP notional or ZTP physical trading services).

2.3 Main characteristics of the commercial model

2.3.1 An entry/exit model with an H-zone and an L-zone

The model under which Fluxys Belgium offers transmission services to grid user network users is an entry/exit model. Through this entry/exit model, natural gas enters the BeLux area at an interconnection connection point, and can either leave the transmission grid at another interconnection point or be consumed by a Belgian final customer at a domestic exit point, or be traded within the grid.

The transmission grid is divided into two entry/exit zones: the H-zone and the L-zone. The H-zone corresponds to the physical H-calorific subgrid and the L-zone to the physical L-calorific subgrid. Entry services enable a grid user network user to inject a quantity of natural gas at an interconnection point into the considered zone. Exit services enable the grid user network user to withdraw a quantity of natural gas at an interconnection point or at a domestic exit point from the zone in question. Section 3 contains more information on the entry and exit services.



An interconnection point is a type of connection point³ linking the Fluxys Belgium transmission grid with the transmission grid of an adjacent TSO.

An installation point is a type of connection point linking the Fluxys Belgium transmission grid with the transmission grid of an adjacent TSO or with an installation operated by Fluxys Belgium or one of its subsidiaries or with an installation connected to the Fluxys Belgium grid by means of a cross border capacity. Those connection points are the quality conversion facilities, the

³ A connection point is a physical or a virtual point on the transmission grid, as specified in the access code for transmission, at which grid user network users deliver natural gas to Fluxys Belgium for the performance of transmission services or at which Fluxys Belgium redelivers natural gas to grid user network users after having performed such transmission.

Loenhout storage facility, the LNG terminal in Zeebrugge and the LNG terminal in Dunkirk, ~~and are called installation points.~~

A ~~domestic exit point~~domestic point is a connection point connecting the Fluxys Belgium transmission grid to a final customer, either directly connecting an end user to the transmission grid (end user ~~domestic exit point~~domestic point), or via a distribution network (distribution ~~domestic exit point~~domestic point).

2.3.2 A model interconnecting the Northwest European market areas and Belgian final customers

The Fluxys Belgium transmission grid enjoys a high level of interconnectivity with adjacent transmission grids, offering extensive access to Northwest European market areas and production facilities.

~~As from 1 November 2018, and according to EU Commission Regulation 2017/459 (CAM NC), transmission system operators offer the available capacities at different Interconnection Points connecting the same two Entry/Exit systems at a Virtual Interconnection Point (VIP⁴). Since 4th December 2017, Fluxys Belgium operates a VIP with GRTgaz, between ZTP-H and PEG-Nord, named Virtualys which combines the former interconnection points Blaregnies Trott, Blaregnies Segeo and Atveringem.~~

Interconnection Points and installation points		Adjacent Operator / Market Area	
Interconnection points (H gas)	Virtualys ⁵	GRTgaz	PEG Nord
	Eynatten 1	Gascade	GasPool
	Eynatten 2	Open Grid Europe Thyssengas Fluxys TENP	NCG
	IZT	Interconnector UK	NBP ⁶
	's Gravenvoeren	GasunieTransportServices	TTF
	Zandvliet H		
	Zelzate 1		
	Zelzate 2	Zebra pijpleiding	-
	Zeebrugge	Fluxys Belgium	-
ZPT	Gassco	-	
Interconnection points (L gas)	Blaregnies L	GRTgaz	PEG Nord
	Hilvarenbeek L	GasunieTransportServices	TTF
Installation p <u>P</u> oints	Loenhout	Fluxys Belgium	
	Zeebrugge LNG Terminal	Fluxys LNG	
	Dunkirk LNG Terminal	Dunkerque LNG	
	QC - Quality Conversion	Fluxys Belgium	

⁴Virtual Interconnection Point (VIP) is in this CAM NC defined as "two or more Interconnection Points which connect the same two adjacent entry-exit systems, integrated together for the purposes of providing a single capacity service"

⁵Combining former Blaregnies Trott, Blaregnies Segeo and Atveringem.

⁶ IZT interconnection point connects to the National Grid's NBP through the undersea pipeline Interconnector IUK.

3 SERVICES OFFERED

Entry and Exit Capacity services are available in various capacity types and can be subscribed independently:

- Firm (F) capacity is always available and usable under normal operating conditions⁷.
- Interruptible (I) capacity means that Fluxys Belgium can interrupt the service due to physical restrictions on its transmission grid.
- Backhaul (BH) capacity is offered at unidirectional **inter**connection points, in the opposite direction of the physical gas flow direction and is usable as long as the resulting physical flow remains in the physical direction of the **inter**connection point.

3.1 Entry and exit services on interconnection points and installation points

Entry services are services enabling natural gas to be injected into a zone of the transmission grid at an interconnection point or installation point. Exit services are services enabling natural gas to be withdrawn from a zone of the transmission grid at an interconnection point or installation point.

The table below shows the services offered at **att** interconnection points and installation points.

<u>Interconnection Points and installation points</u>		Entry service			Exit service		
		F	BH	I	F	BH	I
Interconnection points (H gas)	Eynatten 1	X		0	X		0
	Eynatten 2	X		0	X		0
	IZT	X		0	X		0
	's Gravenvoeren	X		0		X	
	Virtualys	X	X**	0	X		0
	Zandvliet H	X		0		X	
	Zeebrugge	X		0	X		0
	Zelzate 1	X		0	X		0
	Zelzate 2		X		X		0
	ZPT	X		0		X	
Interconnection points (L gas)	Blaregnies L		X		X		0
	Hilvarenbeek L	X		0		X	
Installation Points	Loenhout	X		X** ⁸	X		X*
	Zeebrugge LNG Terminal	X				X	
	Dunkirk LNG Terminal ⁹	X					

- X = Service is offered and can be contracted within indicative availabilities as published on the Fluxys Belgium website
- X* = Operational interruptible capacity that corresponds to capacities that Fluxys Belgium has secured for the operation of the transmission grid and that are made available to **grid user network users** on an interruptible basis.
- X** = Only for contracts concluded before 30 November 2017.
- 0 = Service is optionally offered, depending on firm availability.
- ~~Installation points are considered to be a specific type of interconnection point.~~

⁷ Which are subject to the terms and conditions of the standard transmission agreement.

⁸ ~~Operational interruptible capacity that corresponds to capacities that Fluxys Belgium has secured for the operation of the transmission grid and that are made available to grid user network users on an interruptible basis.~~

⁹ With the subscription of Dunkirk LNG Terminal the associated Cross Border Delivery Service will be implicitly allocated meaning that they are matched in quantity, time and Capacity Type as described in ACT – Attachment A.

3.1.1 Definition of the service offer at interconnection points and installation points

As long as firm (or backhaul) transmission services are available at an interconnection point or LNG Terminal installation point, only firm (or backhaul) transmission services are offered at this interconnection point or installation point, which are allocated as requested or via auctions, as detailed in section 4.1.

Subscribed firm transmission services are, subject to the terms and conditions of the standard transmission agreement, always usable under normal operating conditions. Furthermore, subscribed Entry and Exit transmission services are usable independently of each other¹⁸.

For unidirectional ~~inter~~interconnection points and installation points, only backhaul services are offered in the reverse direction.

Backhaul capacity is usable on selected ~~inter~~interconnection points and installation points as long as the resulting physical flow remains in the physical direction of such unidirectional ~~inter~~interconnection point or installation point.

Interruptible services are offered at an interconnection point or installation point, when firm transmission services are available in limited quantity over such a period. The offered quantities are calculated such that the probability of interruption based on historical data does not exceed **105%**. This probability is based on historical data and only serves as an indication, without giving any guarantee as to the probability of interruption for the future.

Interruptible services can be interrupted by Fluxys Belgium if the requested quantities exceed the physical capabilities.

~~For unidirectional interconnection points, only backhaul services are offered in the reverse direction.~~

Operational interruptible capacity is offered at the Loenhout installation point, where Fluxys Belgium has secured capacities for the operation of the transmission grid. In order to maximise the service offer, such operational capacities are made available to grid user network users on an interruptible basis. This service is offered in addition to firm capacity. These firm and operational interruptible services are implicitly allocated by Fluxys Belgium to grid user network users according to the subscribed storage services with Fluxys Belgium at the Loenhout underground storage facility.

Operational interruptible capacity offered at the Loenhout installation point can be interrupted by Fluxys Belgium in case such capacity is needed to operate the transmission grid.

~~The H→L quality conversion service is the ability to convert H-gas from the H-zone in L-gas for the L-zone. The capacity type can be firm or interruptible. The L→H quality conversion service consists of the ability to convert L gas from the L-zone in H-gas for the H-zone. The capacity type is interruptible.~~

¹⁸~~With the exception of Wheeling Services and Operational Capacity Usage Commitments as described in section 3.3~~

3.1.2—Availability for use of each service

~~Subscribed firm transmission services are, subject to the terms and conditions of the standard transmission agreement, always usable under normal operating conditions. Furthermore, subscribed Entry and Exit transmission services are usable independently of each other**:~~

~~Interruptible services can be interrupted by Fluxys Belgium if the requested quantities exceed the physical capabilities:~~

~~Operational interruptible capacity offered at the Loenhout installation point can be interrupted by Fluxys Belgium in case such capacity is needed to operate the transmission grid:~~

~~Backhaul capacity is usable on selected interconnection points as long as the resulting physical flow remains in the physical direction of such unidirectional interconnection point:~~

3.1.3.1.2 Rate type for ~~interconnection~~ interconnection points and installation points

Two types of rates apply for entry service at an interconnection point and installation point, depending on the duration of the booked service. If the service period is equal to one calendar year or any multiple of calendar years, the yearly rate type will apply. In other cases (less than one calendar year), a seasonal rate type will apply in proportion to the number of days of the booking. For an exit service at an interconnection point and installation point with any service duration, the yearly rate type applies.

This is summarized in the following table:

Capacity services	Service period	Rate type
Entry services	= 1 year or multiple of 12 calendar months(*)	Yearly
	1 month >= x < 1 year	Seasonal
	< 1 month	
Exit services	All service periods	Yearly

3.2 Services at ~~domestic exit point~~ domestic points

Domestic ~~exit~~ services are services enabling natural gas to be withdrawn from or injected to a zone of the transmission grid at a ~~domestic exit point~~ domestic point.

	Connection Point	Firm	Backhaul	Interruptible
<u>Entry services</u>	End User Domestic Exit Point Domestic point	X	=	0
	Distribution Exit Point Domestic point	X	=	-
<u>Exit services</u>	End User Domestic point	X		-
	Distribution Domestic point		X	-

**With the exception of Wheeling Services and Operational Capacity Usage Commitments as described in section 3.3

3.2.1 Exit service and entry service offer at a domestic exit pointdomestic point

For end user domestic exit pointdomestic points, i.e. connection points between the Fluxys Belgium transmission grid and end users' facilities, exit services and/or entry services have to be subscribed by the grid usernetwork user. As long as firm exit or entry services are available at an end user domestic exit pointdomestic point, only firm exit or injection transmission services are offered, which are allocated as requested. These services are offered with high pressure, medium pressure and DPRS (pressure reduction at domestic exit pointdomestic point) parameters¹², if applicable, taking into account the physical characteristics of the end user domestic exit pointdomestic point. For more details on those services, please refer to Section 3.2.4.

If no (or no more) firm transmission services can be offered at an end user domestic exit pointdomestic point, interruptible transmission services can be offered upon consultation with, and agreement of, the end user in question in accordance with the access code for transmission and the connection agreement.

For domestic exit capacity to/from distribution networks, there is no explicit subscription of exit or entry services by the grid usernetwork user. The peak capacity is calculated based on inter alia the methodology agreed with the distribution network operators. Fluxys Belgium implicitly allocates this peak capacity on a monthly basis to grid usernetwork users based on their market share of final customers within each distribution network, taking into account the different producers and final customers profile segmentations.

3.2.2 Availability for use of each exit or entry service

Subscribed firm transmission services are, subject to the terms and conditions of the standard transmission agreement, always usable under normal operating conditions.

Subscribed interruptible transmission services can be interrupted by Fluxys Belgium if the quantities requested to be transported exceed the physical capabilities of the transmission network.

3.2.3 Rate type for domestic exit pointdomestic points

For exit and entry services at end user domestic exit pointdomestic points, four rate types apply, depending on the service period of the booked service. If the service period is equal to one calendar year or any multiple of calendar years (beginning on any date), the yearly rate type will apply. Alternatively the Fix/Flex rate type can apply on exit services if such rate type is requested by all grid usernetwork users active on a given end user domestic exit pointdomestic point for a period equal to one or more calendar years, starting on January, 1st. For a service period which is between 1 or 12 calendar months, the seasonal rate type will apply in proportion to the number of days of the booking. For service with a service period of less than one calendar month, the short term rate type will apply.

¹² From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the reduced pressure service (RPS). This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits.

For exit and entry services at distribution ~~domestic exit point~~domestic points (towards/from the distribution network) that are allocated by the TSO, the rate type is always yearly.

Capacity services	Service period	Rate type
Exit services at End User Domestic Exit Point <u>Domestic point</u>	= 1 year of a multiple of 12 calendar months	Yearly
		Fix/Flex
	1 month $\geq x < 1$ year	Seasonal
	< 1 month	Short term
<u>Entry services at End User</u> <u>Domestic point</u>	<u>year</u>	<u>Yearly</u>
Exit services at Distribution Domestic Exit Point <u>Domestic point</u>	All service periods	Yearly
<u>Entry services at Distribution</u> <u>Domestic point</u>	<u>year</u>	<u>Yearly</u>

The capacity fee under the Fix/Flex rate type consists of a Fix component and a Flex component:

- The Fix component depends on the booked capacity, covering the peak requirements for the considered End User.
- The Flex component depends on the actual usage of the capacity, expressed in running hours (running hours being the allocated quantities divided by the booked capacities).

The Fix/Flex rate type is only available on high pressure firm exit services or end user domestic point and cannot be combined with the yearly, seasonal or short term rate type or further subscriptions.

During the start-up and commissioning process, Fluxys Belgium will apply the yearly rate type for a maximum of 6 months if capacity requirements are not on regular basis.

3.2.4 Specific services at the ~~domestic exit point~~domestic point

At ~~domestic exit point~~domestic points, the exit transmission services always include the high pressure exit service and may include one or more of the following :

- Via the medium pressure service, Fluxys Belgium transports the gas to a ~~domestic exit point~~domestic point via a medium pressure network. ~~(*)~~
- Via the dedicated pressure reduction station service, Fluxys Belgium reduces the pressure at a ~~domestic exit point~~domestic point within the contractual minimum and maximum pressure limits¹³. ~~(*)~~
- Odourisation consists of Fluxys Belgium injecting an odorant in gas at ~~domestic exit point~~domestic points where an odourisation facility is operated by Fluxys Belgium.

When a grid user~~network user~~ subscribes to exit capacity services for a ~~domestic exit point~~domestic point (or is implicitly allocated such services in the case of distribution) connected to the medium pressure network, equipped with a pressure reduction facility or equipped with

¹³ From 2020 onwards, the medium pressure and Dedicated Pressure Reduction Station service will be replaced by the reduced pressure service (RPS). This service will reduce the pressure at a Domestic Point within the contractual minimum and maximum pressure limits.

an odorisation facility, the corresponding services of medium pressure, dedicated pressure reduction station or odorisation are automatically applicable.

~~Domestic point~~ For two specific case of end users located in Belgium but near a border and directly connected to the transmission grid of an adjacent TSO or to the grid of a foreign distribution network operator, the service allowing this is the dedicated direct line service.

3.3 Short haul Services

~~3.2.53.3.1~~ Wheeling and Operational capacity usage commitments (OCUC)

A wheeling allows the direct transmission of natural gas between two interconnection points located within the same border station without entering the entry/exit zone of the transmission grid. Wheelings do not give access either to other entry/exit points of the transmission grid nor to the ZTP notional trading services (ZTP & ZTPL). Under a wheeling, the quantity of entering gas must be equal, on an hourly basis, to the quantity of exiting gas.

Wheelings are available between the following interconnection points:

- Between Eynatten 1 and Eynatten 2, and between Eynatten 2 and Eynatten 1
- Between Zelzate 1 and Zelzate 2, and between Zelzate 2 and Zelzate 1

OCUCs are operational agreements between a ~~grid user~~ network user and Fluxys Belgium consisting of a commitment regarding the combined use of a well-defined entry service at an interconnection point or installation point with a well-defined exit service at another interconnection point or installation point, without access to the market-based balancing model or to ZTP notional trading services. As a proactive measure, Fluxys Belgium determines in advance the eligible entry and exit service that can avoid a bottleneck in the transmission grid, and which are currently the following combinations:

- Entry Eynatten 1 or Eynatten 2, with Exit 's Gravenvoeren
- Entry 's Gravenvoeren, with Exit Eynatten 1 or Eynatten 2
- Entry Zelzate 1 or Zelzate 2, with Exit IZT or Zeebrugge
- Entry IZT or Zeebrugge, with Exit Zelzate 1 or Zelzate 2
- Entry Dunkirk LNG Terminal or Virtualys with Exit IZT or Zeebrugge

~~3.2.63.3.2~~ Zee platform service

The aim of the Zee Platform Service is to facilitate transfers of gas in the Zeebrugge area between IZT, ZPT, ~~Zeebrugge LNG Terminal and~~ Zeebrugge interconnection points and Zeebrugge LNG Terminal installation point. The Zee Platform Service enables ~~grid user~~ network users to transfer natural gas between two or more (at the ~~grid user~~ network user's choice) of these points without explicit capacity reservation and without any capacity limitation.

Zee Platform transfers are firm, except transfers to ZPT and Zeebrugge LNG Terminal which are backhaul, as ZPT and Zeebrugge LNG Terminal are unidirectional ~~inter~~ connection points. Furthermore, transfers to IZT and Zeebrugge are subject to compliance with UK gas quality requirements.

The Zee Platform service does not give access either to the entry/exit zone of the transmission grid nor to the ZTP notional trading services (ZTP & ZTPL). Under the Zee Platform, the quantity of entering gas must be equal, on an hourly basis, to the quantity of exiting gas.

~~3.33.4~~ Gas quality conversion service

As explained above, the Fluxys Belgium grid is composed of 2 independent subgrids which correspond to two entry-exit zones: H-zone and L-zone. The conversion facilities enable rich gas

(H gas) to be converted into Slochteren gas (L gas) or the other way around, combined as a single “virtual” installation point Quality Conversion H/L.

3.3.13.4.1 Gas quality conversion service H → L

The quality conversion services H→L enable the transportation of H gas into the L gas zone.

Different quality conversion services H→L exist, namely “peak load”, “base load” and “seasonal load”; each with a different tariff structure and different specifications regarding availability of the capacity. The peak load conversion service H→L can only be used from 1st November to 31 March and at cold temperatures. Peak load conversion services is sold in bundles with a part in firm capacity and a part in interruptible capacity. These features make the peak load serving a perfect insurance system to cover increased demand for L gas with H gas at a peak during the cold winter. The H→L base and seasonal load quality conversion services can be used during the whole contract year and are therefore suitable, for example, just for supplying an end customer L gas in with H gas.

These quality conversion services are first sold through an annual subscription window for periods of one or more gas years for the peak load and for periods of one gas year for base load and seasonal load. During the subscription window requests are allocated in proportion to the requested quantities with priority to the longest period. Upon closing of this subscription window any remaining quantities can be allocated as requested subject to explicit prior confirmation by Fluxys Belgium of available necessary logistics contracts and in so far the request covers the remaining period up to 30 September of the next year.

The use of H→L gas quality conversion service does not require the grid user/network user to subscribe to entry or exit services in the L or H-zone respectively.

The part of the subscribed capacity that can actually be used or real capacity of the peak load conversion service (H→L) is dependent on the temperature, the date and the Wobbe of the L-gas. A part of the peak load bundle is also offered on interruptible basis. The real capacity of the seasonal load conversion service depends on the period. Base load conversion capacity is available year round. All conversion capacities are however subject to any necessary maintenance works. This is described in detail in Annex C.3 of the Access Code for Transmission.

3.3.23.4.2 Gas quality conversion service L → H

The quality conversion service L→H service enables the transportation of L gas into the H gas zone. This service is available on an interruptible basis. The use of gas quality conversion service L→H doesn't require the grid user/network user to subscribe to entry or exit services in the H or L-zone respectively.

Gas quality conversion services L→H are allocated as requested¹⁴ for as long as they are available and with a minimum period of one gas day.

~~These quality conversion services are sold on an annual basis for periods of one gas year. The services are offered through a subscription window in which requests covering the upcoming gas year are allocated in proportion to the requested quantities. Upon closing of this subscription window any remaining quantities are allocated as requested provided the requested period is a minimum of one week gas day and does not exceed the end of the gas~~

¹⁴ The possibility to use PRISMA to subscribe gas quality conversion service L→H on a “First-Committed-First-Services” is being developed. The start date will be confirmed by Fluxys Belgium at least 4 weeks in advance..

~~year. The details of such a subscription window are described in the access code for transmission.~~

~~3.43.5~~ Cross Border Delivery Service

The cross border delivery service is a service that enables the transportation of natural gas between an interconnection point or an installation point located on an adjacent transmission system operator's grid and the transmission system of Fluxys Belgium. A cross border delivery service offered on an interconnection point or an installation point is always offered together with other transmission services available on such interconnection point or installation point. The tariff of the respective transmission system operator shall be applicable for the cross border delivery service, as set out in the regulated tariffs.

~~3.53.6~~ ZTP Trading Services

Fluxys Belgium offers (physical and notional) ZTP trading services enabling grid user network users to exchange title of gas through either notional or physical services. The ZTP trading services include title tracking, nomination, matching, balance check, confirmation and imbalance transfer services. The details on these services are described in the access code for transmission.

~~3.5.13.6.1~~ Imbalance transfer service

The imbalance transfer service ensures that net confirmed title transfers for ZTP physical trading services are automatically transferred to/from the grid user network user balancing position. The transmission capacities at the interconnection point Zeebrugge required to perform such transfer are eventually implicitly allocated.

The implicit allocation mechanism is based on the hourly quantities transferred under the imbalance transfer service, insofar the grid user network user does not hold in its portfolio sufficient unused (e.g. non nominated) transmission services¹⁵ to realize the transfer. The implicit allocation – if any – results in a subscribed within-day transmission service (entry or exit - always till the end of the gas day).

This service is part of the trading services and must not be subscribed by grid user network users. It is performed by the TSO for each grid user network user using the ZTP physical trading service, as long as firm transmission services are available on Zeebrugge, IZT, Zeebrugge LNG Terminal and ZPT in the same direction.

~~3.5.23.6.2~~ Imbalance pooling service

The imbalance pooling service allows grid user network users to pool their hourly net confirmed title transfer for ZTP physical trading services by transferring the hourly net confirmed title transfer for ZTP physical trading services from one grid user network user to another.

The pooling of the hourly net confirmed title transfer for ZTP physical trading services implies a transfer grid user network users need to agree upon before the start of the imbalance pooling service by means of an imbalance pooling form. The imbalance pooling service is based on the designation of a role between two grid user network users, where for one grid user network user known as the imbalance transferor, its hourly net confirmed title transfer for ZTP physical

¹⁵ The entry or exit services taken into account for the calculation of such implicit allocation are the hourly subscribed transmission services at interconnection points IZT, ~~Zeebrugge LNG Terminal, ZPT, and Zeebrugge and Zeebrugge LNG Terminal installation point~~, including the implicitly allocated transmission services at Zeebrugge till the end of the same gas day under the imbalance transfer service for (a) previous hour(s) of the same gas day.

trading services is automatically transferred to another grid user/network user also known as the imbalance transferee, as detailed in the access code for transmission.

3.6.3.7 Substitution services

3.6.3.7.1 Capacity conversion service

The capacity conversion service enables grid user/network users holding unbundled capacity at one side of an interconnection point to convert this capacity into bundled capacity. This service is offered free of extra charge according to the conditions set forth in the access code for transmission.

~~3.6.2—Reshuffling service~~

~~The reshuffling service, offered once in 2018 prior to the yearly auctions on PRISMA, enables grid user/network users holding long term unbundled entry or exit capacity at an interconnection point to convert (part of) that capacity into (un)bundled capacity at another Interconnection Point in accordance with the conditions set forth in the access code for transmission.~~

3.6.3.7.2 L/H capacity switch service

In the framework of the physical conversion of the L-gas network into the H gas network, the L/H capacity switch service, offered once a year prior to the yearly auctions on PRISMA, enables grid user/network users holding unbundled entry capacity at an L-gas interconnection point to convert (part of) that capacity into (un)bundled capacity at an H-gas interconnection point or installation point in accordance with the conditions set forth in the access code for transmission.

3.6.3.7.3 Diversion service

The diversion service, ~~offered prior to all monthly, quarterly and yearly auctions on PRISMA,~~ enables grid user/network users holding unbundled entry or exit capacity at specific interconnection points or installation point to transfer (part of) that capacity to another interconnection point or installation point at the same grid location in accordance with the conditions set forth in the access code for transmission.

3.8 Ancillary services

3.8.1 Real-time data measurement service

~~The TSO offers a real-time data service which can additionally be subscribed by network users and which provides them with on-line gas flow data (updated every 6 minutes) for selected interconnection points and installation points, privately available on the Electronic Data Platform.~~



|

4 SERVICE SUBSCRIPTION AND ALLOCATION RULES

4.1 Primary market

In order to subscribe and use transmission services, a party must first register as a **grid user/network user**, as set out in the code of conduct, which entails signing the standard transmission agreement. The standard transmission agreement is concluded for an indefinite period and service confirmation forms are the legal and contractual form that confirms the subscribed services under this agreement.

Transmission service are offered as follow:

SERVICES		Sales Channel ¹⁶	Allocation method	Duration ¹⁷
Entry and Exit Services on ITPs, VTPs & LNG Terminals	Blaregnies L	PRISMA	Auction	Y, Q, M, DA, WD
	Eynatten 1			
	Eynatten 2			
	Hilvarenbeek L			
	IZT			
	's Gravenvoeren			
	Virtuatys		FCFS	Any duration
	Zandvliet H			
	Zetzate 1			
	Zeebrugge ¹⁸			
	Zetzate 2			
	ZPT			
	Zeebrugge LNG Terminal			
Dunkirk LNG Terminal ¹⁹				
Capacity Conversion Service (unbundled to bundled)			Y, Q, M, DA	
Conversion into Short haul Services (OCUC and Wheeling) ²⁰			Y, Q, M, DA ²¹	

¹⁶ Written procedure can be activated by the TSO as fall-back mechanism, should EBS or PRISMA platforms be unavailable.

¹⁷ (Y)= Yearly, (Q)= Quarterly, (M)= Monthly, (DA)= Day-Ahead, (WD)= Within-Day, (B-o-Y)= Balance of Gas Year, (GD)= Gas Day.

¹⁸ Implicit allocation of Transmission Services at Zeebrugge also possible in the framework of the Imbalance Transfer Service.

¹⁹ With the subscription of Dunkirk LNG Terminal entry capacity the associated Cross Border Delivery Service will be implicitly allocated meaning that they are matched in quantity, time and Capacity Type as described in ACT – Attachment A. No capacity will be allocable for a service period shorter than 1 gas day.

²⁰ The possibility to use PRISMA to request conversion of Entry and Exit services into OCUCs or Wheelings is being developed. The start date will be confirmed by the TSO at least 4 weeks in advance. Until then, the procedure remains manual.

²¹ Except for Short haul Services Wheeling and OCUC for which both Interconnection Points are sold via FCFS, the conversion into Short haul Services can be done for a Service Period of any duration. For Dunkirk LNG where OCUC are offered associated with a Cross Border Delivery Service for the same Service Period which can be shorter than for monthly capacities.

Quality Conversion Service H→L ²²		Written only	Pro-rata and FCFS	Multi-Y, Y and B-o-Y
Quality Conversion Service L→H ²³		EBS or written PRISMA	Pro-rata and FCFS	Multi-Y, Y and min 1 GD
Entry and Exit Services on Loenhout		Implicit		Not applicable
Exit Service for End Users Domestic Exit Point Domestic point ²⁴		EBS/PRISMA	FCFS	Any duration min 1 GD
Exit Service for Distribution Domestic Exit Point Domestic point		Implicit		Not applicable
Entry Service for End Users Domestic point		PRISMA	FCFS	year
Entry Service for Distribution Domestic point		Implicit		Not applicable
Other Services	Zee Platform	Written only	Not applicable	Not applicable
	ZTP Trading Services			
	Imbalance Pooling Service			
	L/H Capacity Switch Service			
	Reshuffling Service/Diversion Service ²⁵			

Sales channel ²⁶	Allocation method	SERVICES	Duration ²⁷
PRISMA	Auction	Blaregnies L	Y, Q, M, DA, WD
		Eynatten 1	
		Eynatten 2	
		Hilvarenbeek L	

²² First subscription window (written only), for which Year and/or Multi-Year products are allocated pro-rata request (Base and Seasonal), with a priority for longest period for Peak product. After subscription window (written only) Balance of Gas Year products are allocated via FCFS principle and are subject to availability and to the required logistics (e.g. with nitrogen suppliers)

²³ The possibility to use PRISMA to subscribe gas quality conversion service L→H on a "First-Committed-First-Services" is being developed. The start date will be confirmed by Fluxys Belgium the TSO at least 4 weeks in advance. Until then, the procedure remains manual which means that for the first subscription window (written only), for which Year and Multi-Year products are allocated, allocation pro-rata request with priority to longest period. After subscription window (written + EBS) products of any duration with a minimum duration of 1 Gas Day are allocated via FCFS allocation and requested via EBS or written request

²⁴ The possibility to use PRISMA to subscribe exit services for end users domestic points on a "First-Committed-First-Services" is being developed. The start date will be confirmed by the TSO at least 4 weeks in advance. Until then, exit services for end users domestic points can be subscribed using the EBS.

²⁵ The possibility to use PRISMA to subscribe Diversion Service is being developed. The start date will be confirmed by the TSO at least 4 weeks in advance. Until then, the procedure to subscribe Diversion Service remains manual.

²⁶ Written procedure can be activated by Fluxys Belgium as fall-back mechanism, should PRISMA or EBS platforms be unavailable. Entry and Exit Services on IPs, VIPs and LNG Terminals, Quality Conversion Services and on Domestic Points can also be implicitly allocated by Fluxys Belgium to network users in case overnomination is being activated for such Connection Point. Overnomination will be activated when all Firm Transmission Services are sold after the Firm Day-Ahead auction and after the Interruptible Day Ahead auction if any or as a fall-back mechanism when PRISMA platform should be unavailable.

²⁷ (Y)= Yearly, (Q)= Quarterly, (M)= Monthly, (DA)= Day-Ahead, (WD)= Within-Day, (B-o-Y)= Balance of Gas Year, (GD)= Gas Day.

	FCFS		<u>IZT</u>	<u>Any duration</u>
			<u>'s Gravenvoeren</u>	
			<u>Virtualys</u>	
			<u>Zandvliet H</u>	
			<u>Zelzate 1</u>	
			<u>Zeebrugge²⁸</u>	
			<u>Zelzate 2</u>	
			<u>ZPT</u>	
			<u>Zeebrugge LNG Terminal</u>	
			<u>Dunkirk LNG Terminal²⁹</u>	
			<u>Capacity Conversion Service (unbundled to bundled)</u>	<u>Y, Q, M, DA</u>
			<u>Conversion into Short haul Services (OCUC and Wheeling)</u>	<u>Y, Q, M, DA³⁰</u>
			<u>Quality Conversion Service L→H³¹</u>	<u>Min 1 GD</u>
			<u>Exit Service for End Users Domestic point³²</u>	<u>Min 1 GD</u>
			<u>Entry Service for End Users Domestic point</u>	<u>Y</u>
<u>Implicit</u>			<u>Entry and Exit Services on Loenhout</u>	<u>Any duration</u>
			<u>Exit Service for Distribution Domestic point</u>	<u>Any duration</u>
			<u>Entry Service for Distribution Domestic point</u>	<u>Y</u>
<u>Written only</u>	<u>Pro rata and FCFS</u>		<u>Quality Conversion Service H→L³³</u>	<u>Multi Y, Y and B-o-Y</u>
	<u>Not applicable</u>		<u>Other Services</u>	<u>Not applicable</u>
		<u>Zee Platform</u>		
		<u>ZTP Trading Services</u>		
		<u>Imbalance Pooling Service</u>		
		<u>L/H Capacity Switch Service</u>		
		<u>Diversion Service³⁴</u>		

Services on interconnection points offered on the PRISMA^{Arisma} capacity booking platform (www.prisma-capacity.eu) can be subscribed via auction³⁵ on a first-committed-first served

²⁸ Implicit allocation of Transmission Services at Zeebrugge also possible in the framework of the Imbalance Transfer Service.

²⁹ With the subscription of Dunkirk LNG Terminal entry capacity the associated Cross Border Delivery Service will be implicitly allocated meaning that they are matched in quantity, time and Capacity Type as described in ACT – Attachment A. No capacity will be allocable for a service period shorter than 1 gas day.

³⁰ Except for Short haul Services Wheeling and OCUC for which both Interconnection Points are sold via FCFS, the conversion into Short haul Services can be done for a Service Period of any duration. For Dunkirk LNG where OCUC are offered associated with a Cross Border Delivery Service for the same Service Period which can be shorter than for monthly capacities.

³¹ The possibility to use PRISMA to subscribe gas quality conversion service L→H on a “First-Committed-First-Services” is being developed. The start date will be confirmed by Fluxys Belgium at least 4 weeks in advance. Until then, products of any duration with a minimum duration of 1 Gas Day are allocated via FCFS allocation and can be requested via EBS or written request.

³² The possibility to use PRISMA to subscribe exit services for end users domestic points on a “First-Committed-First-Services” is being developed. The start date will be confirmed by Fluxys Belgium at least 4 weeks in advance. Until then, exit services for end users domestic points can be subscribed using EBS.

³³ First subscription window (written only), for which Year and/or Multi-Year products are allocated pro rata request (Base and Seasonal), with a priority for longest period for Peak product. After subscription window (written only) Balance of Gas Year products are allocated via FCFS principle and are subject to availability and to the required logistics (e.g. with nitrogen suppliers)

³⁴ The possibility to use PRISMA to subscribe Diversion Service is being developed. The start date will be confirmed by the TSO at least 4 weeks in advance. Until then, the procedure to subscribe Diversion Service remains manual.

basis or by converting already subscribed entry and exit services into a Wheeling or OCUCor PRISMA³⁶ (www.prisma-capacity.eu). Other services described in this brochure can be subscribed at Fluxys Belgium either in writing (letter, ~~fax~~ or email), using a transmission service request form (the templates are available on the Fluxys Belgium website), or by on-line booking, using an Internet-based electronic booking system accessible via the Fluxys Belgium website (www.fluxys.com/belgium) or via an implicit allocation.

4.1.1 Subscription via PRISMA

PRISMA European Capacity Platform is a joint initiative developed in cooperation with other EU transmission systems operators (e.g. from Austria, Belgium, Denmark, France, Germany, Italy, United Kingdom, Ireland and the Netherlands) with the goal to implement a joint platform implementing of the European Network Code for Capacity Allocation Mechanisms ("CAM NC")³⁷.

On ~~PRISMA~~, Entry and Exit services at interconnection points can be subscribed in the form of bundled products with the relevant adjacent transmission system operators or in the form of unbundled products with Fluxys Belgium.

On PRISMA, Entry and Exit services can either be subscribed using the first-committed-first-served principle or in auctions. Fluxys Belgium offers as well the possibility to convert Entry and Exit services into short haul services through the registration of such conversion via PRISMA.

On PRISMA, the unbundled capacity services offered using the first-committed-first-served principle can be booked at any time taking into account a minimum leadtime of 120 min and this on 24/7 basis. Services are marketed in non-standardized durations³⁸, which can either be within-day products (balance of gas day product) or products with a minimum period of 1 day and for which there is no maximum period. These capacity services are allocated in the order as they have been requested, for as long as capacity services are available.

On PRISMA, capacity services offered in auctions are marketed in standardized durations, called standard products, which can either be within-day (balance of gas day product), daily (for a duration of one gas day), monthly (from 1st gas day to last gas day of any calendar month), quarterly (starting on the 1st of October, 1st of January, 1st of April or the 1st of July respectively) or yearly (starting on the 1st of October).

If applicable, for services auctioned on PRISMA, the interruptible services will be offered after the closure of the firm auctions for the same product period. For the remaining interconnection points, interruptible capacities are allocated as requested.

In accordance with the article 3 paragraph 5 of the CAM NC, competing auctions may be set up. These auctions provide the TSO the ability to offer a limited amount of capacity available in two different auctions, where the market indicates via the auction process which auction is the most requested. This is the case for the 1-N auctions situation, where N can be the number of TSOs

~~³⁵ In case PRISMA is not available the TSO keeps the possibility to offer the available capacity on the Electronic Booking System, or in written form, as the case may be, and grid user/network user has the right to send its service request for such service period directly to the TSO in written with the appropriate form.~~

³⁷ Commission Regulation EU (No) 984/2013 (CAM NC) has entered into force after its publication in the Official Journal of the European Union in late 2013 and is applicable since 1 November 2015; the allocation processes on PRISMA are based on this official version of the CAM NC.

³⁸ A quality conversion request for H→L should be a balance of gas year product with a minimum service period of 1 gas day, starting at the earliest on the 1st of October of each gas year and with a service period which ends at 30 September of that gas year. The quality conversion services shall be allocated to grid user/network user taking into account the availability of necessary logistics contracts.

at one side of the border (e.g. Eynatten 2) or can be the number of products available at one side of the border (e.g. IZT).

Example: Fluxys Belgium has 100 MWh/h available exit capacity at Eynatten 2; on the German side, two TSOs each have 75 MWh/h available. Instead of Fluxys Belgium in advance chooses to make a bundled product of the maximum 75MWh/h with TSO 1 and the 25 MWh/h remaining product with TSO 2, the competing auction will generate a range of two auctions of 75 MWh/h with an overall limit of 100 MWh/h.

On PRISMA, auctions are held according to a European-wide agreed calendar which is determined annually and published on ENTSOG website, but reflected on PRISMA and on Fluxys Belgium websites as well.

The auction premium that can result from the auction process applied to allocate the bundled products is split between Fluxys Belgium and the concerned adjacent transmission system operators in accordance with a key subject to approval by the competent regulatory authorities. The part of such auction premium relating to the services subscribed with Fluxys Belgium is invoiced to the grid user network users by Fluxys Belgium on top of the reserve price being the regulated tariff, according to section 7.

On PRISMA, auctions are held according to two possible algorithms: ascending clock or uniform price.

4.1.1.1 Ascending Clock

For the auctioning of yearly, quarterly and monthly services, an ascending clock auction algorithm is applied.

During consecutive bidding rounds, grid user network users are invited to submit quantity bids. A quantity bid specifies the amount of capacity that the grid user network user would like to acquire at the proposed price of such bidding round. The reserve price in the first bidding round is equal to the sum of the reserve prices at each side of the interconnection point, with such reserve price being the regulated tariff for the Belgian part of the bundled products. In subsequent bidding rounds, the price for the bundled products is increased by fixed large price increments until the sum of the submitted bid quantity bids is smaller than or equal to the amount of capacity offered.

At that stage, the price is brought back to the price of the previous bidding round. A new series of bidding rounds is launched, in which the price is subsequently increased by small price increments until the sum of the submitted quantity bids is lower than or equal to the amount of capacity offered. In this case the auction is finished. The capacities are allocated according to the last quantity bids at the premium, equal to the sum of the large price increments and small price increments having led to the last bidding round, to be added to the sum of the respective reserve prices.

For each product the large and small price increments are fixed, defined and published on www.prisma-capacity.eu. The amount of capacities offered is published at www.prisma-capacity.eu before the beginning of each auction and in a timely manner.

4.1.1.2 Uniform Price

For the auctioning of daily and within-day services, a uniform price auction algorithm will be applied:

Grid user Network users submit their bids or bidding lists during only one bidding round. A bidding list can contain up to 10 bids. Each bid contains the requested capacity amount, the minimum capacity amount and the price at which the grid user network user would like to

acquire this capacity amount, it being understood that the reserve price is equal to the sum of the reserve prices at each side of the interconnection point, with such reserve price being the regulated tariff for the Belgian part of the bundled products.

At the end of the bidding round, capacity is allocated to the bids in function of their price ranking, i.e. the requested capacity amount of the bid with the highest price is allocated first. After each allocation, the remaining unallocated capacity is reduced by the same quantity. Each bid is considered successful if capacity can still be allocated in accordance with the minimum capacity amount requested in the bid. All successful bids are allocated at the price of the lowest successful bid if demand exceeds the offered capacity. In all other cases, all successful bids are cleared at the reserve price.

~~Beside the services offered on PRISMA through auctions or through a first-committed-first-served principle, Fluxys Belgium offers as well the possibility to convert Entry and Exit services into short haul services through the registration of such conversion via PRISMA. All network users having newly acquired³⁹ firm and/or backhaul entry and exit services in the last 15 days on the primary market eligible for wheeling and OCUCs, will have the possibility to convert these entry and exit services into a wheeling or an OCUC.~~

4.1.2 Subscribing services with Fluxys Belgium directly.

Beside the services exclusively offered on PRISMA, other services can be booked at any time in writing or via the electronic booking system (hereinafter EBS). If the requested services via EBS are available both in terms of the service period as the available capacity, then the request will be directly confirmed via EBS. For example, capacity services at ~~domestic exit pointdomestic points~~ can be subscribed via EBS on 24/7 basis.

Services are offered for a minimum period of one day (gas day from 6:00 AM to 6:00 AM) and there is in general no maximum period, except for the services where another period is explicitly determined (interruptible, Fix/Flex rate type, or H/L quality conversion – see section ~~0003~~).

The Fix/Flex rate type for exit services on end user ~~domestic exit pointdomestic points~~ can only be requested on an annual basis during a window. It can only be attributed per period of 1 or several calendar years, starting on January 1st, for all ~~grid usernetwork users~~ active on a given end user ~~domestic exit pointdomestic point~~.

In general, services not offered on PRISMA, are allocated as requested, with the exception of services offered in a subscription window, implicitly allocated, through an Open Season process or Incremental Process. Fluxys Belgium allocates these services based on the order of receipt of ~~grid usernetwork users~~' applications.

~~The TSO also offers all grid users having entry and exit services the possibility to convert those into a wheeling or an operational capacity usage commitment⁴⁰ with the TSO, under following restrictive conditions:~~

- ~~• only yearly, quarterly or monthly eligible entry and exit services can be converted⁴¹;~~

³⁹ For the avoidance of doubt newly acquired Services in the framework of Substitution Services are not eligible for the conversion to a Wheeling or an Operational Capacity Usage Commitment

⁴⁰ A PRISMA based solution is being developed which then will replace this manual solution.

⁴¹ Except for Dunkirk LNG where OCUC are offered associated with a Cross Border Delivery Service for the same period service which can be shorter than for monthly capacities.

- ~~the grid user has a period of 1 week, after the allocation of its capacities, to send in his request to convert the entry and exit services into a wheeling or an operational commitment usage commitment which must be equal in quantity. The period remains identical as initially contracted.~~

4.1.3 Services implicitly allocated by Fluxys Belgium

There are ~~3-4~~ types of services implicitly allocated by Fluxys Belgium, where the ~~grid user~~network user has no need to subscribe capacity for using services.

For domestic exit capacity to distribution networks, Fluxys Belgium implicitly allocates the peak capacity on a monthly basis to ~~grid user~~network users based on their market share of final customers within each distribution network, taking into account the different final customers profile segmentations (see section 3.2.1).

The firm and operational interruptible services at Loenhout are implicitly allocated by Fluxys Belgium to ~~grid user~~network users according to the subscribed storage services with Fluxys Belgium at the Loenhout underground storage facility (see section ~~0003.1.1~~).

To perform the imbalance transfer service (see section ~~3.6.13-6.13.7.13-9.1~~), Fluxys Belgium will implicitly allocate entry or exit transmission services at interconnection point Zeebrugge if the ~~grid user~~network user has no more unused entry or exit capacity in its portfolio⁴².

Interruptible services are implicitly allocated by Fluxys Belgium to network users in case overnomination is being activated for such connection point and insofar network users are requesting interruptible services by sending nominations which exceed their subscribed capacity.

4.1.4 Incremental capacity process and Open Seasons

Fluxys Belgium can assess the market potential for new capacity to be developed by means of Open Seasons or Incremental Capacity Process as defined in the Access Code for Transmission. At least every odd year, and at the latest 16 weeks after the start of the annual yearly auctions, Fluxys Belgium will, jointly with its Adjacent TSOs, publish a Demand Assessment Report, analysing the market demand and potential for new or incremental capacity at interconnection points, and concluding on the need – nor absence thereof – to further proceed with incremental capacity projects.

4.2 Trading capacity on the secondary market

~~Grid user~~Network users are legally bound (pursuant to Article 11 of the code of conduct) to make available on the secondary market, the subscribed firm capacity which they no longer need, for a specific period or permanently.

Fluxys Belgium organises the secondary market by enabling ~~grid user~~network users to trade capacity services they no longer need on an electronic market platform, Fluxys Belgium uses PRISMA (“PRISMA secondary”) for such purpose.

⁴² Being the sum of subscribed capacities on ~~interconnection~~interconnection ~~points~~points Zeebrugge, ~~ZPT~~, IZT and ~~installation point~~Zeebrugge LNG Terminal.

PRISMA secondary allows grid user network users to trade capacity services among themselves or with the TSO, either anonymously or through registration of over-the-counter transactions.

Aside from PRISMA secondary, transmission services can always be traded on the secondary market by a standard written “over the counter” assignment procedure which is detailed in the access code for transmission.

5 OPERATING RULES

5.1 Nominations

In order to notify Fluxys Belgium of the quantity of natural gas that will be delivered at each connection point, installation point, exit point, the grid user network user shall send nominations and, if applicable, renominations to Fluxys Belgium, according to the procedure detailed in the access code for transmission. No nominations have to be sent for distribution ~~domestic exit point~~ domestic points.

A nomination is a standardised electronic message issued by the grid user network user via Edig@ds protocol. It relates to a particular gas day (a gas day begins at 06:00 hours and terminates at 06:00 hours the following day, Belgian time) and to a specific point, and provides for each hour of the relevant gas day the quantities of natural gas, expressed in kWh, that the grid user network user wishes to inject or offtake under its subscribed services at the relevant point.

The time schedule for the nominations and the renominations cycles for a given gas day are described in the access code for transmission and are based on the EASEE-gas common business practice⁴³. The first nomination cycle begins at 14:00 hours of the preceding gas day and is composed of the following steps:

- The grid user network user sends his nominations to Fluxys Belgium
- Fluxys Belgium checks the validity of the message format
- The nominations are processed by Fluxys Belgium (conformity checks and matching with the nominations in the adjacent system)
- Fluxys Belgium computes the quantities that can be confirmed and that are scheduled to be delivered/offtaken to/from the transmission grid
- Fluxys Belgium sends a confirmation message in order to communicate to the grid user network user the results of the process.

Fluxys Belgium supports both double sided nominations and single sided nominations⁴⁴. In double sided nominations, matching nominations have to be submitted to both Fluxys Belgium and the Adjacent TSO, while in single sided nominations only one nomination is required with one of the TSOs. The TSOs have to define⁴⁵ in which network the grid user network users will be the active and the passive grid user network users, whereby the active grid user network user is sending the nominations as described above towards the active TSO. The passive grid user network user will have to send only once a declaration notice to the passive TSO. Both grid user network users

⁴³ EASEE-gas Common Business Practice 2003-002/01 “Harmonisation of the Nomination and Matching Process”, as approved on February 18, 2004 (see <http://www.easee-gas.org/cbps.aspx>)

⁴⁴ Single sided nominations will optionally be made available to Grid User Network users as from 1 November 2015, provided that the necessary Edig@ds messages have been published by EASEE-gas, taking the necessary implementation time, that the Adjacent TSO has developed the capability to support single sided nominations, that both TSOs have agreed upon their respective role, and that the concerned Grid User Network user(s) have indicated their respective roles.

⁴⁵ The information will be published per IP on Fluxys Belgium website, once the necessary agreements on those roles are in place with the respective TSOs

~~user~~network users will receive, after conducting a capacity check, the confirmation of the active and/or passive TSO.

The ~~grid~~usernetwork user may revise its nominations on a day-ahead or intraday basis by sending renominations. During the gas day a renomination is considered valid when received before the applicable minimum renomination lead time and will be processed for confirmation according to the same process as described above. The standard minimum renomination lead time is "full hour + 2". For net confirmed title transfers (NCTTN_{n,z}) relating to ZTP notional trading services, the notification is accepted until 30 minutes before the considered hour. For other points, Fluxys Belgium plans to reduce this lead time to "full hour + 1"⁴⁶ subject to harmonization on that matter between adjacent TSOs. Fluxys Belgium will inform the ~~grid~~usernetwork users accordingly and confirm the start date of such potential change in due course.

5.2 Metering and allocations

The metering procedures are specified in the access code for transmission. Based on the metering services that cover metering at metering facilities, validation of measurements and measurement repatriation, Fluxys Belgium allocates gas quantities at the ~~interconnection points~~ and end user domestic exit points on an hourly basis to the involved ~~grid~~usernetwork user(s). The unit used for the allocation is the kWh.

Two types of allocations can be distinguished. The first is the provisional allocation which is based on the hourly provisional measurement and is communicated to the ~~grid~~usernetwork user within 30 minutes after the hour to help him steer its balancing position. In the second type, the validated allocation which is based on the validated measurements Fluxys Belgium determines at the latest on the 20th day of the month following the month for which the allocations are to be validated and which are used for the final gas settlements between Fluxys Belgium and the ~~grid~~usernetwork user.

Two types of gas allocation rules can be distinguished at the interconnection points or installation points. First, the "deemed to confirmed nomination" rule where the allocated energy equals the last confirmed energy nominations as confirmed by the adjacent TSO⁴⁷. Second, the "proportional to measurement" rule where the allocations will be proportional to the energy measurements.

For the end user ~~domestic exit point~~domestic points, the domestic ~~exit~~ energy allocation allocated to the ~~grid~~usernetwork users shall be determined according to the allocation agreement valid for this connection point (agreement between Fluxys Belgium, the end user and the ~~grid~~usernetwork users supplying natural gas to or injecting from the said end user). The pooling of capacity is possible at end user ~~domestic exit point~~domestic points to allow ~~grid~~usernetwork users supplying the same end user to pool and share each other's entire subscribed exit capacity for such end user ~~domestic exit point~~domestic point. The pooling of capacity needs to be described in the specific allocation rule at the given end user ~~domestic exit point~~domestic point on which concerned ~~grid~~usernetwork users need to agree upon in the allocation agreement, as detailed in the access code for transmission.

For the distribution ~~domestic exit point~~domestic points, the allocation is based on the telemetered value at the connection point with the distribution network, and based on the ~~grid~~usernetwork user

⁴⁶ For quality conversion services, the renomination lead time is and remains "full hour+6".

⁴⁷ The difference between the sum of the hourly allocated quantities and the metered quantities will be allocated to an operating balancing account (OBA) held between Fluxys Belgium and its adjacent TSO or any other party

usernetwork user's portfolio of producers and final customers on that distribution network, who can be either telemetered final customers or profile-based final customers. Furthermore, an imbalance smoothing profile, aiming at neutralising, on a daily basis, part of the imbalance caused by the hourly profiled offtake within distribution networks, is allocated to the grid usernetwork users supplying final customers on the distribution networks. The hourly imbalance smoothing allocations of each grid usernetwork user are calculated according to the total forecasted offtake of the distribution networks and the provisional allocations for each grid usernetwork user to the distribution networks, as described in the access code for transmission. They are communicated to the relevant grid usernetwork users by Fluxys Belgium on a day-ahead basis and indicatively forecasted for the next 3 days.

5.3 Data transmission

In accordance with transparency obligations under European regulation and the Belgian code of conduct, Fluxys Belgium publishes information on the operational data of its transmission grid on its website (<http://www.fluxys.com/belgium>) where market parties can find a variety of useful information. Data for all relevant parameters are updated hourly or daily as the case may be and users can retrieve customised reports tailored specifically to their needs.

The following information (and more) is publicly available on our electronic data platform:

- Interconnection points and installation points: capacities, nominations, allocations and flows at the interconnection points with adjacent operators
- Consumption: capacities, nominations, allocations and flows for domestic consumption
- Secondary market: capacities traded on the secondary market and their average price
- Temperatures: daily equivalent and degree-day temperatures and their forecast
- List of end users connected to the Fluxys Belgium transmission grid
- Pre-defined reports: supply, demand, storage and LNG reports using a predefined selection of criteria in accordance with ENTSOG guidelines (European Network of Transmission System Operators for Gas).

As part of the standard transmission agreement or connection agreement Fluxys Belgium also provides personalised data services via the electronic data platform, yet only privately accessible to ~~grid user network users~~ or end users, that allows them to visualize, consult or download their own individualised operational data such as:

- hourly measurements including volume, pressure and gross calorific composition of the natural gas at the connection points ~~domestic exit~~ where they are active;
- hourly allocation data for the interconnection connection points ~~domestic exit points~~ where they are active⁴⁸;
- all data required to check Fluxys Belgium invoices.

Fluxys Belgium furthermore offers a real-time data service which can additionally be subscribed by ~~grid user network users~~ and which provides them with on-line gas flow data (updated every 6 minutes) for selected interconnection points, privately available on the electronic data platform.

5.4 Gas quality requirements

The Fluxys Belgium web site —(<http://www.fluxys.com/belgium>) —provides the technical specifications in force for all the interconnection connection points on the Fluxys Belgium grid for gas entering or leaving the grid. Operational rules are explained in the access code for transmission. Furthermore, exits towards IZT and Zeebrugge are subject to compliancy with UK gas quality requirements. Fluxys Belgium will use its reasonable endeavours to bring gas exiting IZT within UK Wobbe specifications. If taken measures prove insufficient, Fluxys Belgium has the possibility to constraint the exit gas towards IZT and/or Zeebrugge of ~~Grid User Network users~~, in proportion of the gas they injected within the transmission grid which was off-specification with regards to UK Wobbe specifications.

⁴⁸ Note that allocation data is also provided via standardized electronic messages based on the Edig@S protocol.

6 BALANCING REGIME AND ALLOCATION SETTLEMENTS IN THE BELUX AREA

Balancing services are operated by the Balancing Operator. As prerequisite to the use of services within the BeLux area and to the use the of the notional trading services offered by Fluxys Belgium, a grid user/network user is required to subscribe a Balancing Agreement with the Balancing Operator, unless explicitly otherwise expressed.

Balancing Services-services operated by the Balancing Operator are based on provisional data (H+1). The quantity to be settled for a given Gas-gas Day-day for a Grid-User-network user, in a given Zone is calculated as the sum of the difference between the provisional and the final data and are settled between the grid user and the concerned TSO of the Belux area.

In case of difference, settlement is calculated at the latest the 20th day after the relevant month and will be financially handled during the next invoicing cycle.



7 INVOICING

According to the terms and conditions set forth in the standard transmission agreement, invoices are usually issued monthly by Fluxys Belgium to grid user network users, on the 10th day of the month. Invoices will be rendered either electronically either by letter or fax. A copy of the invoices and all their related appendices will be made privately available on the electronic data platform. Generally speaking, invoices are due within 30 business days after receipt and failure to respect terms of payment may lead to the provision of financial security by the grid user network user or the suspension of such services.

As detailed in the attachment A of the access code for transmission, two types of invoice are issued to grid user network users with respect to the total monthly fee for their subscribed services:

- Monthly invoice,
- and
- Monthly self-billing invoice.

The monthly invoice on the 10th day of a given month M will contain:

- The monthly capacity fees relating to subscribed or implicit allocated services, including additional services, for month M and additionally subscribed services in month M-1 and not already invoiced in M-1.
- The monthly capacity fees relating to distribution domestic ~~exit~~ services, provisionally allocated for such month M and the correction for such fees relating to distribution domestic ~~exit~~ services, finally allocated for month M-3.
- The monthly variable flex fee relating to services subscribed on end user ~~domestic exit point~~ domestic point with Fix/Flex rate type, based on final allocations for month M-3.
- The monthly fix fees relating to the ZTP trading services for the month M.
- The monthly commodity fee (relating to ~~interconnection points and end user domestic exit point~~ domestic points) for month M-2.
- The monthly allocation settlement fees in case of purchase for month M-3.
- The monthly odorisation fee for end user ~~domestic exit point~~ domestic points for month M-3.
- The monthly transmission imbalance fee for month M-3.
- The monthly commodity fee for peak load quality conversion service H->L for month M-3.
- The monthly commodity fee (relating to distribution ~~domestic exit point~~ domestic points) for month M-3.
- The monthly variable fee relating to ZTP trading services for month M-3.
- The monthly incentive fees for month M-3.
- The monthly administrative fees for month M-3.

The monthly self-billing invoice on the 10th of a given month M will cover:

- The monthly allocation settlement fees in case of sale for month M-3.

A summary of the consolidated invoices by due date will be transferred to the grid user network user for each month, including a summary note with the balance payable to the TSO or refund to the grid user network user.

Conveniently, the grid user network user may choose between:

- The payment of the consolidated amounts, as calculated in the summary note or, ~~4~~
- The payment of the total monthly fee(s) to the TSO and the payment of the total monthly self-billing fee(s) of the TSO to the network user.

8 CONGESTION MANAGEMENT

8.1 Proactive congestion management policy

In accordance with its obligations set out in the code of conduct, Fluxys Belgium applies a proactive congestion management policy aiming to achieve optimal and maximal utilisation of available capacities and prevent congestion. This policy, detailed in the access code for transmission, is based on the following set of measures.

A secondary market is organised by Fluxys Belgium as detailed in section 4.2, via an electronic capacity trading platform, Prisma, enabling ~~grid user network users~~ to offer the subscribed transmission services they no longer require to other ~~grid user network users~~. This allows for the optimal and market-based distribution of transmission services amongst ~~grid user network users~~ and is supported by the regular publication by Fluxys Belgium of aggregated volumes and average prices of the services traded on the secondary market.

Interruptible capacities are offered at ~~interconnection points and domestic exit points~~ as detailed in section 3 from the moment the level of available firm services becomes limited. Such interruptible services enable the dynamic recycling of unused subscribed firm transmission services to other ~~grid user network users~~.

Fluxys Belgium also encourages the utilisation of subscribed transmission services by keeping an electronic register of the utilisation rate of subscribed transmission services for each ~~grid user network user~~ and for each service. This register is submitted to CREG at least annually, as set out in the code of conduct. Each ~~grid user network user~~ is also provided with part of the register concerning his individual data.

~~Grid user Network users~~ have furthermore the possibility to post firm transmission services they wish to sell at Fluxys Belgium (surrender of contracted capacity). Interested ~~grid user network users~~ are allowed to respond to this offer, either directly or via PRISMA.

Furthermore, as another measure to apply a proactive congestion management policy, Fluxys Belgium allows the conversion of entry and exit services into wheeling and/or operational capacity usage commitment under defined conditions (see 3.3 and 4.1).

8.2 Congestion management procedure

Congestion occurs when a service request for firm transmission services at a ~~interconnection connection point or an end-user domestic exit point domestic connection point~~ cannot be confirmed due to the lack of available firm transmission services and if none of the proactive congestion management measures detailed in the access code for transmission or any other alternatives envisaged between Fluxys Belgium and ~~grid user network user~~ have provided for an acceptable solution.

8.2.1 Interconnection Points

In consequence of Annex 1 of the Regulation (EC) No 715/2009 three (3) specific congestion management procedures are applicable on interconnection points in particular:

- “surrender of contracted capacity” as congestion measure against contractual congestion, in order to bring unused capacity back to the market, as described in section 8.1;
- “long-term use-it-or-lose-it mechanism” in order to bring unused capacity back to the market upon decision of CREG or;
- “capacity increase through oversubscription and buy-back scheme” in order to create additional firm capacity.

8.2.1.1 Long-term use-it-or-lose it mechanism

The “long-term use-it-or-lose-it” procedure is designed to release all or part of the unused subscribed firm transmission services of grid user network users, upon decision of CREG. The TSO, on behalf of grid user network users, shall offer the released services on the primary market per periods of 2 months as foreseen in the code of conduct .

This release will be performed after notification to the relevant grid user network users of the amounts subject to possible release. In the absence of response from the grid user network user within the scheduled period, such amounts will be automatically released on the secondary market. However, a response from the grid user network user will lead to a decision of the CREG on the quantities which are finally released and effective.

8.2.1.2 Capacity increase through oversubscription and buy-back scheme

In order to solve contractual congestion Fluxys Belgium may offer firm transmission services in the framework of oversubscription, on top of the technical capacity. In determining this oversubscription firm capacity, Fluxys Belgium will take into account:

- statistical scenarios for the likely amount of physically unused capacity at any given time at interconnection points;
- technical conditions, such as the gas gross calorific value, temperature and expected consumption; and
- a risk profile for offering this additional firm capacity which does not lead to excessive buy-back obligations.

Where necessary to maintain system integrity, Fluxys Belgium will apply a market-based buy-back procedure in which grid user network users can offer firm transmission services back to the TSO.

8.2.2 End user domestic exit point domestic points and installations points

For end users domestic exit point domestic points and installations points, a long-term use-it-or-lose-it can be applied. This mechanism is similar to the mechanism applied for interconnection points in section 8.2.1.1.



9 HOW TO CONTACT US

Any request for additional information or questions in relation to the service offer should be addressed to:

Fluxys Belgium SA/NV
Direction Commercial Regulated
Avenue des Arts, 31
1040 Brussels
Belgium

E-mail: info.transport@fluxys.com or marketing@fluxys.com

